

NORMAL STEP

FULL PROCEDURE STEP

CONDITIONAL STEP

NON-FUNCTIONAL STEP

FULL PROCEDURE SUB-STEP

CONDITIONAL SUB-STEP

NON-FUNCTIONAL SUB-STEP

INTERIOR INSPECTION / RESET CHECKLIST

Left Horizontal Panel	1. REGLAGEBROMS LEVER (Auto-throttle)	UP
	2. GEAR HANDLE	B / DOWN
	3. KABINL. GOLV KNOB (Cabin Air Flow)	CLOSED
	4. BELYSNING KNOBS (Interior Lights)	FULLY CCW
	5. NÖDTRIM ROLL SWITCH (Roll Trim)	CENTRED
	6. NÖDTRIM TIPP SWITCH (Pitch Trim)	CENTRED
	7. SIDTRIM SWITCH (Yaw Trim)	CENTRED
	8. LJUS RADAR KNOB (Radar Brightness)	FULLY CCW
	9. VOL KNOB (Radio Volume)	FULLY CW
	10. MIK BAND SWITCH (Voice Recorder)	CENTRED
	11. FR24 MODE SELECTOR	NORM+LARM
	12. RENFLYGN KNOB (Autopilot Yaw Trim)	0
	13. NÖDSKJUT HUV BUTTON (Canopy Jettison)	CHECK
	14. AS SELECTOR (Anti-jamming Mode)	0
	15. PASSIV SPAN SWITCH (Passive Reconnaissance)	FRÅN / DOWN
	16. PULS SWITCH (Radar Pulse Setting)	KORT / DOWN
	17. LOG/LIN SWITCH (Logarithmic/Linear Radar Gain)	LOG
	18. LAND/SJÖ SWITCH (Land/Sea Doppler Mode)	LAND
	19. MASTER MODE SELECTOR	BER
	20. T-F SWITCH (Start System)	F / RIGHT
	21. TÄNDSYSTEM SWITCH (Ignition System)	AUT / LEFT
	22. GENERATOR SWITCH (Generator)	FRÅN / RIGHT
	23. HUVUDSTRÖM SWITCH (Main Power)	FRÅN / DOWN
	24. LT-KRAN SWITCH (Low-pressure Fuel Valve)	FRÅN / DOWN
25. FR22 GROUP and BASE SELECTOR KNOBS Refer to kneeboard for relevant ground and base channels.	AS REQUIRED	
26. A/G BUTTON	DEPRESSED	
27. PITCH TRIM GAUGE	0	
28. BROMSTR. GAUGE (Brake Pressure)	0	
29. KAB.TR. GAUGE (Cabin Pressure)	0	
Radar Stick	1. A0/A1/A2 SWITCH (Radar Mode)	A0 (UP)
	2. T0/T1/TV TRIGGER (Fix Point)	T0 (RELEASED)
	3. TERRAIN AVOIDANCE BUTTON	CHECK
	4. MINNE BUTTON (Memory Mode)	CHECK

LFP = Left Front Panel — CC = Central Console — RFP = Right Front Panel — CTS = Control Stick
LHP = Left Horizontal Panel — LSP = Left Side Panel — LWP = Left Warning Panel — TRS = Throttle & Radar Stick
RWP = Right Warning Panel — RHP = Right Horizontal Panel — RSP = Right Side Panel

NORMAL STEP

FULL PROCEDURE STEP

CONDITIONAL STEP

NON-FUNCTIONAL STEP

FULL PROCEDURE SUB-STEP

CONDITIONAL SUB-STEP

NON-FUNCTIONAL SUB-STEP

INTERIOR INSPECTION / RESET CHECKLIST

Left Side Panel	1. IR-RB FRAMSTEGN <i>BUTTON</i> (Missile Select)	CHECK																				
	2. LJUDSTRYRKA UK DAMP <i>KNOB</i> (Master Volume)	FULLY CCW																				
	3. CANOPY LEVER	CENTRED																				
	4. KB <i>SWITCH</i> (Countermeasure release <i>switch</i>) NB: The livery is based on an older Viggen version where this switch controlled the emergency receiver. The three modes – FRÅN / INT / KONT are not marked as such.	FRÅN / AFT																				
	5. TAXI/LANDING LIGHTS <i>SWITCH</i> (Aft, Unlabelled)	UP (OFF)																				
	6. EMERGENCY LIGHTS <i>SWITCH</i> (Front, Unlabelled)	UP (OFF)																				
	7. KONTR. LAMPTABLÅ <i>BUTTON</i> (Warning Lights Test)	CHECK																				
Left Warning Panel	1. WARNING LIGHTS	OFF																				
	<table border="1"> <tr> <td>BRAND (Engine fire)</td> <td>TIPPVÄXEL (Pitch gearing)</td> </tr> <tr> <td>BRAND (Engine fire)</td> <td>ELFEL (Electrical failure)</td> </tr> <tr> <td>BRÅ UPPF (Low fuel pressure)</td> <td>RESERVEFF (Backup hydro./gen. fault)</td> </tr> <tr> <td>X-TANK BRÅ (External fuel feed fault)</td> <td>HYDR-TR 2 (Low hydraulics 2 pressure)</td> </tr> <tr> <td>TANK PUMP (Tank pump fault)</td> <td>HYDR-TR 1 (Low hydraulics 1 pressure)</td> </tr> <tr> <td>LANDSTÄLL (Landing gear)</td> <td>AFK FEL (Autothrottle failure)</td> </tr> <tr> <td>FÖRV FÖRBJ (Thrust reverser warning)</td> <td>EJ REV (Thrust reverser failure)</td> </tr> <tr> <td>NOSSTÄLL (Nose gear locked)</td> <td></td> </tr> <tr> <td>V-STÄLL (Left gear locked)</td> <td>OLJETRYCK (Oil pressure warning)</td> </tr> <tr> <td>H-STÄLL (Right gear locked)</td> <td>OLJETEMP (Oil temperature warning)</td> </tr> </table>	BRAND (Engine fire)	TIPPVÄXEL (Pitch gearing)	BRAND (Engine fire)	ELFEL (Electrical failure)	BRÅ UPPF (Low fuel pressure)	RESERVEFF (Backup hydro./gen. fault)	X-TANK BRÅ (External fuel feed fault)	HYDR-TR 2 (Low hydraulics 2 pressure)	TANK PUMP (Tank pump fault)	HYDR-TR 1 (Low hydraulics 1 pressure)	LANDSTÄLL (Landing gear)	AFK FEL (Autothrottle failure)	FÖRV FÖRBJ (Thrust reverser warning)	EJ REV (Thrust reverser failure)	NOSSTÄLL (Nose gear locked)		V-STÄLL (Left gear locked)	OLJETRYCK (Oil pressure warning)	H-STÄLL (Right gear locked)	OLJETEMP (Oil temperature warning)	
	BRAND (Engine fire)	TIPPVÄXEL (Pitch gearing)																				
	BRAND (Engine fire)	ELFEL (Electrical failure)																				
	BRÅ UPPF (Low fuel pressure)	RESERVEFF (Backup hydro./gen. fault)																				
	X-TANK BRÅ (External fuel feed fault)	HYDR-TR 2 (Low hydraulics 2 pressure)																				
	TANK PUMP (Tank pump fault)	HYDR-TR 1 (Low hydraulics 1 pressure)																				
	LANDSTÄLL (Landing gear)	AFK FEL (Autothrottle failure)																				
	FÖRV FÖRBJ (Thrust reverser warning)	EJ REV (Thrust reverser failure)																				
	NOSSTÄLL (Nose gear locked)																					
V-STÄLL (Left gear locked)	OLJETRYCK (Oil pressure warning)																					
H-STÄLL (Right gear locked)	OLJETEMP (Oil temperature warning)																					
Left Front Panel	1. SPAK LAMP <i>BUTTON</i> (Stick Dampening AP mode)	OFF																				
	2. ATT LAMP <i>BUTTON</i> (Attitude Hold AP mode)	OFF																				
	3. HÖJD LAMP <i>BUTTON</i> (Altitude Hold AP mode)	OFF																				
	4. AFK <i>LIGHT</i> (Autothrottle Annunciator)	OFF																				
	5. α15,5° <i>BUTTON</i> (Autothrottle Mode 3)	OFF																				
	6. AIRSPEED GAUGE	0 km/h, M0.00																				
	7. RADIO FREQUENCY SELECTOR	CHECK																				
	8. FM/AM <i>SWITCH</i>	AM																				
	9. REV <i>LAMP</i> (Thrust Reverser Annunciator)	OFF																				
	10. REV <i>HANDLE</i> (Thrust Reverser Armed)	IN																				
	11. HUVUDVARNING <i>LAMPS</i> (Master Caution)	OFF																				
	12. α <i>GAUGE</i> (Angle of Attack)	0																				
	13. ATTITUDE DIRECTION INDICATOR (ADI) - Attitude - Heading - Slip ball - "Off" warning flag - Vertical Speed	CHECK Level Check Level Showing 0																				
	14. HÖJD <i>GAUGE</i> (Barometric altimeter) - QFE Selector	CHECK Check																				

LFP = Left Front Panel – CC = Central Console – RFP = Right Front Panel – CTS = Control Stick
LHP = Left Horizontal Panel – LSP = Left Side Panel – LWP = Left Warning Panel – TRS = Throttle & Radar Stick
RWP = Right Warning Panel – RHP = Right Horizontal Panel – RSP = Right Side Panel

NORMAL STEP

FULL PROCEDURE STEP

CONDITIONAL STEP

NON-FUNCTIONAL STEP

FULL PROCEDURE SUB-STEP

CONDITIONAL SUB-STEP

NON-FUNCTIONAL SUB-STEP

INTERIOR INSPECTION / RESET CHECKLIST

Central Console	1. HEADS UP DISPLAY	OFF
	2. HUD BRIGHTNESS KNOB	CHECK
	3. CENTRAL INDICATOR - Altitude warning light - Heading - Commanded course index - Warning flag - Radar display - Radar Warning Receiver lights - Snabbresning button (<i>Fast erect</i>)	CHECK Off Check Check Showing Off Off Check
	4. PARK LEVER (Parking Brake)	IN
Control Stick	1. TRIGGER SAFETY	DOWN
	2. TRIGGER	CHECK
	3. AUTOPILOT DISCONNECT BUTTON	CHECK
	4. REFERENCE BUTTON	CHECK
	5. TRIM HAT	CHECK
	6. FR-22 TRANSMIT/RECEIVE BUTTON	CHECK
Right Front Panel	1. EP-13 SIGHT	CHECK
	2. CLOCK	CHECK
	3. FÄLLD LAST LIGHT (Stores Released)	OFF
	4. SLAV SI SWITCH (HUD Slave source)	I / RIGHT
	5. HÖJD CI SI SWITCH (HUD Altitude source)	RHM / LEFT
	6. ACCELEROMETER	1
	7. REV AVDR TRANSONIC LAMP (Thrust reduce/Transonic warning)	OFF
	8. DESTINATION INDICATOR	CHECK
	9. BACKUP ADI - Error flag	CHECK Showing
	10. BACKUP AIRSPEED GAUGE	2
	11. HÖJD GAUGE (Backup Altimeter) - QFE Selector	CHECK Set to QNH
	12. VARV % GAUGE (RPM Indicator)	0
	13. KURS GAUGE (Backup Compass)	CHECK
	14. AFTERBURNER ZONE SELECTED LIGHTS	OFF
	15. P7/P2 GAUGE (Exhaust Pressure Ratio / EPR Indicator)	1.0
	16. DISTANCE INDICATOR	0 km
	17. BRÄNSLE % GAUGE (Fuel Indicator)	CHECK

LFP = Left Front Panel — CC = Central Console — RFP = Right Front Panel — CTS = Control Stick
LHP = Left Horizontal Panel — LSP = Left Side Panel — LWP = Left Warning Panel — TRS = Throttle & Radar Stick
RWP = Right Warning Panel — RHP = Right Horizontal Panel — RSP = Right Side Panel

NORMAL STEP

FULL PROCEDURE STEP

CONDITIONAL STEP

NON-FUNCTIONAL STEP

FULL PROCEDURE SUB-STEP

CONDITIONAL SUB-STEP

NON-FUNCTIONAL SUB-STEP

INTERIOR INSPECTION / RESET CHECKLIST

1. WARNING LIGHTS		OFF
Right Warning Panel	SPAK (Stick damper failure)	SYRGAS (Oxygen valve off or oxygen low)
	HÅLL-FUNK (AP hold function failure)	BRÄ <24 (Low fuel warning)
	RHM FEL (Radio altimeter failure)	BRAND GTS (Gas turbine starter fire)
	ROLLVÄXEL (Roll gearing fault)	TILS (TILS landing status)
	CK (Computer fault)	NAV-SYST (Navigation system failure)
	KABINHÖJD (Cabin pressure warning)	KB-V SLUT (Left countermeasures depleted)
	HUV o STOL (Canopy unlocked; seat not armed)	KB-H/KA SL (Right c.m:s empty/ECM fault)
	TÄNDSYST (Ignition system active)	FACKL SL (Flares depleted)
	STARTSYST (Engine starter active)	MOTVERK (CM/RWR status)
MAN BR REG (Fuel regulator in 'Manual')	LUFTBROMS (Airbrakes extended)	
Right Horizontal Panel	1. ENGINE NOZZLE GAUGE	S
	2. EXHAUSE GAS TEMPERATURE (EGT) GAUGE	1
	3. SYRGAS GAUGE (Oxygen pressure)	>150kp/cm ²
	4. OXYGEN LEVER	OFF / DOWN
	5. CK37 DATA PANEL - Data selector - IN – UT switch	CHECK ID-NR UT / Right
	6. RB-05 CONTROL STICK	CHECK
	7. DME SWITCH (Legacy DME)	FRÅN / DOWN
	8. RHM SWITCH (Radar Altimeter)	TILL / UP
	9. WAYPOINT BUTTONS - B1–B9 (Waypoint) - Bx (RB-15 nav points) - LS/SKU (Takeoff base/Tracked target toggle) - L/Mål (Landing base/Reconnaissance target toggle)	
	10. TILS SELECTOR (TILS STATION)	A
	11. TILS SWITCH (TLIS Selector Band)	1–10 / LEFT
	12. U22/A MODE and BANDWIDTH SELECTORS	0 / F
	13. KB SELECTOR (Countermeasure Pod Operating Mode)	A
	14. FRÅN – LJUS – LJUS/LJUD SELECTOR (RWR Signalling Mode)	FRÅN
	15. STREAK SELECTOR	0
	16. R – RF – F SELECTOR (Chaff/Flare)	RF
	17. ANTIKOLL-LJUS SWITCH (Anti-collision Lights)	FRÅN / DOWN
	18. LANTERN SWITCH (Navigation Lights)	OFF / CENTRED
	19. FORM-LJUS SWITCH (Formation Lights)	FRÅN / DOWN
	20. LED-LJUS SWITCH (Position Lights)	FRÅN / DOWN
	21. VARMLUFTSPOLN FRONTRUTA KNOB (Windscreen De-icing)	STÄNGT / FULLY CCW

LFP = Left Front Panel – CC = Central Console – RFP = Right Front Panel – CTS = Control Stick
LHP = Left Horizontal Panel – LSP = Left Side Panel – LWP = Left Warning Panel – TRS = Throttle & Radar Stick
RWP = Right Warning Panel – RHP = Right Horizontal Panel – RSP = Right Side Panel

INTERIOR INSPECTION / RESET CHECKLIST

Right Horizontal Panel (cont.)	22. FUNCTION CHECK MODE SELECTOR	0
	23. ÖVRIG EL NIK – RADAR – MOTMEDEL SWITCH (Maintenance Test)	RADAR / CENTRED
	24. KURSKORR KNOB (Magnetic Declination)	CHECK
	25. FUNKTION KNOB (IFF Mode)	CHECK
	26. FORMLJUS \ LEDLJUS SELECTOR (Position Light Brightness)	3
	27. TÄNDSTIFT SWITCH (Ignition Coils)	TILL / UP
28. BR AGG KABINLUFT VENT DRÄKT SELECTOR (Drysuit Ventilation)	0	
Right Side Panel	1. NÖDF BUTTON (Emergency Release)	COVERED
	2. X TANK BUTTON (External Tank Release)	COVERED
	3. WEAPON SELECTOR	SJÖ / PLAN
	4. WEAPON INTERVAL SELECTOR	SPÄNNV 15
	5. FÄLLSÄTT SWITCH (Weapon Release Mode)	NORM SERIE
	6. MÅLVAL / PREP SWITCH (RB04/RB15 Release Mode)	GRUPP VALB
	7. IFF PANEL - TILL – FRÅN switch (On/Off) - Ident button (Identify)	CHECK FRÅN / Down Check
	8. BRÄNSLEREGL. SWITCH (Fuel Regulator)	AUT / DOWN
	9. KONTROLL BUTTON (Indicator System Test)	CHECK
	10. TANKPUMP SWITCH (Fuel Boost Pumps)	CHECK
	11. LT-KRAN EBK SWITCH (AB Fuel Regulator)	ÖPPEN / DOWN
	12. RESERVSTRÖM SWITCH (Backup Generator)	FRÅN / DOWN
	13. TIPPVÄXEL SWITCH (Pitch Gearing)	FRÅN / DOWN
	14. AVISN MOTOR (Engine Anti-icing)	FRÅN / DOWN
	15. CIRCUIT BREAKERS - SA (Autopilot) - HAV (High Alpha Warning) - TRIM SYST (Trim Systems) - CI/SI (Central Indicator and Heads-up Display) - UTSKJ KRETS (Ejection Circuits) - MOTOR (Engine Starter Circuits)	CHECK In In In In In In

END

NORMAL STEP

FULL PROCEDURE STEP

CONDITIONAL STEP

NON-FUNCTIONAL STEP

FULL PROCEDURE SUB-STEP

CONDITIONAL SUB-STEP

NON-FUNCTIONAL SUB-STEP

BEFORE ENGINE START CHECKLIST

Cockpit	1. EJECTION SEAT	SAFE Handle forward
	2. TRIGGER SAFETY	SAFE / DOWN
	3. PARKING BRAKES	ON Depress brakes, pull lever
	4. DATA CARTRIDGE	INSERT
	5. GROUND POWER	REQUESTED If available
Left Horizontal Panel	1. HUVUDSTRÖM SWITCH - HUVUDVARNING lamps - LT-KRAN lamp - TANK PUMP, CK, HUV o STOL, MAN BR REG caution lights - RESERVEFF, HYDRA-TA2, HYDRA-TA1 warning lights - NOSSTÄLL, V STÄLL, H STÄLL advisory lights - ELFEL and RHM FEL if not on ground power	TILL / UP Blinking Illuminates Illuminate Illuminate Illuminate Illuminate
	2. LT-KRAN SWITCH - LT-KRAN lamp	TILL / UP Off
	3. HUVUDVARNING BUTTON	PRESS TO CANCEL
	4. GENERATOR SWITCH	TILL / LEFT
	5. BELYSNING KNOBS	AS DESIRED
	6. MASTER MODE SELECTOR	BER
	7. LANDING GEAR LEVER - NOSSTÄLL, V STÄLL, H STÄLL advisory lights	CONFIRM DOWN Confirm Illuminated
	8. REGLAGEBROMS LEVER	UP
	9. THROTTLE	GROUND IDLE
	10. NÖDTRIM ROLL, TIPP and SIDTRIM SWITCHES If on ground power.	CHECK CENTRED
NOTE If the emergency trim switches have been used, and are not centred, the normal control stick trim system has been disengaged and can only be operated if the TRIMSYST circuit breaker (RSP15) is cycled.		
11. RENFLYGN KNOB	0	
12. FR24 MODE SELECTOR	NORM+LARM	
13. MIK BAND SWITCH	AS DESIRED	
14. LJUS RADAR KNOB	MIDDLE	
15. RADAR - Radar Mode switch - AS selector - PASSIV SPAN - LOG – LIN - Antenna Elevation	SET UP A0 / Up 1 FRÅN / Down LOG Middle	
16. LAND – SJÖ SWITCH	AS REQUIRED According to flight terrain.	

LFP = Left Front Panel – CC = Central Console – RFP = Right Front Panel – CTS = Control Stick
LHP = Left Horizontal Panel – LSP = Left Side Panel – LWP = Left Warning Panel – TRS = Throttle & Radar Stick
RWP = Right Warning Panel – RHP = Right Horizontal Panel – RSP = Right Side Panel

NORMAL STEP

FULL PROCEDURE STEP

CONDITIONAL STEP

NON-FUNCTIONAL STEP

FULL PROCEDURE SUB-STEP

CONDITIONAL SUB-STEP

NON-FUNCTIONAL SUB-STEP

BEFORE ENGINE START CHECKLIST

LHP (cont.)	17. FR22 RADIO - Group and Base channels - Frequency Selector (LFP7) - FM/AM Switch (LFP8)	SET UP As required As required As required
Left Side Panel	1. TAXI/LANDING LIGHTS SWITCH	OFF / UP
	2. EMERGENCY LIGHTS SWITCH	OFF / UP
	3. VENTILATION - Temp - Mode - Emergency Switch	AS DESIRED Set AUT TILL
	4. BACKUP INSTRUMENT ILLUMINATION If on ground power.	CHECK
	5. WARNING PANEL LIGHTS - KONTR LAMPTABLÅ button - All caution, warning, and advisory lamps and lights - ELFEL, RHM FEL, CK lights, if on battery power - X-TANK BRÅ light, if drop tank is empty or not mounted	CHECK Press Illuminate Illuminate Illuminates
Left and Right Front Panels	1. REV HANDLE	IN
	2. ADI,CENTRAL INDICATOR and BACKUP COURSE INDICATOR If on ground power. - Error Flags	CHECK ALIGNMENT and HEADING Stowed
	3. BACKUP ADI If on ground power. - Error Flag - Fast Erect/Cage Knob	CHECK ALIGNMENT Stowed Push if Required
	4. HUD REFLECTOR GLASS	DOWN
	5. SLAV SI SWITCH	F / LEFT
	6. HÖJD CI SI SWITCH	LD / RIGHT
	7. MAIN and BACKUP HÖJD GAUGES Keep QNH on backup altimeter to provide an in-flight reference.	SET QFE and QNH
	8. P7/P2 GAUGE	CONFIRM ~1.0
	9. FUEL INDICATOR If on ground power. - With full tank - With full tank and external tank	CHECK 106±5% 131±5%
Right Side Panel	1. INDICATOR SYSTEMS If on ground power. - KONTROLL button - High alpha warning: two short bursts; stickshaker - BRAND and BRAND GTS warning lights - LANDSTÄLL caution light - Altitude Warning lamp - Indicated fuel - Data Indicator Panel - Green FK light	CHECK Press and hold Check Illuminate Remains off Illuminates 29±3% 1 and current CK program# Illuminates

LFP = Left Front Panel — CC = Central Console — RFP = Right Front Panel — CTS = Control Stick
LHP = Left Horizontal Panel — LSP = Left Side Panel — LWP = Left Warning Panel — TRS = Throttle & Radar Stick
RWP = Right Warning Panel — RHP = Right Horizontal Panel — RSP = Right Side Panel

BEFORE ENGINE START CHECKLIST

Right Side Panel (cont.)	2. CIRCUIT BREAKERS	ALL IN																																									
	3. WEAPON SELECTOR	AS DESIRED																																									
	4. WEAPON INTERVAL SELECTOR	AS DESIRED																																									
	5. FÄLLSÄTT SWITCH	AS DESIRED																																									
	6. MÅLVAL / PREP SWITCH	AS DESIRED																																									
Right Horizontal Panel	1. RWR and KB COUNTERMEASURES POD - FRÅN – LJUS – LJUS/LJUD switch - KB selector - R – RF – F selector - Streak selector	SET UP As desired As desired As desired As desired																																									
	<table border="1"> <thead> <tr> <th>Program</th> <th>KB selector</th> <th>Chaff/Flare selector</th> <th>Streak Selector</th> <th>Effect</th> </tr> </thead> <tbody> <tr> <td>P1 Rapid</td> <td>1</td> <td>R or RF</td> <td>0</td> <td>Chaff release while KB switch is in INT or KONT. Total release time 1.5 min.</td> </tr> <tr> <td>P2 Medium</td> <td>2</td> <td>R or RF</td> <td>0</td> <td>Chaff release in 2s intervals with 2.5s pause while KB switch is in INT or KONT.</td> </tr> <tr> <td>P3 Slow</td> <td>3</td> <td>R or RF</td> <td>0</td> <td>Chaff release while KB switch is in INT or KONT. Total release time 8 min.</td> </tr> <tr> <td>P4 Slow streak</td> <td>3</td> <td>R or RF</td> <td>0</td> <td>Chaff release when Streak selector is set to 4. Total release time 8 min per pod.</td> </tr> <tr> <td>Automatic</td> <td>A</td> <td>R or RF</td> <td>0</td> <td>Chaff released per program P2 if RWR detects radar lock while KB switch is in INT or KONT.</td> </tr> <tr> <td>Automatic with U22 ECM pod</td> <td>A</td> <td>R or RF</td> <td>0</td> <td>Chaff released per program P1 if RWR detects radar lock while KB switch is set to KONT.</td> </tr> <tr> <td>Quick Release</td> <td>Any</td> <td>As desired</td> <td>Any</td> <td>In R mode: chaff released in accordance with program P2. In RF mode: chaff release per program P2; flares released in 2s intervals. In F mode: flares released in 1s intervals.</td> </tr> </tbody> </table>	Program	KB selector	Chaff/Flare selector	Streak Selector	Effect	P1 Rapid	1	R or RF	0	Chaff release while KB switch is in INT or KONT. Total release time 1.5 min.	P2 Medium	2	R or RF	0	Chaff release in 2s intervals with 2.5s pause while KB switch is in INT or KONT.	P3 Slow	3	R or RF	0	Chaff release while KB switch is in INT or KONT. Total release time 8 min.	P4 Slow streak	3	R or RF	0	Chaff release when Streak selector is set to 4. Total release time 8 min per pod.	Automatic	A	R or RF	0	Chaff released per program P2 if RWR detects radar lock while KB switch is in INT or KONT.	Automatic with U22 ECM pod	A	R or RF	0	Chaff released per program P1 if RWR detects radar lock while KB switch is set to KONT.	Quick Release	Any	As desired	Any	In R mode: chaff released in accordance with program P2. In RF mode: chaff release per program P2; flares released in 2s intervals. In F mode: flares released in 1s intervals.		
	Program	KB selector	Chaff/Flare selector	Streak Selector	Effect																																						
	P1 Rapid	1	R or RF	0	Chaff release while KB switch is in INT or KONT. Total release time 1.5 min.																																						
	P2 Medium	2	R or RF	0	Chaff release in 2s intervals with 2.5s pause while KB switch is in INT or KONT.																																						
	P3 Slow	3	R or RF	0	Chaff release while KB switch is in INT or KONT. Total release time 8 min.																																						
	P4 Slow streak	3	R or RF	0	Chaff release when Streak selector is set to 4. Total release time 8 min per pod.																																						
	Automatic	A	R or RF	0	Chaff released per program P2 if RWR detects radar lock while KB switch is in INT or KONT.																																						
	Automatic with U22 ECM pod	A	R or RF	0	Chaff released per program P1 if RWR detects radar lock while KB switch is set to KONT.																																						
	Quick Release	Any	As desired	Any	In R mode: chaff released in accordance with program P2. In RF mode: chaff release per program P2; flares released in 2s intervals. In F mode: flares released in 1s intervals.																																						
2. U22 and U22/A ECM POD If carried. - Mode selector - Bandwidth selector	SET UP A F																																										
<table border="1"> <thead> <tr> <th>U22 Mode</th> <th>Mode selector</th> <th>Bandwidth selector</th> <th>U22/A Mode</th> <th>Mode selector</th> <th>Bandwidth selector</th> </tr> </thead> <tbody> <tr> <td>Off</td> <td>0</td> <td>No function</td> <td>Off</td> <td>0</td> <td>No function</td> </tr> <tr> <td>Automatic</td> <td>A</td> <td>Any</td> <td>Standby/preheat</td> <td>A</td> <td>F</td> </tr> <tr> <td>Standby/preheat</td> <td>B</td> <td>Any</td> <td>Silent recording</td> <td>A</td> <td>G (low) H J (high) K (G/J cycle)</td> </tr> <tr> <td>N/A</td> <td>D</td> <td>Any</td> <td>Active emission</td> <td>B</td> <td>F G H J K</td> </tr> <tr> <td>N/A</td> <td>E</td> <td>Any</td> <td>Active emission</td> <td>D</td> <td>F G H J K</td> </tr> <tr> <td></td> <td></td> <td></td> <td>Active emission</td> <td>E</td> <td>F G H J K</td> </tr> </tbody> </table>	U22 Mode	Mode selector	Bandwidth selector	U22/A Mode	Mode selector	Bandwidth selector	Off	0	No function	Off	0	No function	Automatic	A	Any	Standby/preheat	A	F	Standby/preheat	B	Any	Silent recording	A	G (low) H J (high) K (G/J cycle)	N/A	D	Any	Active emission	B	F G H J K	N/A	E	Any	Active emission	D	F G H J K				Active emission	E	F G H J K	
U22 Mode	Mode selector	Bandwidth selector	U22/A Mode	Mode selector	Bandwidth selector																																						
Off	0	No function	Off	0	No function																																						
Automatic	A	Any	Standby/preheat	A	F																																						
Standby/preheat	B	Any	Silent recording	A	G (low) H J (high) K (G/J cycle)																																						
N/A	D	Any	Active emission	B	F G H J K																																						
N/A	E	Any	Active emission	D	F G H J K																																						
			Active emission	E	F G H J K																																						
3. EXTERIOR LIGHTING - ANTIKOLL-LJUS switch - LANTERN switch - FORM-LJUS switch - LED-LJUS switch - FORMLJUS \ LEDLJUS knob	SET UP As required As required TILL TILL As required																																										
4. KURSKORR KNOB Consult airport charts for local magnetic declination.	AS REQUIRED																																										
5. VARMLUFTSPOLNING FRONTRUTA KNOB	STÄNGT / FULLY CCW																																										
6. TILS SELECTOR	A																																										
7. RHM SWITCH	TILL / UP																																										
8. OXYGEN LEVER	TILL / UP																																										

END

NAVIGATION DATA INPUT CHECKLIST**NOTE**

Loading and setting up navigation data should if possible be done before engine start while on ground power. If ground power is not available, it must be done immediately after engine start while on generator power.

At minimum, always confirm or input the start base (using reference number or latitude/longitude and runway heading) and current time. If this is not done, the navigation system will not function properly.

1. DATA CARTRIDGE	CONFIRM INSERTED
2. CK WARNING LIGHT	OFF
3. RENSA <i>BUTTON</i>	UNCOVER and PRESS
4. LOAD DATA - Data Selector - IN – UT switch - Input code - Confirm - First display digit	CHECK REF LOLA IN / Left 9099 LS/SKU button Blinking 9 while loading
NOTE Refer to kneeboard for current theatre reference points and navigation data.	
5. STARTING BASE - Data Selector - IN – UT switch - Display	CONFIRM REF LOLA UT / Right 90 + base reference number
6. STARTING BASE If not set or inaccurate - Data Selector - IN – UT switch - Input code - Confirm	INPUT REF LOLA IN / Left 90 + base reference number LS/SKU button
7. STARTING RUNWAY - Data Selector - IN – UT switch - Display	CONFIRM BANA GRÄNS UT / Right Runway heading and TILS
8. STARTING RUNWAY If not set or inaccurate - Data Selector - IN – UT switch - Input code - Confirm	INPUT BANA GRÄNS IN / Left Rwy hdg (4 digits) and TILS (2 digits) LS/SKU
9. CURRENT TIME - Data Selector - IN – UT switch - LS/SKU button - Display	CONFIRM TID UT / Right Press Current time (HHMMSS)
10. CURRENT TIME If not set or inaccurate - Data Selector - IN – UT switch - Input code - Confirm	INPUT TID IN / Left HHMMSS LS/SKU

END

ENGINE START CHECKLIST

NORMAL STEP	NON-FUNCTIONAL STEP
1. TÄNDSYSTEM SWITCH	TILL / LEFT
2. TÄNDSTIFT SWITCH	TILL / UP
3. BRÄNSLEREGLAGE SWITCH	AUT / DOWN
4. LT-KRAN EBK SWITCH	ÖPPEN / DOWN
5. THROTTLE	GROUND IDLE
6. START SWITCH Switch will catch and hold during the starting cycle. - STARTSYST caution light	T / RIGHT For 2 seconds Illuminates
7. STARTING SEQUENCE - MAN BR REG caution light - TÄNDSYST caution light - Generator If not on ground power, a number of systems will receive generator power and turn on, as indicated by the following: - RESERVEFF and ELFEL warning lights - TANK PUMP and CK caution lights - RHM FEL caution light - SPAK autopilot mode - Data Indicator and Destination Indicator - HYDR-TR2 and HYDR-TR1 warning lights	MONITOR Out at ~5% RPM Illuminates at ~10% RPM On at 30% RPM Out as generator turns on Out as generator turns on Out as altimeter calibrates On as generator turns on On as CK activates Out at 50% RPM
8. ENGINE PARAMETERS DURING STARTUP - Engine RPM - EGT - Maximum EGT - P7/P2 pressure ratio - Start Switch	MONITOR Steady rise to idle: 60% Steady rise within 30s <400° ~1.0 Resets to F once engine idle
⚠ CAUTION If parameters are exceeded during start, or if STARTSYS does not illuminate within 5 seconds, set Start Switch to F and let engine spool down.	
9. ENGINE PARAMETERS AT IDLE - Engine RPM - P7/P2 pressure ratio - EGT - Nozzle indicator - OLJETRYCK caution light, if previously illuminated - X-TANK BRÄ caution light, if external fuel is carried	MONITOR 55–65% ~1.0 <350°C Fully Open Out within 60s Out
⚠ CAUTION A maximum of three engine startup attempts is allowed. Each attempt should be separated by at least one minute to allow engine to cool down. If engine has spooled up before startup is aborted, perform a dry start/engine ventilation. While Starter Switch is set to T and until the STARTSYST light goes out, HUVUDVARNING is blocked.	
⚠ WARNING Further startup attempts may not be made if: • Startup failed or was aborted due to excessive EGT. • RPM has increased over 65% without pilot input (danger of runaway engine). • Startup has failed three times.	
END	

BATTERY STARTUP CHECKLIST AFTER ENGINE START**NOTE**

If startup has been performed without being connected to ground power, the following checks and tests that require AC power must now be performed.

1. NÖDTRIM ROLL, TIPP and SIDTRIM SWITCHES**CHECK CENTRED****NOTE**

If the emergency trim switches have been used, and are not centred, the normal control stick trim system has been disengaged and can only be operated if the TRIMSYST circuit breaker (RSP15) is cycled.

2. BACKUP INSTRUMENT ILLUMINATION**CHECK****3. ADI,CENTRAL INDICATOR and BACKUP COURSE INDICATOR****CHECK ALIGNMENT and HEADING**
Stowed

- Error Flags

4. BACKUP ADI**CHECK ALIGNMENT**- Error Flag
- Fast Erect/Cage KnobStowed
Push if Required**5. FUEL INDICATOR****CHECK**- With full tank
- With full tank and external tank106±5%
131±5%**6. INDICATOR SYSTEMS****CHECK**- KONTROLL button (RSP9)
- High alpha warning: two short bursts; stickshaker
- BRAND and BRAND GTS warning lights
- LANDSTÄLL caution light
- Altitude Warning lamp
- Indicated fuel
- Data Indicator Panel
- Green FK lightPress and hold
Check
Illuminate
Remains off
Illuminates
29±3%
1 and current CK program#
Illuminates**7. NAVIGATION DATA****LOAD and SET**

Refer to earlier checklist.

END**DRY START / ENGINE VENTILATION CHECKLIST****NOTE**

Procedure is used to purge a flooded engine after a failed start attempt.

1. TÄNDSTIFT SWITCH (RHP27)**FRÅN / DOWN****2. THROTTLE****OFF, FULLY REAR****3. LT-KRAN SWITCH (LHP24)****FRÅN / DOWN****4. START SWITCH (LHP20)****T / LEFT**
Hold for 2 seconds

Starter system will run without igniting the engine. Wait 40 seconds for the process to complete.

5. START SWITCH**F / RIGHT****END**

AFTER ENGINE START CHECKLIST

1. AVISN MOTOR SWITCH (RSP14) If operating in a cold weather environment.	TILL
2. CONTROL SURFACES	CHECK
3. PITCH TRIM (LHP27) - Without drop tank or with empty drop tank. - With external drop tank.	SET 0 -3 (Nos upp)
4. AIRBRAKES	CHECK
5. BRAKE PRESSURE - Brakes - PARK lever (CC4) - Bromstr. gauge (LHP28)	CHECK Press Disengages 200–270 kPa/cm ²
6. EJECTION SEAT	ARMED
7. HÖJD GAUGES (LFP14 & RFP11)	CHECK Deviation ≤2 hPa
8. HUVUDVARNING and WARNING LIGHTS - X-TANK BRÅ caution light - HUV o STOL caution light	CHECK Remains lit until 70% RPM Remains lit if canopy open
9. AUTOPILOT EMERGENCY DISCONNECT NB: The game currently has no such button, function, or bind. Emulate by toggling SPAK, ATT, and HÖJD lamp buttons on and off.	PRESS
10. SPAK LAMP BUTTON (RFP1)	ON
11. WHEEL CHOCKS NB: The game currently has not implemented wheel chocks for the AJS-37	REMOVED
12. TAXI/LANDING LIGHT (LSP5)	ON / DOWN
13. HUD REFLECTOR GLASS	LOWERED
14. PERMISSION TO TAXI	REQUESTED
END	

TAXIING NOTES

- Full deflection of rudder gives a nose wheel rotation of about 30°. Turning radius can be reduced by using differential braking.
- Fuel consumption on the ground is about 0.3% per minute.

⊘ CAUTION

The engine gives relatively high thrust on idle. Taxiing on slippery, wet, and even certain dry surfaces should be done carefully.

- Thrust reversal may be used to reduce speed during taxiing.
- In confined areas, thrust reversal may be used to reverse the aircraft.

⊘ CAUTION

Check that the area is clear behind the aircraft before reversing.
Do not reverse if the surface consists of a large amount of particles, such as sand or stone. On other surfaces, use as little thrust as possible to minimise the chance of particle ingestion.

⚠ WARNING

When reversing, do not apply brakes until the aircraft has come to a complete halt, as the aircraft may pivot backwards on braking, causing a tailstrike.

BEFORE TAKEOFF CHECKLIST

1. MASTER MODE SELECTOR (LHP19) No more than 2 minutes before throttle-up, to avoid navigation system errors to accumulate on the ground.	NAV
NOTE The radar and Central Indicator (CI) requires a software initialisation period of 180 seconds after the generator has been turned on and 30 seconds after NAV mode has been engaged.	
2. CANOPY - HUV o STOL caution light.	CLOSED and LOCKED Off
3. PERMISSION TO TAKEOFF	REQUESTED
4. AIRCRAFT ALIGNED	WITH RUNWAY
5. IFF TRANSPONDER SWITCH (RSP7)	TILL / UP
6. ADI, BACKUP ADI, CI, KURS, and HÖJD GAUGES	CHECK and SET
NOTE Any discrepancies in heading should be automatically corrected during the takeoff run as the navigation system calculates the initial heading based on airport data and navigation gyros. However, in case of strong crosswinds or a slippery runway, the movement and attitude of the aircraft during takeoff may introduce errors that are not compensated for by the automated system. Under such conditions, a manual course correction will be needed to override the automatic alignment.	
7. MANUAL COURSE CORRECTION - Master Mode Selector - HUD Reflector Glass - Aircraft carefully aligned - Stick Reference button - HUD Reflector Glass	IF REQUIRED NAV Inflight mode / Raised With runway Press Takeoff/Landing mode / Lowered
NOTE Ensure that the aircraft is carefully aligned in the direction of the runway before engaging the course correction, as all inertial navigation from wheels-up will be based on this initial alignment. If the runway or weather conditions are such that a good alignment is still unlikely, add in an early navigation update just after take-off in the mission planning. To reset an existing initial course setting, the Master Mode Selector needs to be cycled: NAV – BER – NAV. This also applies if the pilot desires an automatic setting of the initial course.	
8. SPAK AUTOPILOT LAMP BUTTON (LFP1)	ON
9. HUVUDVARNING and WARNING LIGHTS - X-TANK BRÅ light	CHECK Remains lit until 70% RPM
10. HUD SYMBOLOGY	CHECK
11. TAXI/LANDING LIGHT SWITCH (LSP5)	ON / DOWN
12. ANTIKOLL. LJUS SWITCH (RHP17)	FRÅN / DOWN
END	

NORMAL STEP

FULL PROCEDURE STEP

CONDITIONAL STEP

NON-FUNCTIONAL STEP

FULL PROCEDURE SUB-STEP

CONDITIONAL SUB-STEP

NON-FUNCTIONAL SUB-STEP

HUD TAKEOFF CHECKLIST

1. BRAKES	ON
2. THROTTLE	100% DRY POWER
3. EGT	<590°C + AMBIENT
4. BRAKES	RELEASE
NOTE To achieve shortest possible take-off distance on a short runway, Zone 3 afterburner should be used.	
5. AFTERBURNER - Zone Indicator - Exhaust Nozzle Indicator - P7/P2 Pressure ratio	SELECT AS NEEDED As desired Zone achieved Zone 2: >1.9 for <+15°C <1.8 for >+15°C Zone 3: maximum
6. HUD AIRSPEED INDICATOR and TIME LINE	CHECK
7. WHEN HUD TIME LINE REACHES MARKERS - If using dry power, adjust flight path marker - If using afterburner, adjust flight path marker	ROTATE To horizon To outer pillars (~3° above horizon)
8. AIRSPEED	INCREASING While climbing
⊘ CAUTION With Zone 3 full afterburner, the aircraft accelerates very quickly, and may reach the maximum allowed airspeed with extended landing gear before the gears have fully retracted. Monitor the airspeed during a fast take-off and throttle back to select a lower afterburner zone if the retraction mechanism is still operating.	
9. LANDING GEAR	RETRACT When airborne
⊘ CAUTION There is a risk of decrease in lift as the flaps retract along with the landing gear. Be prepared to compensate with additional throttle or stick input.	
10. CLIMB	TO SELECTED ALTITUDE
The HUD should switch modes automatically from takeoff symbology to normal navigation symbology as altitude increases.	
11. HUD REFLECTOR GLASS	INFLIGHT / RAISED
END	

NORMAL STEP

FULL PROCEDURE STEP

CONDITIONAL STEP

NON-FUNCTIONAL STEP

FULL PROCEDURE SUB-STEP

CONDITIONAL SUB-STEP

NON-FUNCTIONAL SUB-STEP

ADI TAKEOFF CHECKLIST

1. BRAKES	ON
2. THROTTLE	100% DRY POWER
3. EGT	<590°C + AMBIENT
4. BRAKES	RELEASE
NOTE To achieve shortest possible take-off distance on a short runway, Zone 3 afterburner should be used.	
5. AFTERBURNER - Zone Indicator - Exhaust Nozzle Indicator - P7/P2 Pressure ratio	SELECT AS NEEDED As desired Zone achieved Zone 2: >1.9 for <+15°C <1.8 for >+15°C Zone 3: maximum
6. AT SPEED - If using dry power - If using afterburner	ROTATE To 10° climb at 280 km/h To 13° climb at 250 km/h
7. AIRSPEED	INCREASING While climbing
⊘ CAUTION With Zone 3 full afterburner, the aircraft accelerates very quickly, and may reach the maximum allowed airspeed with extended landing gear before the gears have fully retracted. Monitor the airspeed during a fast take-off and throttle back after lift-off to select a lower afterburner zone if the retraction mechanism is still operating.	
8. LANDING GEAR	RETRACT When airborne
⊘ CAUTION There is a risk of decrease in lift as the flaps retract along with the landing gear. Be prepared to compensate with additional throttle or stick input.	
9. CLIMB	TO SELECTED ALTITUDE
The HUD should switch modes automatically from takeoff symbology to normal navigation symbology as altitude increases.	
10. HUD REFLECTOR GLASS	INFLIGHT / RAISED
END	

NORMAL STEP

FULL PROCEDURE STEP

CONDITIONAL STEP

NON-FUNCTIONAL STEP

FULL PROCEDURE SUB-STEP

CONDITIONAL SUB-STEP

NON-FUNCTIONAL SUB-STEP

VISUAL APPROACH CHECKLIST

1. AIRSPEED GAUGE (LFP6)	550km/h
2. BACKUP ATTITUDE INDICATOR (RFP9)	CHECK Fast erect if needed
3. LANDING GEAR HANDLE (LHP2) NOSSTÄLL, V-STÄLL, H-STÄLL <i>lights</i> (LWP1)	DOWN At 15km from runway Green
4. LANDING LIGHTS (LSP5)	ON
5. REV HANDLE (LFP10) REV <i>light</i> (LFP9)	AS DESIRED Per setting
6. REGLAGEBROMS HANDLE (LHP1) AFK <i>light</i> (LFP4)	AS DESIRED Per setting
7. SPAK LIGHT BUTTON (LFP1)	ON
8. BRAKE PRESSURE BROMSTR. <i>gauge</i> (LHP28)	CHECK 200–270 kp/cm ²
9. HUD REFLECTOR GLASS (CC1)	LANDING / LOWERED
10. MASTER MODE SELECTOR (LHP19)	LANDNING P/O
11. GLIDE SLOPE - Airspeed - Descent angle	ESTABLISH Maintain 12° α Maintain 3°
NOTE Primarily use throttle to set the descent angle, and balance with pitch input to maintain the AoA. If the REGLAGEBROMS autothrottle is engaged, AoA will be maintained automatically — instead, use pitch input to maintain proper glideslope. The HUD line in LANDNING P/O mode represents a 2.86° descent angle.	
Place the descent line on the runway threshold and centre the sight dot on the centre- line, steer the flight path indicator onto the line. Maintain attitude. Strive for a touch-down at about 100-200 metres in on the runway.	
At 15 metres altitude above the runway (30 if not using the radar altimeter), the HUD will change to the descent rate mode. The previous 2.86° line represents the maximum vertical velocity (2.96 m/s).	
12. TOUCH-DOWN	CONFIRMED
END	

NORMAL STEP

FULL PROCEDURE STEP

CONDITIONAL STEP

NON-FUNCTIONAL STEP

FULL PROCEDURE SUB-STEP

CONDITIONAL SUB-STEP

NON-FUNCTIONAL SUB-STEP

TILS APPROACH CHECKLIST

1. AIRSPEED GAUGE (LFP6)	550km/h
2. LANDING BASE L MÅL <i>button</i> (RHP9)	SET Press
3. HÖJD GAUGE (LFP14)	SET FIELD QFE
4. RUNWAY HEADING - CK37 data selector (RHP5) - LS/SKU <i>button</i> (RHP9)	SET BANA Press to cycle
5. TILS STATION SELECTOR (RHP10)	SET
6. TILS SWITCH (RHP11)	SET
7. MASTER MODE SELECTOR (LHP19)	LANDN NAV At 30km from runway
8. BACKUP ATTITUDE INDICATOR (RHP9)	CHECK Fast erect if needed
9. TILS LIGHT (RWP1)	SOLID
10. LANDING GEAR HANDLE (LHP2) NOSSTÄLL, V-STÄLL, H-STÄLL <i>lights</i> (LWP1)	DOWN At 15km from runway Green
11. LANDING LIGHTS (LHP5)	ON
12. REV HANDLE (LFP10) REV <i>light</i> (LFP9)	AS DESIRED Per setting
13. REGLAGEBROMS HANDLE (LHP1) AFK <i>light</i> (LFP4)	AS DESIRED Per setting
14. SPAK LIGHT BUTTON (LFP1)	ON
15. BRAKE PRESSURE BROMSTR. <i>gauge</i> (LHP28)	CHECK 200–270 kp/cm ²
16. HUD REFLECTOR GLASS (CC1)	LANDING / LOWERED
17. HUD ALTITUDE, HEADING INDICATIONS	FOLLOW
18. GLIDE SLOPE - Airspeed - Descent angle - HUD and ADI pitch and heading incations	INTERCEPT At 10km from runway Maintain 12° α Follow to maintain 3° glide slope
NOTE	
Primarily use throttle to set the descent angle, and balance with pitch input to maintain the AoA. If the REGLAGEBROMS autothrottle is engaged, AoA will be maintained automatically — instead, use pitch input to maintain proper glideslope.	
At 15 metres altitude above the runway (30 if not using the radar altimeter), the HUD will change to the descent rate mode. The previous 2.86° line represents the maximum vertical velocity (2.96 m/s).	
19. TOUCH-DOWN	CONFIRMED
END	

LANDING CHECKLIST

Aerobraking

NOTE: AEROBRAKING

Using the wing span and high AoA to create drag and slow the aircraft down reduces wear and tear on brakes and engines but creates a longer landing roll and thus is only suitable for longer paved runways.

1. ESTABLISH AOA	16°
2. NOSE DOWN	AT 160km/h
3. RUDDER PEDALS	TO STEER
4. TOE BRAKES	APPLY EVENLY

Thrust reversal braking

NOTE: THRUST REVERSAL

If preselected, the thrust reverser engages as the nose wheel strut compresses and reduces wear on brakes while allowing very short landing rolls, but at the cost of risking compressor stalls as exhaust gasses are fed backwards into the engine.

1. NOSE DOWN	IMMEDIATELY
2. RUDDER PEDALS	TO STEER
3. REV HANDLE When REV AVDR TRANSSONIC <i>light</i> comes on.	IN To avoid gas ingestion.
4. TOE BRAKES	APPLY EVENLY
5. MASTER MODE <i>SELECTOR</i> (LHP19)	BER
6. TAXI / LANDING <i>LIGHTS</i> (LSP5)	AS DESIRED

Refer to taxiing notes for vacuating the runway.

END

SHUTDOWN CHECKLIST

1. EJECTION SEAT	SAFE
2. REGLAGEBROMS <i>LEVER</i> (LHP1)	OFF / UP
3. GENERATOR <i>SWITCH</i> (LHP22)	FRÅN / RIGHT
4. AVIONICS and OTHER SYSTEMS Radar, RWR, IFF, External illumination etc.	OFF
5. OXYGEN <i>LEVER</i> (RHP4)	OFF / DOWN
6. LT-KRAN <i>SWITCH</i> (LHP24)	FRÅN / DOWN
7. CANOPY (LSP3)	OPEN
8. HUVUDSTRÖM <i>SWITCH</i> (LHP23)	FRÅN / DOWN

END

NAVIGATION DATA UPDATE CHECKLIST

Automated fixes

NOTE: INITIAL FIX

When taking off, an initial fix is made automatically when weight is removed from the nose wheel. Fix is set to the runway centre point of the selected starting base. Landing outside of any LANDNING master mode will not update the current starting base and subsequent take-offs may introduce errors if the starting base is not set manually.

NOTE: TILS FIX

When using TILS, position errors are removed during phase 3 of the approach through automatic calibration against the TILS signal.

NOTE: TERNAV

TERNAV fixes are applied automatically and continuously if the system is operating and the radar altimeter is used. TERNAV status can be monitored in AKT POS / UT mode on the CK37: digit 5 shows current TERNAV operation mode; digit 6 shows accumulated position error in km.
Mode 0: TERNAV inoperable. Mode 1: Stand-by. Mode 2: Rough search. Mode 3: Fine search.
Mode 4: Operating, not used. Mode 5: Operating and sending fixes.

B and M navigation points

⚠ CAUTION

The same procedures are used for updates of both target points (MÅLPUNKT) and waypoints (BRYTPUNKT). Updating a waypoint position adjusts all subsequent waypoints according to their relative positions, and the accrued navigation error between two fixed waypoints will rarely be large enough to cause the flight plan to be dangerously off target. However, when updating target points, the target may have moved significant distances from their pre-planned assumed positions and the MÅLPUNKT data is thus disassociated from the BRYTPUNKT data to allow for these differences

It is critically important to ensure that the right type of update is done to the right type of navigation point. Accidentally moving a waypoint as if it were a target point will offset the entire flight plan. Before making a target update for the purpose of weapons delivery, ensure that the destination indicator shows an M number; before making a waypoint update, ensure the destination indicator shows a B number.

Visual fix

NOTE: VISUAL FIX

Visual fixes are done by overflying a known landmark corresponding to a waypoint location.

1. RADAR MODE SWITCH (TRS1)	A0 (OFF)
2. DESTINATION INDICATOR (RFP8) - B, Bx, or M type - Navpoint number	CHECK Confirm as appropriate Confirm
3. FIX TRIGGER (TRS2) - Destination indicator	FIRST DETENT / T1 Steady E
4. LANDMARK / TARGET	FLY OVER
5. FIX TRIGGER (TRS2) - Destination indicator	SECOND DETENT / TV Steps to next nav point

Radar fix

NOTE: RADAR FIX

Visual fixes are done by identifying and designating a landmark on the radar scope.

1. RADAR MODE SWITCH (TRS1)	A1
2. MASTER MODE (LHP19)	NOT IN SPA
3. DESTINATION INDICATOR (RFP8) - B, Bx, or M type - Navpoint number	CHECK Confirm as appropriate Confirm
4. FIX TRIGGER (TRS2) Destination indicator	FIRST DETENT / T1 Blinking E
5. RADAR CROSS and CIRCLE MARKER (CC3) If done in memory radar mode, only the circle marker is manipulated.	SLEW TO NEW POSITION
6. FIX TRIGGER (TRS2) Radar circle marker	SECOND DETENT / TV Updates to new position

END

CK37 EMPLOYMENT MODES and DATA

1. CK37 DATA SELECTOR	AS REQUIRED
2. IN – UT SWITCH For data input For data output	AS REQUIRED In / Left Ut / Right

Output modes	Button	Display	Specifics
	AKT POS		DD MM X Y
		DD MM X Y	TERNAV operating status : 0 – inoperable; 1 – stand-by; 2 – rough search; 3 – fine search; 4 – operating, not used; 5 – operating, providing fixes
		DD MM X Y	Estimated navigational drift in km .
REF LOLA	LS/SKU	DD MM SS	Lo/La or Ref# of current destination.
	L/MÁL	or	Lo/La or Ref# of LS starting base.
	B1–B9	9XXX 00	Lo/La or Ref# of L1/L2 landing base.
	Bx1–Bx9		Lo/La or Ref# of Bx mark point.
BANA GRÄNS		XXXXXX	Output depends on current destination
	L/MÁL	DDDD XX	Runway heading in tens of degrees .
		DDDD XX	TILS channel .
	B1–B9	DDD DDD	First boundary line heading in degrees .
		DDD DDD	Second boundary line heading in degrees .
VIND RUTA MÁL	LS/SKU	DDD XX 0	Doppler wind direction in degrees .
		DDD XX 0	Doppler wind speed in km/h .
		DDD XX □	Forecast wind direction in degrees .
		DDD XX □	Forecast wind speed in km/h .
	1–9	DD MM SS	Alternating Lo/La of SPA/MÁL target.
TID		X H MM SS	Deviation of ETA with respect to ToT: X=□ – ahead; X=9 – behind schedule.
		7 H MM SS	Relative ETA if no ToT was set.
	LS/SKU	HH MM SS	Current time.
	B1–B9		ToT for selected waypoint.
		X YY 000	Ingress speed in Mach X.YY .
	Bx	HH MM SS	ToT for RB15 at Bx8.
	1–9		Timestamp for SPA/MÁL target.
TAKT		X ₁ X ₂ X ₃ X ₄ X ₅ X ₆ X ₇ X ₈ X ₉	Weapon status of pylon <i>i</i> ; (X ₁ = 0 – empty; X ₁ = 1 – available; X ₁ = - – inoperable).
	B1–B9	9 00000	Depressed WP button is a target navpoint.

Input modes	Input	Confirm	Function	Parameters
	REF LOLA	9099	LS/SKU	Load data
90 XX			L1	Reference number XX of landing base L1.
99 XX		L/MÁL	L2	Reference number XX of landing base L2.
			Lo/La L1	Longitude/Latitude of landing base L1.
DD MM SS		B1–B9	Lo/La WP	Longitude/Latitude of Waypoint B1–B9.
		Bx + Y	Lo/La Bx	Longitude/Latitude of Markpoint BxY.
BANA GRÄNS	DDDD YY	LS/SKU	Takeoff RWY	Heading of takeoff runway in tens of degrees .
	DDDD YY			TILS channel of takeoff runway.
	DDDD YY	L/MÁL	Landing RWY	Heading of landing runway in tens of degrees .
	DDDD YY			TILS channel of landing runway.
DDD DDD	B1–B9	Boundary lines	Headings in degrees of first and secondary boundary line of waypoint B1–B9	
VIND RUTA MÁL	DDD XX	LS/SKU	Forecast wind	Heading in degrees of forecast wind.
	DDD XX			Speed in km/h of forecast wind.
	DD MM SS	L/MÁL + X	Lo/La M1–M9	Longitude/Latitude of recon target MX .
		B1–B9	Lo/La R1–R9	Longitude/Latitude of recon RUTA points R1–R9.
TID		LS/SKU	Current time	Time in 24-hour format.
	HH MM SS	B1–B9	WP ToT	Time on target for selected waypoint in 24-hour format.
		Bx	RB15 ToT	Time on target for RB15 to arrive in target area in 24-hour format.
	X YY	B1–B9	Ingress speed	Ingress speed in Mach X.YY at selected waypoint.
TAKT	DDD XX Y	B1–B9	Pop-up point	Desired attack heading in degrees and popup distance in XX.Y km
	9		Target point	Convert between waypoint (B) ↔ target point (M).

END

GENERAL WEAPON SELECTION CHECKLIST

	Weapon selector	Master mode	Specifics	Release mode	Other settings
AKAN	ATTACK	ANF		AG mode	
	AKAN JAKT		AA mode		
ARAK	ATTACK	ANF	SERIE	Normal range	
			IMP	Long range	
Bombs	PLAN	ANF		Level release	Weapon Interval selector is used to designate spread between bombs. Radar mode A0 for all release modes except RR.
		NAV	Low-drag	Direct release	
		NAV	High-drag	CCIP release	
	DYK	ANF		Precision release	
		NAV		Quick release	
	RR	ANF		Radar release	
NAV			NAV/toss release		
LysB	ATTACK	ANF	VÄ	Left-offset	TAKT mode address 23 is used to specify offset distance.
			RAKT	On-target	
			HÖ	Right-offset	
RB 04E	ATTACK	ANF	GRUPP	Preplanned release	Group targeting available for targets offset on the depth axis.
			ENKEL	Quick release	
RB 05A	MARK	ANF		Impact detonation	
	SJO		Delayed detonation		
	LUFT		Proximity detonation		
RB 15F	ATTACK	ANF	VALB	Target selection per TAKT	TAKT mode addresses 81–88 are used for programming the VALB target selection.
			STD	Standard mode	
				Quick release	
RB 24 / 74	ANF	IR-RB		AA mode	Weapon Interval selector sets wingspan.
RB 75	RB 75	NAV	A0	Black-on-white	Fix trigger is used to uncage seeker and command a lock.
			A1	White-on-black	
			A2	Automatic	
BK 90	ATTACK	ANF		Preplanned release	TAKT mode addresses 91–92 are used to program pattern.
		NAV or SPA		Quick release	

⚠ CAUTION

Many weapons use the same settings — notably the ATTACK Weapon Selection — and thus cannot be selected individually. Weapons using conflicting/overlapping selection settings should not be carried at the same time as this will leave either or all weapons disabled as indicated by the TAKT mode stores display.

1. WEAPON SELECTOR (RSP3)	AS REQUIRED
2. MASTER MODE SELECTOR (LHP19)	AS REQUIRED
3. HÖJD GAUGE (LFP14)	SET TARGET QFE
4. WEAPON INTERVAL SELECTOR (RSP4) If carrying bombs, LysB, or RB 24 / 74	AS REQUIRED
5. FÄLLSÄTT SWITCH (RSP5) If carrying ARAK, RB 04, RB 15 or BK 90.	AS DESIRED
6. MÅLVAL / PREP SWITCH (RSP6) If carrying RB 04, RB 15 or BK 90.	AS DESIRED
7. RADAR MODE SWITCH (TRS1) If using RB-04, RB-15, RB-24 / 74, BK 90, or toss release.	AS REQUIRED
8. WEAPON DELIVERY SETTINGS and DATA - Data Selector - IN — UT switch - Data/code input - Confirm input	SET TAKT IN / Left As desired (<i>see next page</i>) LS/SKU

GENERAL WEAPON SELECTION CHECKLIST

9. SIGHT and RADAR FLAGS

SET

Affects	Address	Data mask/code	Setting
AKAN, ARAK, Bombs, and RB 75	21	211	Fixed sight
		21 (no data)	Moving sight (default)
AKAN, ARAK, Bombs	22	221	Disable target motion measurement (default).
		220	Enable motion measurement
LysB	23	23N	Offset distance in km: 1, 2 (default), 3.
Radar modes	25	251	Radar lock before trigger unsafe
		252	Radar lock after trigger unsafe
		253	Radar lock disabled
		250	Radar lock before trigger unsafe (default)

10. RB 15 SETTINGS and DATA

If carried.

SET

Address	Default	Data mask/code	Setting
80	800000	800000	Reset address 81–86 to STD mode
		800001	Confined area; multiple target N (nearest); medium area search
		800002	Unconfined area; multiple target A (all); medium area search
		800003	Convoy targeting; group target; large area search
81	810111	800004	Bearing attack; bearing search mode
		81Nxxx	Single target: 0=yes (default), 1=no
		81xNxx	Multiple target N (one of three targets nearest to Bx8): 0=yes, 1=no (default)
		81xxNx	Multiple target A (random selection between all targets): 0=yes, 1=no (default)
82	820000	81xxxN	Group target: 0=yes, 1=no (default)
		82Nxxx	Analysis during search: 0=yes (default), 1=no — Not implemented.
		82xNxx	Analysis mode: 0=yes (default), 1=no — Not implemented.
		82xxNx	Delayed acquisition: 0=yes (default), 1=no — Not implemented.
83	830000	82xxxN	0 = active + passive lock (default), 1=active lock — Not implemented.
		83Nx00	Altitude after Bx6: 0=sea skimming (default); 1=30m
		83xN00	0 = area search (default); 1 = bearing search
		83xxNN	Empty (default =00)
84	841110	84Nxxx	Precise search area: 0=yes, 1=no (default)
		84xNxx	Small search area: 0=yes, 1=no (default)
		84xxNx	Medium search area: 0=yes, 1=no (default)
		84xxxN	Large search area: 0=yes (default), 1=no
85	851100	85Nxxx	Boundary line left: 0=yes, 1=no (default)
		85xNxx	Boundary line right: 0=yes, 1=no (default)
		85xxNN	Distance, 01–15 km
86	861000	86Nxx0	0 = target approach 10m, 1 = sea skimming (default)
		86xNx0	0 = detonate on impact (default), 1 = delayed — Not implemented.
		86xxN0	0 = arming 2 out of 3 (default), 1 = arming 1 out of 3 — Not implemented.
		86xxxN	Empty (default =0)
87	—	87NNN	Wind direction, degrees (by default sourced from aircraft)
88	—	88NN	Wind strength, km/h (by default sourced from aircraft)

11. BK 90 SETTINGS and DATA

If carried.

SET

Address	Default	Data mask/code	Setting
91	91060	NNN	Weapon altitude, m (default =60)
92	920000	1000	Long area of effect in SERIE release
		2000	Wide area of effect in SERIE release
		3000	Compact / overlapping area of effect in SERIE release
		0000	Reset to compact / overlapping area

END

AKAN 30/55 GUNPOD EMPLOYMENT CHECKLIST

Air-to-ground mode	1. WEAPON SELECTOR Data selector and switch to TAKT / UT		ATTACK Check digits 2 and 5 show "1"
	NOTE If TAKT mode do not show stations 2 and 6 (digits 2 and 5) as operational, the aircraft is carrying conflicting mixed stores on stations 3 and 5. In such a configuration, the AKAN 30/55 cannot be selected or used, and the loadout must be altered.		
	2. MASTER MODE SELECTOR		ANF
	NOTE The weapon can also be used in master mode NAV. The sight appears when the trigger in set to UNSAFE. Target motion measurement and radar ranging is not used.		
	3. HÖJD GAUGE		SET TARGET QFE
	4. TRIGGER		UNSAFE When reticule is on target
5. TRIGGER		PRESS and HOLD When in range	
NOTE If the angle between the sight line and the horizon is less than 5° the distance line does not appear and the triangulation or radar ranging is not used. A fixed distance of 1400m is used which will have to be estimated visually.			
<div style="text-align: center;"> ⚠ WARNING If the flashing 2° poles appear, the attack should be aborted immediately and evasion with maximum G should be done as the safety distance will not be met. </div>			
6. STICK		PULL TO EVADE Pull up at 5G.	
Air-to-air mode	1. WEAPON SELECTOR Data selector and switch to TAKT / UT		AKAN JAKT Check digits 2 and 5 show "1"
	NOTE If TAKT mode do not show stations 2 and 6 (digits 2 and 5) as operational, the aircraft is carrying conflicting mixed stores on stations 3 and 5. In such a configuration, the AKAN 30/55 cannot be selected or used, and the loadout must be altered.		
	2. MASTER MODE SELECTOR		ANF
	NOTE The AKAN 30/55 can be used in a fixed wingspan mode or a radar-guided calculated ballistic mode. In winspan mode, the HUD marker represents the target wingspan at 500m. In radar mode, the sight dot is continually adjusted for the range of the target.		
	3. WEAPON INTERVAL SELECTOR		SET TARGET WINGSPAN
	4. RADAR MODE SWITCH		A1 or A2
	5. SIGHT DOT		ON TARGET
	6. RADAR FIX TRIGGER		FIRST DETENT / T1 To lock
7. TRIGGER When time/distance line reaches the event markers or the wingspan markers envelop the target. In wingspan mode, the pilot will need to manually lead a manoeuvring target.		UNSAFE and FIRE	
After Attack	1. TRIGGER		SAFE
	2. MASTER MODE SELECTOR		NAV
END			

ARAK M/70B ROCKET POD EMPLOYMENT CHECKLIST

1. WEAPON SELECTOR Data <i>selector</i> and <i>switch</i> to TAKT / UT	ATTACK Check station digits show "1"
NOTE If TAKT mode do not show the appropriate stations as operational, the aircraft is carrying conflicting mixed stores on other stations. In such a configuration, the ARAK M/70B cannot be selected or used, and the loadout must be altered.	
2. MASTER MODE SELECTOR	ANF
NOTE The weapon can also be used in master mode NAV. The sight appears when the trigger in set to UNSAFE. Target motion measurement and radar ranging is not used.	
NOTE The ARAK M/70B can be launched at normal or long ranges by selecting either FÄLLSÄTT SERIE (normal) or FÄLLSÄTT IMP (long range). In long-range mode, target motion prediction and radar rangings need to be disabled by inputting TAKT codes 221 and 253. Long-range mode is less precise but offers some stand-off distance.	
3. FÄLLSÄTT SWITCH - For normal range firing - For long range firing	AS DESIRED NORM / Up LÅ / Down
4. HÖJD GAUGE	SET TARGET QFE
5. TRIGGER	UNSAFE When reticule is stable on target
6. TRIGGER - If using normal range firing mode - If using long range firing mode	PRESS and HOLD When in range When wings are displayed
NOTE If the angle between the sight line and the horizon is less than 5° the distance line does not appear and the triangulation or radar ranging is not used. A fixed distance of 1400m is used which will have to be estimated visually.	
⚠ WARNING If the flashing 2° poles appear, the attack should be aborted immediately and evasion with maximum G should be done as the safety distance will not be met.	
7. STICK	PULL TO EVADE Pull up at 5G.
8. TRIGGER	SAFE
9. MASTER MODE SELECTOR	NAV
END	

BK-90 "MJÖLNER" CBU EMPLOYMENT CHECKLIST

Weapon Selection	Release altitude: 50–500m / 165–1650' AGL Flight altitude: 30–500m AGL Release speed: Mach 0.6–0.9 Flight range: <7km / 3.8 nm Warhead: 72× HE (MJ1) or 24× AP (MJ2) Targeting area: ±2km / 1.1 nm	
	1. WEAPON SELECTOR Data selector and switch to TAKT / UT	ATTACK Check station digits show "1"
	NOTE If TAKT mode do not show the appropriate stations as operational, the aircraft is carrying conflicting mixed stores on other stations. In such a configuration, the ARAK M/70B cannot be selected or used, and the loadout must be altered.	
	2. WEAPON DELIVERY SETTINGS - TAKT address 91 - TAKT address 92	SET Flight altitude in VALB release Target area in SERIE release.
3. FÄLLSÄTT SWITCH - For single release - For pair release	AS DESIRED IMP / Down SERIE / Up	
4. PREP SWITCH - For standard flight altitude (60m) - For selectable flight altitude	AS DESIRED STD / Down VALB / Up	
Target Selection	1. TARGET WAYPOINT	SELECTED
	2. HÖJD GAUGE	SET TARGET QFE (=QNH)
	3. MASTER MODE SELECTOR	ANF
	NOTE The BK 90 can be fired directly from NAV mode and will attempt to fly towards and release at the current target point. However, no ranging, drift, or release information will be available on the HUD.	
4. TARGET POSITION - Radar mode - Radar trigger - Slew CI crosshair - Radar trigger - HUD steering information - Radar mode	ADJUST IF NEEDED A1 First detent / T1 On target Second detent / TV Check updated A0 / Off	
⚠ CAUTION If the selected navpoint is not a target waypoint (indicated by M for "Målpunkt" on the destination indicator), a position update will affect the actual waypoint and as such alter all subsequent navigation positions relative to this updated position. If adjustments are needed: Data Selector to TAKT, input 9, press the corresponding waypoint button to convert the waypoint to a target point.		
Weapon Release	1. HUD STEERING CUES	FOLLOW
	2. SLAV SI SWITCH Once at launch altitude	T / RIGHT 50–500m AGL
	3. TARGET IN RANGE - HUD distance line	CHECK Inside brackets
	4. TRIGGER	UNSAFE
	5. TRIGGER - In SERIE release, weapons will be released with 2s intervals	PRESS and HOLD Until FÄLLD LAST illuminates
	6. TRIGGER	SAFE
END		

NORMAL STEP

FULL PROCEDURE STEP

CONDITIONAL STEP

NON-FUNCTIONAL STEP

FULL PROCEDURE SUB-STEP

CONDITIONAL SUB-STEP

NON-FUNCTIONAL SUB-STEP

RB-04/E ASM EMPLOYMENT CHECKLIST

Weapon Selection	Release altitude: 50–425m / 165–1400' ASL Release speed: Mach 0.7–0.9 Warhead: 200kg HE	Flight altitude: 10m / 30' ASL Flight range: 32km / 17 nm Targeting range: 8km / 4.3 nm
	1. WEAPON SELECTOR Data selector and switch to TAKT / UT	ATTACK Check digits 2 and 5 show “1”
	NOTE If TAKT mode do not show stations 2 and 6 (digits 2 and 5) as operational, the aircraft is carrying conflicting mixed stores on stations 3 and 5. In such a configuration, the Rb-04 cannot be selected or used, and the loadout must be altered.	
	2. FÄLLSÄTT SWITCH - For single missile - For both missiles	AS DESIRED IMP / Down SERIE / Up
3. MÅLVAL SWITCH - For single target - For multiple targets	AS DESIRED ENKEL / Down GRUPP / Up	
Target Selection	1. TARGET WAYPOINT	SELECTED
	2. HÖJD GAUGE	SET TARGET QFE (=QNH)
	3. MASTER MODE SELECTOR	ANF
	NOTE The Rb-04/E can be fired directly from NAV mode and will fly straight ahead and engage detected targets of opportunity as programmed. However, no ranging, drift, or release information will be available on the HUD.	
4. TARGET POSITION - Radar trigger - Slew CI crosshair - Radar trigger - HUD steering information	ADJUST IF NEEDED First detent / T1 On target Second detent / TV Check updated	
⚠ CAUTION If the selected navpoint is not a target waypoint (indicated by M for “Målpunkt” on the destination indicator), a position update will affect the actual waypoint and as such alter all subsequent navigation positions relative to this updated position. If adjustments are needed: Data Selector to TAKT, input 9, press the corresponding waypoint button to convert the waypoint to a target point.		
Weapon Release	1. HUD STEERING CUES	FOLLOW
	2. SLAV SI SWITCH Once at launch altitude	T / RIGHT 50–425m ASL
	3. TARGET IN RANGE - HUD distance line - CI target radar echo	CHECK Inside brackets Between crosshairs
	4. TRIGGER	UNSAFE
	5. TRIGGER	PRESS and HOLD Until FÄLLD LAST illuminates
	NOTE The release will unbalance the aircraft, requiring forceful roll trim change. In a SERIE release, maintain lever flight through stick adjustment alone since the aircraft will be rebalanced as the second weapon is released.	
6. TRIGGER	SAFE	
END		

NORMAL STEP

FULL PROCEDURE STEP

CONDITIONAL STEP

NON-FUNCTIONAL STEP

FULL PROCEDURE SUB-STEP

CONDITIONAL SUB-STEP

NON-FUNCTIONAL SUB-STEP

RB-05A RCMRM EMPLOYMENT CHECKLIST

Weapon preparation	1. WEAPON <i>SELECTOR</i> Data <i>selector</i> and <i>switch</i> to TAKT / UT	MARK or SJÖ Check digits 3 and 4 show "1"
	NOTE If TAKT mode do not show stations 3 and 5 (digits 3 and 4) as operational, the aircraft is carrying conflicting mixed stores on stations 2 and 6. In such a configuration, the RB-05A cannot be selected or used, and the loadout must be altered.	
	NOTE In MARK mode, the weapon fuse is set to immediate detonation on contact with the target. In SJÖ mode, the fuse is set to delayed detonation. In LUFT mode, the weapon fuse is set to proximity detonation.	
	2. MASTER MODE <i>SELECTOR</i>	ANF
NOTE The weapon can also be used in master mode NAV, but will have to be aimed without any ranging information.		
Air-to-ground	1. FLY TOWARDS TARGET	LEVEL or SLIGHT DIVE
	2. HÖJD and / or ATT AUTOPILOT MODES	AS DESIRED
	3. RANGE TO TARGET	<10km
NOTE The RB 05A can be used in a fixed wingspan mode or a radar-ranging mode. In wingspan mode, the HUD marker represents the target wingspan at 500m. In radar mode, the sight dot is continually adjusted for the range of the target.		
Air-to-air	1. WEAPON INTERVAL <i>SELECTOR</i>	SET TARGET WINGSPAN
	2. RADAR MODE <i>SWITCH</i>	A1 or A2
	3. SIGHT DOT	ON TARGET
	4. RADAR FIX TRIGGER	FIRST DETENT / T1 To lock
	5. FLY TOWARDS TARGET	LEVEL
	6. HÖJD and / or ATT AUTOPILOT MODES	AS DESIRED
	7. RANGE TO TARGET - In wingspan mode - In radar mode	<2800m Wingspan envelops target Distance line reaches markers
Weapon employment	1. TRIGGER	UNSAFE and FIRE
	⊘ CAUTION The batteries in the RB 05A only last for 40 seconds and are activated on trigger unsafe. Do not activate the missile prematurely, or it may fail to operate long enough to fire or to reach its target. If the trigger is set back to safe, the missile is disabled and the next missile available is selected.	
	2. RB-05 CONTROL STICK	STEER ONTO TARGET
	3. TRIGGER	SAFE After impact
	4. MASTER MODE <i>SELECTOR</i>	NAV
END		

RB-15F ASM EMPLOYMENT CHECKLIST

Weapon Selection

Release altitude:	50–2000m / 165–6500' ASL	Flight altitude:	Selectable up to 30m ASL or 80m AGL
Release speed:	Mach 0.9	Flight range:	70km / 37 nm
Warhead:	200kg HE	Targeting range:	24km / 13 nm

1. WEAPON SELECTOR

Data selector and switch to TAKT / UT

ATTACK

Check digits 2 and 5 show “1”

NOTE

If TAKT mode do not show stations 2 and 6 (digits 2 and 5) as operational, the aircraft is carrying conflicting mixed stores on stations 3 and 5. In such a configuration, the Rb-15F cannot be selected or used, and the loadout must be altered.

2. FÄLLSÄTT SWITCH

- For single missile
- For both missiles

AS DESIRED

IMP / Down
SERIE / Up

3. MÅLVAL SWITCH

- For standard target selection
- For programmed target selection

AS DESIRED

STD / Down
VALB / Up

VALB target selection depends on the settings stored in TAKT addresses 81–89.
STD target selection is the equivalent to single target, large-area search: the target closest to the assumed target position is detected and selected by the missile. This mode can also be selected in VALB by inputting TAKT code 800000.

NOTE

Unlike other weapons that assume the target will be at a target point (“Målpunkt”), Rb-15F employment assumes that the weapon will be released at the corresponding target navpoint. It then uses markpoints Bx6–Bx9 to determine the route it will fly and where to search for targets. As such, the location of the Målpunkt does not need the same precision adjustments other than to aid the pilot in low visibility situations in order to ensure a clear flight path between the Målpunkt and the Bx7 first steerpoint for the missile.

The Bx number is selected using the data input number buttons, not the B1–B9 waypoint buttons. Ensure that the Destination Indicator is showing a “Bx” destination rather than a navigation waypoint (“B”) or target waypoint (“M”) before making any updates or adjustments.

All Bx markpoints can be created and adjusted using the same procedure. However, if the Bx8 assumed target position (ATP) is created first, the CK37 will create Bx6, Bx7 and Bx9 automatically according to a predefined pattern, and these markpoints can then be adjusted as needed. If the markpoints come pre-programmed on the data cartridge, the same procedure can be used to adjust their position in-flight. Bx6 is not a steerpoint – instead, its distance to Bx7 is used to determine when the Rb-15 descends to skimming altitude. For ease of visualisation, it is always positioned between the release Målpunkt and markpoint Bx7.

Route Programming

1. SELECTING and VISUALISING

- Bx button + data input number
- Destination Indicator
- Destination Distance
- Radar display

Press
Displays Bx + number
Distance to markpoint
Circle for Bx8, cross for others

2. INPUT USING LATITUDE/LONGITUDE

- Data Selector
- IN – UT switch
- Latitude and longitude (6 digits, DDMSS format)
- Save
- New position

REF LOLA
IN / Left
Enter
Press Bx, then number button
Check

3. INPUT USING RADAR MARKING

- Radar mode
- Select markpoint
- Radar trigger
- Radar crosshairs
- Radar trigger
- New position

A1
Press Bx, then number button
T1 / First detent
Slew to correct position
TV / Second detent and release
Check

NOTE

To ensure that the steerpoint manoeuvres are possible, the system automatically limits how close the crosshairs can be slewed to pre-existing points when manipulating the radar marks.

RB-15F ASM EMPLOYMENT CHECKLIST

NOTE

When Master Mode is set to ANF, target selection is done by setting the MÅLVAL switch. In STD mode, the target closest to Bx8 is attacked. In VALB mode, the selection depends on TAKT addresses 81–89. If the missile is released in NAV Master Mode, the TAKT settings and missile steerpoints are not loaded — instead, the missile flies straight ahead and attacks the first detected target, similar to STD mode but without a predefined search area.

Specifics regarding flight altitudes, target search areas, and target restrictions can be entered as bitmasks in TAKT address 81 and 83–86 (see General Weapon Selection Checklist). For quick selection modes, the following TAKT codes can be used:

- 800001: Confined attack area; N-selection; medium search area.
- 800002: Unconfined attack area; A-selection; medium search area.
- 800003: Convoy attack; group selection; large search area.
- 800004: Bearing attack; bearing search area.

N-selection (“Nearest”): the three ships closest to Bx are determined; one is randomly selected as the target.
 A-selection (“All”): all ships in attack area range of Bx are determined; one is randomly selected as the target.
 Group selection: a group of ships, all within 3km of each other, is determined; one ship is randomly selected as the target. Only
 Bearing search: the target is assumed to be on the bearing between Bx7 and Bx8; search arc is expanded up to ±35° as the missile approaches Bx8. Search range is 6–24km.

Target Selection

Release Positioning

Weapon Release

1. RELEASE WAYPOINT

SELECTED

2. HÖJD GAUGE

SET TARGET QFE (=QNH)

3. MASTER MODE SELECTOR

ANF

NOTE

The Rb-15F can be fired directly from NAV mode and will fly straight ahead and engage detected targets of opportunity without being loaded with the steering or target selection programming entered in CK37. As such, no ranging, drift, or release information will be available on the HUD.

4. HUD STEERING CUES

FOLLOW

1. RELEASE PARAMETERS

- Aircraft altitude
- HUD distance line
- Altitude warning light

CHECK
 50–2000m
 Inside brackets
 Off

⚠ CAUTION

The altitude warning light will illuminate and launch is inhibited in if any of the following conditions are true:

- No Bx8 point is defined while in ANF mode.
- The commanded course change, or sum of commanded course changes >135° while in ANF mode.
- Missile flight time to Bx9 is <30 seconds while in ANF mode.
- If there is a CK or error or primary data/pitot system error.

The altitude warning light will illuminate, but launch will not be inhibited if the aircraft is outside the release altitude envelope.

Pressing the trigger while launch is inhibited will cause FÄLLD LAST to flash.
 The trigger has to be set to safe to reset the release circuits and clear the error.

2. TRIGGER

UNSAFE

3. TRIGGER

PRESS and HOLD
 Until FÄLLD LAST illuminates

NOTE

The release will unbalance the aircraft, requiring forceful roll trim change. In a SERIE release, maintain lever flight through stick adjustment alone since the aircraft will be rebalanced as the second weapon is released.

4. TRIGGER

SAFE

5. EVADE or CIRCLE FOR SECOND RELEASE

AS REQUIRED

6. MASTER MODE SELECTOR

NAV

The missile steers directly from the release point to Bx7, where it turns toward Bx8. If no targets are detected as it passes through Bx8, it turns towards Bx9. Depending on route and distance, the flight time to target may be up to 4 minutes.

END

RB-24J / RB74 AAM EMPLOYMENT CHECKLIST

Seeker	RA IR (RB24J), AA IR (RB74)	Minimum range:	500m
Release g-load:	<6 G	Maximum range:	8km / 4 nm.
Warhead:	4.8kg (RB24J), 9.4kg (RB74)		

1. WEAPON *SELECTOR***IR-RB****NOTE**

The RB-24J and RB-74 can also be selected by pressing the IR missile fast select button (LSP1).

2. MASTER MODE *SELECTOR***ANF****NOTE**

The weapon can also be used in master mode NAV. The sight appears when the trigger is set to UNSAFE. Target ranging is not used.

NOTE

The RB-24J and RB-74 can be ranged in a fixed wingspan mode or a radar-ranging mode.

3. WEAPON INTERVAL *SELECTOR***SET TARGET WINGSPAN****4. RADAR MODE *SWITCH*****A1 or A2****5. SIGHT DOT****ON TARGET****6. RADAR FIX TRIGGER****FIRST DETENT / T1**
To lock**7. MISSILE UNCAGE *BUTTON***

To track a manoeuvring target.

PRESS IF NEEDED**8. TRIGGER**

- Tone
- With wingspan ranging
- With radar ranging

UNSAFE and FIRE
High-pitch and steady
Wingspan envelops target
Distance line inside markers**9. TRIGGER****SAFE****10. MASTER MODE *SELECTOR*****NAV****END**

RB-75 AGM EMPLOYMENT CHECKLIST

Seeker	Electro-optical with fixed zoom.	Field of view	5° (RB-75 / RB-75T), 4° (RB-75B)
Warhead:	57kg (RB-75), 136kg (RB-75T)	Sleuable cone	30°
Targeting range:	500m – 22km / 12 nm.	Launch cone	15°

1. WEAPON SELECTOR

Data selector and switch to TAKT / UT

RB75

Check station digits show "1"

NOTE

If TAKT mode do not show the appropriate stations as operational, the aircraft is carrying conflicting mixed stores on other stations. In such a configuration, the ARAK M/70B cannot be selected or used, and the loadout must be altered.

NOTE

If RB-75:s are carried on both inner and outer pylons, the outer pair will be used first. If attempting a single-run attack, it is therefore advantageous to fit RB-75B on the outer pylons and RB-75 on the inner pylons. As range decreases on the attack run, the RB-75's lower zoom will make it easier to make out targets at the lower ranges the aircraft will be at when the second missile pair is employed.

2. MASTER MODE SELECTOR**ANF****NOTE**

The weapon can also be used in master mode NAV, but will have to be aimed without any ranging information. If firing from NAV mode, the sight will activate on trigger unsafe. In this mode, ensure that the RB 75 is selected and the sight active before trying to slew the seeker and command a lock, as the fix trigger may otherwise trigger an undesired target point or waypoint position update.

3. HÖJD GAUGE**SET TARGET QFE****4. DIRECT AIRCRAFT****TOWARDS TARGET****5. RADAR MODE SELECTOR**

To set RB 75 sensor mode.

- A0
- A1
- A2

AS DESIRED

Black-on-white
White-on-black
Auto

6. FIX TRIGGER**FIRST DETENT / T1**

To uncage seeker

7. EP-13 SEEKER CROSSHAIR**SLEW ONTO TARGET****8. FIX TRIGGER****SECOND DETENT / TV**

To command lock

9. TRIGGER**UNSAFE and FIRE**

On stable target lock

10. NEXT MISSILE using either:

- Trigger
- IR-RB FRAMSTEGN button (LSP1)

SELECT

Safe
Press

NOTE

Trigger unsafe boresights the selected missile. This can also be done by releasing the fix trigger to T0. Newly selected missiles start out boresighted. To perform rapid follow-up shots, it is therefore advantageous to fly through the EP-13 seeker scope using the boresighted seeker image — the next shot will require little slewing from the fast-moving and unsteady platform. The HÖJD and ATT autopilot modes may help in stabilising the aircraft while the pilot concentrates on slewing the seeker.

11. REPEAT STEPS 4–10**AS NEEDED****12. TRIGGER****SAFE****13. MASTER MODE SELECTOR****NAV****END**

SB71 GENERAL PURPOSE BOMB EMPLOYMENT CHECKLIST

All modes	1. WEAPON INTERVAL <i>SELECTOR</i>	DESIRED SPREAD	
	2. HÖJD <i>GAUGE</i>	SET TARGET QFE	
	3. POP-UP POINT - Data selector - IN – UT switch - Desired attack heading in degrees and distance in xx.y km - Select target point to confirm	SET AS and IF DESIRED TAKT IN / Left Enter as DDD XXY B1–B9	
NOTE Creating a pop-up point will convert the navpoint to a target point (“Målpunkt”) if that has not already been done. Pop-up points will be marked on the Destination Indicator with a “U” followed by the corresponding navpoint number and will offer terminal steering guidance on the HUD. With good visibility, the pop-up offset and roll-in manoeuvre can be performed manually based off of the steering cues for the regular target point.			
Level (PLAN) release	1. WEAPON <i>SELECTOR</i>	BOMB PLAN	
	2. RADAR MODE <i>SWITCH</i>	A0	
	3. MASTER MODE - For level release - For direct or CCIP release	AS DESIRED ANF NAV	
	NOTE: HIGH-DRAG BOMB CCIP High-drag bombs can be released in a CCIP mode only by selecting BOMB PLAN and NAV modes. In NAV mode, the target indicators activate on Trigger Unsafe and show the first and last calculated fall points based on QFE setting.		
	4. TARGET MOTION PREDICTION and RADAR RANGING - TAKT input codes 221 and 253.	DISABLED AS DESIRED If not using CCIP delivery	
	5. POP-UP POINT	SET AS and IF DESIRED If not using CCIP delivery	
	6. HUD POSITION	LOWER	
	7. SLAV SI <i>SWITCH</i>	F / LEFT	
8. HUD STEERING CUES	FOLLOW		
NOTE If using a pop-up point, the HUD indications will first steer you towards it before changing to the actual target point. Be prepared to adjust to the desired attack heading and roll in on the target while maintaining the set attack altitude.			
9. TRIGGER	UNSAFE When aiming dot is on target		
10. RADAR MODE <i>SWITCH</i> - To use radar ranging to improve accuracy of aim point, unless disabled.	A1 or A2 As desired		
11. TRIGGER - When ranging cue reaches markers.	PRESS and HOLD Until FÄLLD LAST illuminates		
12. HUD STEERING ORDER RING	FOLLOW Until FÄLLD LAST illuminates.		
⚠ CAUTION If slightly high or in a slight climb, the aiming marker and release cues may disappear below the HUD. In that case, the pilot will have to estimate the release point.			

NORMAL STEP

FULL PROCEDURE STEP

CONDITIONAL STEP

NON-FUNCTIONAL STEP

FULL PROCEDURE SUB-STEP

CONDITIONAL SUB-STEP

NON-FUNCTIONAL SUB-STEP

SB71 GENERAL PURPOSE BOMB EMPLOYMENT CHECKLIST

Dive (DYK) release	1. WEAPON <i>SELECTOR</i>	BOMB DYK
	2. RADAR MODE <i>SWITCH</i> - To use radar ranging to improve accuracy of aim point	AS DESIRED A1 or A2, otherwise A0 / Off
	3. MASTER MODE - For precision release - For quick release	AS DESIRED ANF NAV
	4. POP-UP POINT	SET AS DESIRED
	5. HUD POSITION	LOWER
	6. SLAV SI <i>SWITCH</i>	F / LEFT
	7. HUD STEERING CUES	FOLLOW
NOTE If using a pop-up point, the HUD indications will first steer you towards it before changing to the actual target point. If using a pop-up point, be prepared to pull up and roll into the desired attack heading set for the target.		
	8. TRIGGER	UNSAFE When reticule is on target
	9. TRIGGER - When ranging cue reaches markers.	PRESS and HOLD Until FÄLLD LAST illuminates
	10. HUD STEERING ORDER RING - Pull up from the dive at constant 4G	FOLLOW Until FÄLLD LAST illuminates.
Radar (RR) release	1. WEAPON <i>SELECTOR</i>	BOMB RR
	2. RADAR MODE <i>SWITCH</i>	A1 or A2
	3. MASTER MODE	ANF
	4. TRIGGER	UNSAFE
	5. TRIGGER - When radar range marker reaches target echoes.	PRESS and HOLD Until FÄLLD LAST illuminates
	6. RADAR MODE	AUTOMATICALLY TO A0
NAV release	⚠ CAUTION The precision of the NAV release mode is wholly contingent on accurate and precise QFE settings and on accurate and navigation data. A navigation fix should be performed on the waypoint before the target point, and the aircraft should be from with TERNAV constantly zeroing out any drift on the way to the target point.	
	1. WEAPON <i>SELECTOR</i>	BOMB RR
	2. RADAR MODE <i>SWITCH</i>	A0
	3. MASTER MODE	NAV
	4. TRIGGER	UNSAFE
	5. COMMANDED ALTITUDE	FOLLOW
	6. HUD DISTANCE LINE	FLASHES At 2s from release
	7. TRIGGER	PRESS and HOLD Until FÄLLD LAST illuminates

LFP = Left Front Panel — CC = Central Console — RFP = Right Front Panel — CTS = Control Stick
LHP = Left Horizontal Panel — LSP = Left Side Panel — LWP = Left Warning Panel — TRS = Throttle & Radar Stick
RWP = Right Warning Panel — RHP = Right Horizontal Panel — RSP = Right Side Panel

SB71 GENERAL PURPOSE BOMB EMPLOYMENT CHECKLIST

Toss release

⚠ CAUTION

The precision of the toss release mode is wholly contingent on accurate and precise QFE settings and on accurate and navigation data. A navigation fix should be performed on the waypoint before the target point, and the aircraft should be from with TERNAV constantly zeroing out any drift on the way to the target point.

1. WEAPON <i>SELECTOR</i>	BOMB RR
2. RADAR MODE <i>SWITCH</i>	A0
3. MASTER MODE	NAV
4. DIRECT AIRCRAFT Until distance indicator shows less than maximum release range	TOWARDS TARGET
5. PULL UP	AT 4G
6. TRIGGER	UNSAFE At 5° climb angle.
7. TRIGGER - When markers on distance line appear.	PRESS and HOLD Until FÄLLD LAST illuminates

NOTE

If the toss manoeuvre is performed correctly, the bombs will be released at 12–15° climb angle.

Attack complete

1. TRIGGER	SAFE
2. RADAR MODE <i>SWITCH</i>	A0
3. MASTER MODE <i>SELECTOR</i>	NAV
4. NEXT WAYPOINT	SELECT

END

NORMAL STEP

FULL PROCEDURE STEP

CONDITIONAL STEP

NON-FUNCTIONAL STEP

FULL PROCEDURE SUB-STEP

CONDITIONAL SUB-STEP

NON-FUNCTIONAL SUB-STEP

LYSB ILLUMINATION BOMB EMPLOYMENT CHECKLIST

1. WEAPON <i>SELECTOR</i>	ATTACK
2. WEAPON INTERVAL <i>SELECTOR</i> - VÄ - RAKT - HÖ	DESIRED POSITION Left of target On top of target Right of target
3. OFFSET DISTANCE - TAKT address 23	SET AS DESIRED 1–3 km (<i>default 2km</i>)
NOTE When creating a final target radar fix before attacking, the dialled-in offset will be added to the selected position. The targeting cross should therefore be set on top of the target position as usual, but the resulting navigation position circle after the fix will be offset per the settings.	
4. HÖJD <i>GAUGE</i>	SET TARGET QFE
5. MASTER MODE <i>SELECTOR</i>	ANF
NOTE The weapon can also be used in master mode NAV, but will have to be aimed without any ranging information. If firing from NAV mode, the aim point will activate on trigger unsafe.	
6. HUD STEERING CUES	FOLLOW
7. TRIGGER	UNSAFE
8. TRIGGER - When distance line flashes, 2 seconds before pull-up.	PRESS and HOLD Until FÄLLD LAST illuminates.
9. ADI FLIGHT DIRECTOR NEEDLES - Pull up at constant 4G	FOLLOW Until FÄLLD LAST illuminates.
10. TRIGGER	SAFE
11. MASTER MODE <i>SELECTOR</i>	NAV
END	

STORES JETTISON CHECKLIST

NOTE To release all carried fuel tanks, use the X TANK button (RSP2)		
Fuel tank jettison	1. X TANK <i>BUTTON COVER</i>	OPEN
	2. X TANK <i>BUTTON</i>	PRESS
NOTE To release all carried stores except RB 24J/74 on pylons 1 and 7, use the NÖDF button (RSP1)		
External stores	1. NÖDF <i>BUTTON COVER</i>	OPEN
	2. NÖDF <i>BUTTON</i>	PRESS
END		

FR22 V/UHF RADIO CHECKLIST

1. SPECIAL CHANNEL - H button - 1-3 buttons - - button	SET Guard frequency Special channel 1-3 Manual frequency
2. BASE CHANNEL - Rotary - A/G button - B button - C/F button - C2 button - D/E button	SET Airport number Subchannel A Subchannel B Subchannel C Subchannel C2 Subchannel D
NOTE Refer to kneeboard for a list of base numbers and their respective subchannels.	
3. GROUP CHANNEL - Rotary - 0-9 buttons	SET Group number Subgroup channel
NOTE Refer to kneeboard for a list of group numbers and their respective subgroups.	
END	

QFE DETERMINATION CHECKLIST

1. BACKUP HÖJD GAUGE	SET QNH OF REGION
2. MAIN HÖJD GAUGE	SET QFE OF AIRFIELD
Note the ASL altitude of the airfield as well as the difference in barometric pressure between QNH and QFE. • At or near sea level, 8.2m (27') of altitude should equate to a reduction in barometric pressure by 1 hPa. • At 100m ASL, the factor has increased to 8.4m / 1 hPa • For every 250m thereafter, the factor increases by 0.1 m / hPa: 8.5 @ 350m; 8.6 @ 600m; 8.7 @ 800m and so on.	
3. ALTITUDE OF POINT ON MAP (in metres)	NOTE RESULT
4. DIVIDE BY PRESSURE RATIO AT ALTITUDE	NOTE RESULT
5. SUBTRACT FROM QNH (As indicated on the backup HÖJD gauge)	ENTER AS QFE
END	