

POWER AND INTERCOM ACTIVATION

Wall panel	1. PARKING BRAKE ON	CHECK
	2. BATT 1/ТОК АКК1 СВ LH VLV CLOSED/КРАН ЛЕВ ЗАКРЫТ, RH VLV CLOSED/КРАН ПРАВ ЗАКРЫТ and landing gear lights will illuminate. INVERTER ON/ПРЕОГРАЗ light may illuminate if INV./ПРЕОГР. switch is in AUTO/АВТ or MAN/РУЧН position.	ON AND COVERED
	3. BATT 2/АКК2 СВ	ON AND COVERED
	4. INT.COM/АВСК СВ	ON
	5. INV./ПРЕОБР. СВ	AUTO/АВТ
Left panel	Set up ground power if needed	
	1. SPU-9 RADIO/РАДИО DIAL	GROUND CREW/ХОЛ
	2. GROUND POWER	REQUEST
Wall panel	1. EXT DC/=ТОК АЭР ПИТ СВ EXT DC PWR=/АЭР ПИТ= light will illuminate.	ON AND COVERED
	2. EXT AC/~ТОК АЭР ПИТ СВ EXT AC PWR~/ АЭР ПИТ~ light will illuminate.	ON AND COVERED
	3. VHF-1/УКВ-1 СВ	ON
	4. VHF-2/УКВ-2 СВ	ON
END		

NIGHT FLYING LIGHT SETUP

Wall panel	When using night vision goggles.	
	1. NVG/ПРИБОРЫ СВ	ON
	When not using night vision goggles.	
	1. ADI SAI/АГР ПКП СВ	ON
	2. PANEL HSI ADI/ПУЛЬТЫ СВ	ON
Back panel	1. REAR PANEL LIGHTING/ПОДСВЕТ ПУЛЬТ КОНТРОЛЯ СВ	ON
	2. СОКРПИТ PANEL LIGHTS/ЯРКОСТЬ ПОДСВЕТА and REAR PANEL/ПОДСВЕТ BRIGHTNESS	ADJUST
Wall panel	1. BLADE TIP LIGHTS/КОНТУР ОГИН СВ	ON
	2. FORM LIGHT/СТРОЕВ. ОГИН SWITCH	100%
	3. ANTI-COL BEACON/ПРОБЛЕСК МАЯК СВ	ON
OhP	1. NAV LIGHTS/АНО КОД SWITCH	100%
CP	1. LAND LIGHTS/ПОСАД ФАРА SWITCHES	LDG LIGHT/УПР. СВЕТ and MAIN/OCH
END		

EKRAN AND WARNING SYSTEM TESTS

Back panel	1. EKRAN HYD TRANS PWR/ ВМГ ГИДРО ЭКРАН СВ Master Warning light and MAIN GRBX/ГРAB РЕД warning lights will illuminate.	OPER (DOWN) AND COVERED
	2. BETTY VOICE TEST/ ПРОВЕРКА РЕЧЬ BUTTON	PUSH
Front panel	3. MASTER CAUTION BUTTON EKRAN will display SELFTEST/CАМОКОHT. After five seconds, the message should be replaced by EKRAN READY/ЗКРАH ГОДЕH.	RESET, THEN PUSH AND HOLD
	4. LAMPS TEST/ КОНТРОЛЬ СИГНАЛИЗ BUTTON	PUSH
	5. ENG EXH GAS TEMP TEST STOP/КОНТРОЛ ДВИГ ГАЗ HE РАБОТ BUTTON	PUSH TO CHECK Should show >800°C
Wall panel (top)	6. FIRE EXTINGUISHER OPER-OFF-TEST/ОГНЕТУЖ.- ОТКЛ-КОНТР. SWITCH	TEST/КОНТР.
	7. FIRE SIGNALLING WARN-OFF/СИГНАЛИЗ.-ОТКЛ. SWITCH	WARN/СИГНАЛИЗ.
	8. FIRE TEST/КОНТРОЛ SWITCH FIRE LH ENG/ПОЖАР ЛЕВ ДВИГ, FIRE АРУ/ПОЖАР ВСУ, FIRE HYDR/ПОЖАР ГИДРО, FIRE RH ENG/ПОЖАР ПРАВ ДВИГ, FIRE GRBX/ПОЖАР ВЕНТИЛ fire extinguisher lights and FIRE/ПОЖАР main warning light will illuminate	GR1/I ГП
	9. FIRE SIGNALLING SWITCH	TOGGLE OFF AND ON
	10. FIRE TEST/КОНТРОЛ SWITCH FIRE LH ENG/ПОЖАР ЛЕВ ДВИГ, FIRE HYDR/ПОЖАР ГИДРО, FIRE RH ENG/ПОЖАР ПРАВ ДВИГ, FIRE GRBX/ПОЖАР ВЕНТИЛ fire extinguisher lights and FIRE/ПОЖАР main warning light will illuminate	GR2/II ГП
	11. FIRE SIGNALLING SWITCH	TOGGLE OFF AND ON
	12. FIRE TEST/КОНТРОЛ SWITCH	GR3/III ГП
	13. FIRE SIGNALLING SWITCH	TOGGLE OFF AND ON
	14. FIRE EXTINGUISHER OPER-OFF-TEST/ОГНЕТУЖ.- ОТКЛ-КОНТР. SWITCH	OPER/ОГНЕТУЖ.

END

ENGINE START**NOTE**

If ground power is being used, engine start may be deferred until after systems set-up is complete. Once engine start and run-up is complete, perform steps 1–3 on the systems activation checklist to disengage ground power.

Wall panel	1. APU SHUTOFF VLV/ПЕРЕКР. КРАН ВСУ СВ APU LVL OPEN/КРАН ВСУ ОТКРЫТ light on APU panel will illuminate.	ON AND UNGUARDED
	2. LEFT and RIGHT SHUTOFF VLV/ПЕРЕКР. КРАН ЛЕВ. ДВИГ. and ПРАВ. ДВИГ. СВS LH VLV CLOSED/КРАН ЛЕВ ЗАКРЫТ and RH LVL CLOSED/КРАН ПРАВ ЗАКРЫТ lights on overhead panel will go out.	ON AND GUARDED
	3. X-FEED VLV/КРАН КОЛЬЦЕВ СВ X-FEED VLV OPEN/КОЛЬЦЕВ ОТКРЫТУ light on overhead panel will illuminate	ON AND GUARDED
	4. FWD and AFT FUEL PUMPS/ПЕРЕД. and ЗАДН. НАСОСЫ БАКОВ СВS FWD TANK PUMP ON/БАК ПЕРЕДНИЙ and AFT TANK PUMP ON/БАК ЗАДНИЙ lights on overhead panel will illuminate.	ON
	5. INNER and OUTER EXT./ВНУТР. and ВНЕШН. ПОДВЕС СВS	AS REQUIRED
	6. EEG LH and RH/ЗРД ЛЕВ. and ПРАВ. СВS	ON AND GUARDED
	7. FUEL-QTY/ТОПЛИВОМЕР СВ	ON
Front panel	1. SELF TEST FUEL QUAN/КОНТРОЛЬ ТОПЛИВОМЕРД BUTTON	PUSH
	2. STARTUP	REQUEST
Left panel	1. START-CRANK-FALSE START/ЗАПУСК-ПРОКРУТКА-ЛОЖНЫЙ ЗАПУСК SWITCH	START/ЗАПУСК
	2. ENGINE SELECTOR SWITCH	APU/BCY
	3. START/ЗАПУСК BUTTON	PRESS
NOTE APU EGT will rise and should not exceed 850°C. The APU OIL PRESS. NORM/P МАСЛА ВСУ and APU ON/BCY ВКЛЮЧЕНА lights should illuminate. Stand-by mode should be reached in 24 seconds, with an EGT of no more than 720°C.		
<p style="text-align: center;">⚠ CAUTION</p> <p>If there is no EGT response after the start button is pressed for 9 seconds, if the above parameters are not met during start-up, if there are any anomalies in APU operation, or if there is an uncontrolled APU shutdown, cancel APU by pressing the APU SHUTOFF/ОСТАНОВ ВСУ button.</p> <p>If the cancellation is due to lack of EGT or an uncontrolled shut-down, an APU engine crank should be performed before initiating another restart.</p> <p style="text-align: center;">The APU will automatically shut down in case of RPM over-limit, which is indicated by the APU Nmax SHUTOFF/ОСТАНОВ ВСУ no n light on the APU panel.</p>		
	4. APU WARM-UP Warm-up, with no air bleeding, should take one minute before using the APU for engine starts.	COMPLETE

ENGINE START

Left panel	5. COCKPIT DOOR	CLOSED
	6. ROTOR BRAKE	OFF (DOWN)
	7. ENGINE SELECTOR SWITCH	LH ENG/ЛЕВ. ДВИГ.
	8. START/ЗАПУСК BUTTON Tachometer will start to rise.	PRESS
⚠ WARNING It is forbidden to start the engines with no operating boost pumps.		
	9. LH ENGINE CUT-OFF VALVE/ЛЕВ. СТОП-КРАНИ ДВИГАТЕЛЕЙ LEVER	OPEN/ЗАКРЫТУ
NOTE At 20% RPM. Left engine EGT should rise smoothly and reach 600°C at idle (72–78% RPM) in ~60 seconds. Rotor motion should initiate at no more than 25% RPM. Starter will disengage at 60–65% RPM and the START VLV/КЛАПАН ЗАПУСКА light on the engine panel will go out. Hydraulic pressure and temperature should rise in all systems (monitor rear panel).		
⚠ CAUTION Close the engine cutoff valve lever and press STOP/СТОП ЗАПУСК button to cancel an engine startup if the above parameters are not met or in the following situations: • EGT goes over limit. • RPM “freezes” for more than 3 seconds. Another start-up is allowed after an aborted start only after reaching a full stop on the tachometer and addressing the reason(s) for the failed start. Before initiating another start-up, perform an engine crank. It is not advised to move the Engine Selector Switch before the first engine has reached idle power.		
	10. ENGINE SELECTOR SWITCH Repeat process for right engine	RH ENG/ПРАВ. ДВИГ.
⚠ CAUTION After both engines have started, check rotor RPM. Operation between 54–65% rotor RPM is not advised. If necessary to meet this requirement, move the engine throttle levers up to attain a rotor speed of 62–70% RPM.		
⚠ WARNING Do not increase engine power past idle until the output oil temperature reaches +30°C for the engines, and no less than -15°C for the main gearbox (monitor wall panel).		
	11. APU SHUTOFF/ОСТАНОВ ВСУ BUTTON APU OIL PRESS. NORM/P МАСЛА ВСУ and APU ON/ВСУ ВКЛЮЧЕНА lights go out; APU EGT to zero.	PRESS
	12. ENGINE THROTTLES Engine RPM should settle at ~80%.	AUTO/АВТОМАТ
Wall panel	1. APU SHUTOFF VLV/ПЕРЕКР. КРАН ВСУ СВ APU LVL OPEN/КРАН ВСУ ОТКРЫТ light goes out.	OFF AND GUARDED
	2. LH and RH AC SYS GEN/ЛЕВ. and ПРАВ. ~ТОК ГЕН. CBS	ON
END		

APU AND ENGINE CRANK AND FALSE START

APU false start

NOTE

A false APU start is used to check the APU system without fuel ignition.

1. ONBOARD/GROUND ELECTRICAL POWER	CHECK
2. APU SHUTOFF VLV/ПЕРЕКР. КРАН ВСУ СВ	ON
3. AFT FUEL PUMP/ЗАДН. НАСОСЫ БАКОВ СВ	ON
4. START-CRANK-FALSE START/ЗАПУСК-ПРОКРУТКА-ЛОЖНЫЙ ЗАПУСК SWITCH	FALSE START/ЛОЖНЫЙ ЗАПУСК
5. ENGINE SELECTOR SWITCH	APU/ВСУ
6. START/ЗАПУСК BUTTON	PRESS
7. APU SHUTOFF/ОСТАНОВ ВСУ BUTTON After 15 seconds.	PRESS
8. APU CRANK	CHECK

APU crank

NOTE

After a false or failed APU start, you need to vent the remaining fuel from the combustion chamber and then do an APU crank. The crank serves to blow out any fuel in the APU combustion chamber after the incomplete start.

An APU crank is performed exactly like an APU false start, except for step 4. Its purpose

4. START-CRANK-FALSE START/ЗАПУСК-ПРОКРУТКА-ЛОЖНЫЙ ЗАПУСК SWITCH	CRANK/ПРОКРУТКА
---	------------------------

Engine False Start

NOTE

A false engine start is used to check the engine system without fuel ignition.

1. ROTOR BRAKE	ON (UP)
2. ENGINE CUT-OFF VALVE/СТОП-КРАНИ ДВИГАТЕЛЕЙ LEVER Left or right as required by the engine being false-started.	OPEN/ЗАКРЫТУ
3. SHUTOFF VLV/ПЕРЕКР. КРАН ДВИГ. СВ	L/R ON AS REQUIRED
4. START-CRANK-FALSE START/ЗАПУСК-ПРОКРУТКА-ЛОЖНЫЙ ЗАПУСК SWITCH	FALSE START/ЛОЖНЫЙ ЗАПУСК
5. ENGINE SELECTOR SWITCH	L/R AS REQUIRED
6. START/ЗАПУСК BUTTON	PRESS

NOTE

During the false start, monitor the following: oil pressure >0.5 kg/cm², RPM >20%

7. ENGINE CRANK	CHECK
------------------------	--------------

Engine Crank

NOTE

After a false or failed engine start, you need to vent the remaining fuel from the combustion chamber and then do an engine crank. The crank serves to blow out any fuel in the engine combustion chamber after the incomplete start.

An engine crank is performed exactly like an engine false start, except for steps 3 and 4:

3. SHUTOFF VLV/ПЕРЕКР. КРАН ДВИГ. СВ	OFF
4. START-CRANK-FALSE START/ЗАПУСК-ПРОКРУТКА-ЛОЖНЫЙ ЗАПУСК SWITCH	CRANK/ПРОКРУТКА

END

SYSTEMS ACTIVATION

	Cyclic		ON
Wall panel	1. PARKING BRAKE		ON
	NOTE With engines running at 80% RPM in auto mode, ground power may now be turned off. If system set-up is done before starting engine, defer these steps until after completed engine start and run-up.		
	1. EXT DC/=ТОК АЭР ПИТ СВ EXT DC PWR=/АЭР ПИТ= light will go out.		OFF AND COVERED
	2. EXT AC/~ТОК АЭР ПИТ СВ EXT AC PWR~/ АЭР ПИТ~ light will go out.		OFF AND COVERED
	3. GROUND POWER		REQUEST OFF
	4. NAV/ПНК СВ Radar altimeter and HSI will activate; HSI will still display “Heading unreliable” KC flags; HUD NO READY/ПАНЕТ light illuminates, and will go out as HUD comes online after ~3 minutes.		ON
	5. STANDBY SAI/РЕЗЕРВ АГ СВ		ON
	6. IFF/СРО СВ		ON
7. EJECT-SEAT-SYS/АВАР. ПОКИДАН. СВS		ALL ON AND COVERED	
Back panel	1. AUT EJECT SYS ВІТ/КОНТРОЛЬ КАНАЛОВ САП TEST		COMPLETED
	Move the MAN-POWER-BLADES SEPARATION/ИСХОД-ПИТАНИЕ-ОТДЕЛЕНИЕ ЛОПАСТЕЙ egress mode selector through each position and press the circuit test button. The КОНТРОЛЬ САП light should illuminate for all modes except MAN/ИСХОД.		
	2. INU HEAT/ОБОГРЕВ ИКВ СВ		ON
	3. INU/ИКВ СВ ADI will activate; Pitch and bank steering (ДИР) flag will still display; HSI “Heading unreliable” KC flags will be stowed.		ON
	4. UV-26 OPER-OFF/УВ-26 ВЛК-ОТКЛ SWITCH Overhead panel countermeasure indicator turns on, displaying the number of flares available (typically 64/side).		OPER/ВКЛ. AND GUARDED
	5. UV-26 TEST-OFF/УВ-26 КОНТР-ОТКЛ SWITCH Countermeasures indicator should display 990.		TEST/КОНТР
	6. UV-26 TEST-OFF/УВ-26 КОНТР-ОТКЛ SWITCH		OFF/ОТКЛ AND GUARDED
	7. L-140/Л-140 СВ Back-panel LWS/ИСПР light will illuminate green.		ON
8. L-140 TEST/Л-140 КОНТР BUTTON Overhead panel LWS indicator will illuminate random direction and hemisphere lights; MWS light will blink.		PRESS	
Left panel	1. K-041 СВ “Shkval” display turns on; HUD activation starts unless already started with the NAV/ПНК circuit breaker.		ON

SYSTEMS ACTIVATION

Front panel	1. CLOCK	CHECK TIME																																												
	2. HSI COMMANDED HEADING AND COURSE	AS DESIRED																																												
	3. BAROMETRIC ALTIMETER	SET																																												
	4. RADAR ALTIMETER	SET AND TEST																																												
	5. ADI	SET AND TEST																																												
	6. ACCELEROMETER	RESET																																												
	7. АБРИС СВ ABRIS system will boot up, which takes ~3 minutes.	ON																																												
	8. ENG EXH GAS TEMP TEST RUN/ КОНТРОЛ ДВИГ ГАЗ РАБОТ BUTTON	PUSH TO CHECK Should show <150°C																																												
UV-26 Countermeasures panel	1. COUNTERMEASURES AVAILABILITY	CHECK																																												
	Move the QUANT-NUM/НАЛИЧ-ПРОГР switch to QUANT/НАЛИЧ, then move the SIDE/БОПТ switch to the left, right and middle position to show availability in each countermeasures launcher. Fully loaded, it should display 64 per side, and 128 total in the middle position.																																													
	2. COUNTERMEASURES PROGRAM	SET																																												
Move the QUANT-NUM/НАЛИЧ-ПРОГР switch to NUM/ПРОГР. Use the NUM/СЕРИА button to adjust the number of sequences (first number on display). Use the SEQ/ЗАЛП button to adjust the number of flares per sequence (second number on display). Use the INTERVAL/ИНТЕРВАЛ button to adjust the delay between releases (third number on display). Use the RES PROG/СБРОС ПРОГР. button to reset to the default (110) program.																																														
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td>NUM/SEQ/INTERVAL</td> <td>0</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td>9</td> </tr> <tr> <td>Number of sequences</td> <td>∞</td><td>1</td><td>2</td><td>3</td><td>4</td><td>12</td><td>6</td><td>15</td><td>8</td><td>9</td> </tr> <tr> <td>Flares per sequence</td> <td style="text-align: center;">/</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td><td>6</td><td>7</td><td>8</td><td style="text-align: center;">/</td> </tr> <tr> <td>Interval between flares</td> <td>1/8 s</td><td>1 s</td><td>2 s</td><td>3 s</td><td>4 s</td><td>5 s</td><td>6 s</td><td>1/4 s</td><td>8 s</td><td>1/2 s</td> </tr> </table>			NUM/SEQ/INTERVAL	0	1	2	3	4	5	6	7	8	9	Number of sequences	∞	1	2	3	4	12	6	15	8	9	Flares per sequence	/	1	2	3	4	5	6	7	8	/	Interval between flares	1/8 s	1 s	2 s	3 s	4 s	5 s	6 s	1/4 s	8 s	1/2 s
NUM/SEQ/INTERVAL	0	1	2	3	4	5	6	7	8	9																																				
Number of sequences	∞	1	2	3	4	12	6	15	8	9																																				
Flares per sequence	/	1	2	3	4	5	6	7	8	/																																				
Interval between flares	1/8 s	1 s	2 s	3 s	4 s	5 s	6 s	1/4 s	8 s	1/2 s																																				
Move the QUANT-NUM/НАЛИЧ-ПРОГР switch back to QUANT/НАЛИЧ when done.																																														
Overhead panel	NOTE If ambient temperature is below +5°C or if flight at altitude is planned, enable anti-icing systems.																																													
	1. ENG ANTI ICE/DUST PROT / ПОС ДВИГ SWITCH	UPPER POSITION																																												
	2. ROTOR ANTI-ICE/ПОС ВИНТОВ СВ	ON																																												
	3. PITOT HEAT STA AOA/ППД ДУАС AND RAM AIR/ПВД ЧАСЫ CBS	ON																																												
	4. ENG ANTI ICE/DUST PROT / ПОС ДВИГ SWITCH	DUST/ПЗУ If flying in dusty conditions																																												
	5. WINDSH-WIPER/СТЕКЛООЧИСТ SWITCH	AS NEEDED																																												
LWR Panel	1. RESET/СБРОС BUTTON Lights from L-140 test will go out. Back-panel LWS/ИСПР light will illuminate green after 30 seconds.	PRESS																																												
END																																														

COMMUNICATION SYSTEM SETUP

Wall panel	1. INT.COM/ABCK CB	CONFIRM ON																				
	2. VHF-1/УКВ-1 CB	CONFIRM ON																				
	3. VHF-2/УКВ-2 CB	CONFIRM ON																				
	4. DL/ТЛК CB	ON																				
	5. VHF-TLK/УКВ-ТЛК CB	ON																				
	6. SA-TFL/CA-ТЛФ CB	ON																				
Right panel	1. SIGNAL FLARE POWER CB	ON/ВКЛ																				
	2. R-828 (VHF-1) CHANNEL/КАНАЛИ SELECTOR	AS REQUIRED																				
	R-828/VHF-1 Channel presets are:																					
	<table border="1"> <tr> <td>1</td><td>21.5 MHz</td><td>3</td><td>27.0 MHz</td><td>5</td><td>30.0 MHz</td><td>7</td><td>40.0 MHz</td><td>9</td><td>55.5 MHz</td> </tr> <tr> <td>2</td><td>25.7 MHz</td><td>4</td><td>28.0 MHz</td><td>6</td><td>32.0 MHz</td><td>8</td><td>50.0 MHz</td><td>10</td><td>59.9 MHz</td> </tr> </table>		1	21.5 MHz	3	27.0 MHz	5	30.0 MHz	7	40.0 MHz	9	55.5 MHz	2	25.7 MHz	4	28.0 MHz	6	32.0 MHz	8	50.0 MHz	10	59.9 MHz
	1	21.5 MHz	3	27.0 MHz	5	30.0 MHz	7	40.0 MHz	9	55.5 MHz												
	2	25.7 MHz	4	28.0 MHz	6	32.0 MHz	8	50.0 MHz	10	59.9 MHz												
	3. SQ/ПШ CB	AS REQUIRED																				
	4. R-828 VOLUME/ГРОМК. KNOB	AS REQUIRED																				
	5. TUN/АКУ BUTTON	PRESS To tune to selected channel																				
	6. ID NO./КТО Я SELECTOR Flight lead is 1, wingmen/second element are 2–3	PER FLIGHT POSITION																				
7. DATA/РЕЖИМ SELECTOR	AS REQUIRED																					
OFF/ОТКЛ – link disabled; REC/ПРИЕМ – receive only; WINGM/ВЕДОМ – to/from all wing members; COM/КОМ – to/from flight leader only. In WINGM/ВЕДОМ and COM/КОМ mode, wingman icons will be displayed on the ABRIS.																						
8. NAV DATALINK POWER CB	ON/ВЦУ																					
Left panel	1. R-800L1 (VHF-2) FREQUENCY	AS REQUIRED																				
	2. AM-FM/АМ-ЧМ SWITCH	AS REQUIRED																				
	3. SQ/ПШ SWITCH	AS REQUIRED																				
	4. GUARD/АП SWITCH	OFF																				
	5. ADF/АРК SWITCH	OFF																				
	6. 100–50 SWITCH	100																				
	7. TEST/КОНТР. BUTTON	PRESS																				
	8. SPU-9 RADIO/РАДИО SELECTOR	AS REQUIRED																				
	9. COMMUNICATIONS	CHECK																				
END																						

NAVIGATION SYSTEM SETUP

Back panel	1. INU HEAT/ОБОГРЕВ ИКВ СВ		CONFIRM ON																	
	2. INU/ИКВ СВ		CONFIRM ON																	
Wall panel	1. NAV/ПНК СВ		CONFIRM ON																	
	2. MH-GYRO-MAN/МК-ГПК-3К SWITCH		GYRO/ГПК																	
Front panel	3. ADF		CHECK																	
	<p>On the ADF CHAN/КАНАЛИ APK selector, select the setting corresponding to your current airfield. Default configuration is:</p> <table border="1" style="width: 100%; border-collapse: collapse; text-align: center;"> <tr> <td style="width: 5%;">1</td> <td style="width: 25%;">Krasnodar-Center</td> <td style="width: 5%;">3</td> <td style="width: 25%;">Krymsk</td> <td style="width: 5%;">5</td> <td style="width: 25%;">Gali (outer), Mozdok (inner)</td> <td style="width: 5%;">7</td> <td style="width: 25%;">Mineralnye Vody</td> </tr> <tr> <td>2</td> <td>Maykop-Khanskaya</td> <td>4</td> <td>Anapa-Vityazevo</td> <td>6</td> <td>Nalchik</td> <td>8</td> <td>Sukhumi-Babushara (outer), Peredovaya (inner)</td> </tr> </table> <p>On the left front panel, set the DH/DATA MANUAL-AUTO/ЗПУ-3К РУЧН.-АВТ. switch to AUTO/АВТ. On the centre console, set the INNER-AUTO-OUTER NDB/ ПРИВОД P/C БЛИЖН.-АВТ-ДАЛbН. switch to INNER/БЛИЖН. On the right console ADF panel, set the COMPASS-ANT/КОМП.-АНТ. switch to ANT/АНТ. to receive Inner NDB identification signal broadcast (once every 15 seconds). Set the COMPASS-ANT/КОМП.-АНТ. switch to COMPASS/КОМП. and check that the HSI points to the inner beacon.</p> <p>Repeat the process with the INNER-OUTER/БЛИЖН.-ДАЛbН. switch in the OUTER/ДАЛbН. position and confirm that the HSI points to the outer beacon. With checks complete, leave the INNER-OUTER/БЛИЖН.-ДАЛbН. switch in the OUTER/ДАЛbН. position and the COMPASS-ANT/КОМП.-АНТ. switch in the COMPASS/КОМП. position.</p> <p>On the left panel, turn on the ADF/APK switch and check the HDI to confirm that the yellow RMI bearing needle aligns with the Desired Heading index. Then turn the ADF/APK switch off.</p>				1	Krasnodar-Center	3	Krymsk	5	Gali (outer), Mozdok (inner)	7	Mineralnye Vody	2	Maykop-Khanskaya	4	Anapa-Vityazevo	6	Nalchik	8	Sukhumi-Babushara (outer), Peredovaya (inner)
	1	Krasnodar-Center	3	Krymsk	5	Gali (outer), Mozdok (inner)	7	Mineralnye Vody												
	2	Maykop-Khanskaya	4	Anapa-Vityazevo	6	Nalchik	8	Sukhumi-Babushara (outer), Peredovaya (inner)												
	4. DH/DATA MANUAL-AUTO/ЗПУ-3К РУЧН.-АВТ. SWITCH		AS DESIRED																	
5. АБРИС СВ		CONFIRM ON																		
<p>The ABRIS takes 3 minutes to boot and load. If it is not pre-programmed with mission waypoints, they can be added manually by pressing [3] PLAN/ПЛАН; [2] EDIT/РЕДАКТ > DRAW/РИСОВ; [1] EDIT/РЕДАКТ > INSERT/ВСТАВ. Use the cursor knob to adjust position; pushing the cursor alternates between X/Y movement; press [1] ADD/ДОБАВ; [1] ENTER/ВВОД. To insert waypoints between two existing points, select the waypoint after which you want to add the new waypoint, then press [1] EDIT/РЕДАКТ > INSERT/ВСТАВ.</p> <p>When complete, save the flight plan by pushing [1] SELECT/ВЫБРАТЬ > SAVE/ЗАПИСЬ; enter a name; push [4] SAVE/ЗАПИСЬ. Activate the flight plan by pushing [4] ACTIV/АКТ. This puts you directly into NAV/HAB mode.</p>																				
Right Panel	1. PVI-800 NAV MASTER MODE KNOB		EDIT/ВВОД																	
	<p>If the PVI-800 is not pre-programmed with mission waypoints, they can be added manually by pressing the WPT/ППМ button, enter the corresponding number, then enter 5-number latitude and 6-number longitude. For positive numbers (northern, eastern hemisphere), begin entry by pushing the +/0 button. For negative numbers (southern, western hemisphere), begin by pushing the -/1 button. Finish entry by pushing the ENTER/ВВОД button. For example: WPT/ППМ 2 0 44442 0 040063 ENTER/ВВОД sets waypoint 2 to lat N44°44'2[0]"/long E040°06'3[0]".</p> <p>If the ABRIS has been programmed, coordinates can be referenced on the NAV > FPL / HAB > ШБЖ page. The same method can be used to enter nav fix points (FIX PNT/OP), airfields (AIR FIELD/АЭР), target points (NAV TGT/OT) and to manually set the current position (SELF COOR/φλ).</p>																			
	2. PVI-800 NAV MASTER MODE KNOB		OPER/РАБ																	
	3. FIRST WAYPOINT WPT/ППМ button followed by corresponding number.		SELECTED																	
	4. NAV INU FIXTAKING SWITCH		AS DESIRED																	
5. NAV DATALINK POWER CB		CONFIRM ON/ВЦУ																		

END

AUTOPILOT ACTIVATION

Cyclic	1. AUTOPILOT DISENGAGE BUTTON	PRESS
	2. CYCLIC TRIM	CENTRED AND RESET
Right Panel	1. BANK HOLD/K BUTTON	ON
	2. PITCH HOLD/T BUTTON	ON
	3. FD AP/ДИР УПР BUTTON	CONRIFM OFF
	4. HDG HOLD/H BUTTON	ON
	5. ALT HOLD/B BUTTON	CONFIRM OFF
	6. BR-RD/БАР-РВ SWITCH	AS DESIRED
	7. DH-DT/ЗК-ЛЗП SWITCH	AS DESIRED
Cycl.	1. TRIMMER BUTTON	PRESS
Left Panel	1. DESCENT-ROUTE/СНИЖЕН-МАРШР SWITCH	OFF / CENTRED
	2. AUTO-TURN/АДВ BUTTON	OFF
END		

OFFENSIVE SYSTEMS ACTIVATION

Left Panel	1. LAS-OFF/ИЗЛ.-ОТКЛ- SWITCH	LAS/ИЗЛ.											
	2. RESET/СБРОС BUTTON AUTO TURN / АДВ, А/А Н О / ППС, А/А / ВЦ, MOV GND TGT / НПЦ buttons should all be off.	PRESS											
	3. AUTOMATIC TRACKING SWITCH	AT/AC											
	4. HEAD-MOUNTED DEVICE SWITCH	AS DESIRED											
	5. TRAIN-OFF/ТРЕНАЖ-ОТКЛ SWITCH	OFF/ОТКЛ											
Centre Panel	1. MASTER ARM/ГЛАВНЫЙ ВКЛ SWITCH	OFF (DOWN)											
	2. MAN-AUTO/РУЧН-АВТ SWITCH	AUTO/АВТ											
	3. LNG-MED-SHORT/ДЛ-СР-КОР SWITCH	AS DESIRED											
	4. HE-API/ОФ-БР SWITCH	AS DESIRED											
	5. LOW-HIGH/MT-БТ SWITCH	AS DESIRED											
Wall Panel	1. IFF/СРО СВ	ON AND COVERED											
	2. W-SYS/СУО СВ	ON AND COVERED											
Back panel	1. UGM В / НП/АКС DIAL	AS REQUIRED											
	<table border="1"> <tbody> <tr> <td>0</td> <td>S-8KOM AT/AP rockets</td> <td>3</td> <td>S-24 heavy rockets</td> </tr> <tr> <td>1</td> <td>S-8TsM smoke rockets</td> <td>4</td> <td>S-8M HE rockets</td> </tr> <tr> <td>2</td> <td>S-13 rockets</td> <td>5</td> <td>UKP-23 gun pods</td> </tr> </tbody> </table>	0	S-8KOM AT/AP rockets	3	S-24 heavy rockets	1	S-8TsM smoke rockets	4	S-8M HE rockets	2	S-13 rockets	5	UKP-23 gun pods
0	S-8KOM AT/AP rockets	3	S-24 heavy rockets										
1	S-8TsM smoke rockets	4	S-8M HE rockets										
2	S-13 rockets	5	UKP-23 gun pods										
END													

TAXIING PREPARATION

1. ALL SYSTEMS NOMINAL - ENGINES - ROTORS - SYSTEMS - COMPONENTS	CHECK
2. WARNING LIGHTS	CHECK
3. EKРАН/EKPAH DISPLAY	CHECK
4. BANK, PITCH, HDG HOLD/K, T, H AUTOPILOT MODE BUTTONS	ON
5. EJECT-SEAT-SYS/АВАР. ПОКИДАН. СБС	ALL ON AND COVERED
6. SAI	UNCAGE AND SET
END	

HOVER CHECK (WHEN TAKING OFF FROM AN AIRFIELD)

1. HELICOPTER ORIENTED AGAINST THE WIND	CHECK
2. WHEELS ALIGNED	CHECK
3. PARKING BRAKE	ENGAGE
4. FLIGHT INSTRUMENTS	NOMINAL
5. HOVER CHECK	REQUEST
6. PARKING BRAKE	RELEASE
7. COLLECTIVE	SMOOTHLY UP
8. DESIRED HOVER ALTITUDE	SET
9. TRIM BUTTON	PRESS
NOTE Be careful not to let the aircraft bank or yaw. Maintain the required altitude with smooth movements of the collective. Use the radar altimeter and visual ground references to hold a constant altitude. Leaving the cockpit door open may provide better visibility of ground reference points. Use smooth pedal inputs to turn the aircraft, but note that weather cocking affects the turn speed at different headings.	
10. HOVER CHECKS - AIRCRAFT CONTROL - CENTRE OF GRAVITY POSITION - VERTICAL LIFT-OFF ABILITY	CHECK CHECK CHECK
11. HOVER MODE STABILISATION	CHECK
NOTE At an altitude of at least 4m, balance and trim the helicopter and engage the Hover mode by pressing the Hover button. The overhead AUTO HOVER/ВИСЕНИЕ light will illuminate. On the HSI, the needles become perpendicular to each other and their deflection corresponds to the helicopter's hover position. A neutral (zero) position should be indicated on the pitch scale.	
END	

TAXIING

1. TAXI PERMISSION	REQUEST
2. NO OBSTACLES OR FOREIGN OBJECTS IN TAXI PATH	CHECK
3. PARKING BRAKE	OFF
4. TAXI TO ASSIGNED TAKE-OFF POINT	CHECK
NOTE	
Using the ground as reference, control taxi speed with the cyclic, collective, and wheel brakes. You can also use the anti-torque pedals to turn the facing of the helicopter. In case of low visibility conditions, turn on the blade tip lights, the navigation lights, and the anti-collision light. You can also turn on the main or backup landing lights and manually direct the main light.	
To halt the helicopter during a taxi, you should move the cyclic to a neutral position, decrease the collective pitch, and engage the wheels brakes.	
⊘ CAUTION	
Taxi should be performed on hard, smooth surfaces at speeds up to 15km/h with a wind speed less than 20m/s.	
In case of brake failure, you can halt the aircraft by pulling the cyclic back while increasing collective pitch to nearly hover. The helicopter must be carefully controlled with the cyclic to avoid the tail hitting the ground.	
NOTE	
Taxi turns are executed with smooth and simultaneous input of the anti-torque pedals and cyclic stick towards the direction of the turn. Be careful to avoid a banking angle over 5° and high speed turns.	
During taxi in a crosswind, the helicopter will have a tendency to turn toward the wind. This should be compensated for by reacting with a neutral bank angle towards the wind direction up to 5°.	
⊘ CAUTION	
Backward taxi and turns on one wheel are not advised.	
Taxi on soil or snow should be performed with extreme caution and at speeds up to 5 km/h or less. Nose wheel bounce should be avoided by controlling the helicopter via the cyclic and collective sticks.	
END	

VERTICAL TAKE-OFF USING ROTOR-IN-GROUND EFFECT

NOTE	
Take-off technique may be performed when in a stable hover at no more than 2m altitude. Engines will need to be at maximum power.	
1. HOVER CHECK	TO 2m
2. PERMISSION TO TAKE OFF	REQUEST
3. ALL SYSTEMS NOMINAL	CHECK
4. CYCLIC	FORWARD
NOTE	
Initiate forward flight acceleration while increasing engine power to take-off mode (in case spare power is available) This is in order to prevent any sinkage of the helicopter.	
Forward flight acceleration should take place in the rotor-in-ground zone with a gradual climb to 5m altitude at 90–100km/h IAS. Further acceleration should be performed with a slight climb.	
5. LANDING GEAR	UP
END	

VERTICAL TAKE-OFF WITHOUT USING ROTOR-IN-GROUND EFFECT**NOTE**

Take-off technique may be performed when the helicopter is in a stable hover at no less than 10m above obstacle height in the take-off direction. Maximum engine power would be used.

1. HOVER CHECK	TO 10m
2. PERMISSION TO TAKE OFF	REQUEST
3. ALL SYSTEMS NOMINAL	CHECK
4. CYCLIC	FORWARD

NOTE

Initiate forward flight acceleration while increasing engine power to take-off mode (in case spare power is available) or pulling back on the collective. This is in order to prevent any sinkage of the helicopter.

If the collective input for take-off power is not enough to compensate for the sinking of the helicopter, it will be necessary to pull back on the cyclic to increase the pitch angle and decrease both the acceleration rate and sink rate.

5. LANDING GEAR	UP
------------------------	-----------

END**RUNNING TAKE-OFF****NOTE**

Take-off technique may be performed when the helicopter is in a stable hover at an altitude no less than 1m. Engines will need to be at take-off power and the field conditions need to permit operations in the rotor-in-ground zone.

1. HOVER CHECK	PERFORM
2. LAND HELICOPTER	CHECK
3. PERMISSION TO TAKE OFF	REQUEST
4. CYCLIC	FORWARD
5. ENGINE POWER	TAKE-OFF MODE

NOTE

Initiate forward acceleration while increasing engine power to take-off mode. Accelerate with the maximum possible rate (pitch angle no more than -10°). The main landing gear wheels will lift-off the ground.

6. INDICATED AIR SPEED	30–40km/h
7. CYCLIC	SLIGHTLY BACK

NOTE

Lift the helicopter off with a negligible pull on the cyclic. Once airborne, accelerate with a gradual climb up to 100–120 km/h and then continue the climb at this airspeed.

8. LANDING GEAR	UP
------------------------	-----------

NOTE

During a crosswind take-off, deflect the cyclic in the direction against the wind; this will compensate the drift in the lift-off moment. Simultaneously, apply pedal input to prevent the wind's yaw momentum. The required controls deflection depends on wind speed.

NOTE

During take-off and landing on dusty or snowy fields, the helicopter creates dust/snow vortices that impact visibility. Take-off and landing in dusty conditions should be performed with the Engines' Dust Protectors (EDP) on. Prior to takeoff it is recommended to blow off the dust from the field with the rotors' wash.

END

Cross-wind

Snow & dust

INU COORDINATE CORRECTION

NOTE

Once you are within 18 km of a reference point, the EKRAN will sound an audio cue and display PERFORM COORDINATES CORRECTION/ПРОВЕДИ КОРРЕКЦ КООРД.

System preparation

1. SHKVAL Press the target mode panel RESET/СБРОС button.	CAGED
2. PVI-800 REFERENCE POINT On the PVI-800, press the FIX PNT/OP button followed by the corresponding reference point number.	SELECTED
3. PVI-800 INU-UPDATE/И251В-ПРОЛ SWITCH	AS DESIRED
4. TERRAIN REFERENCE POINT	VISUALLY LOCATED

NOTE

If a reference point is not located along the flight route it is recommended to perform corrections using the I-251V Shkval. Select either mode and methodology accordingly.

Fly-over/Пол method

1. REFERENCE POINT	FLY OVER
2. CYCLIC UNCAGE SHKVAL BUTTON The current coordinates are replaced by the reference coordinates and the PVI-800 buttons will go out.	PRESS

INU/И251В Shkval method

1. TARGET MODE LAS-OFF/ИЗЛ-ОТКЛ SWITCH	LAS/ИЗЛ
2. CYCLIC UNCAGE SHKVAL BUTTON The Shkval sensor is uncaged.	PRESS
3. SHKVAL CURSOR	MOVE TO REFERENCE POINT
4. SHKVAL TRACKING GATE SIZE	ADJUST TO COVER POINT
5. COLLECTIVE TGT LOCK/АВТ ЗАХВ BUTTON	PRESS
6. TARGET DESIGNATED Shkval displays "TA".	CHECK
7. CYCLIC UNCAGE SHKVAL BUTTON The relative coordinates of the designated target point are calculated, and the current coordinates are replaced by the reference coordinates corrected for the relative target location. During the calculation, the HUD displays "KOPP".	PRESS
8. TARGET MODE RESET/СБРОС BUTTON Once correction is complete. The HUD "KOPP" message is cleared; the PVI-800 FIX PNT/OP button is turned off; Shkval is caged.	PRESS

END

INSTRUMENT APPROACH

Right Panel	1. PVI-800 NAV MASTER MODE KNOB	OPER/РАВ
	2. DESIRED AIRFIELD On the PVI-800, press AIR FIELD/АЭР followed by the appropriate number.	SELECTED
	3. DH-DT/ЗК-ЛЗП SWITCH	AS DESIRED
	4. BANK, PITCH, HDG, ALT HOLD/К, Т, Н, В AUTOPILOT MODE BUTTONS	ON
	5. ADF	SET
Wall Panel	1. MH-GYRO-MAN/МК-ГПК-ЗК SWITCH	GYRO/ГПК
	NOTE If flying at night, in poor weather, or in dusty conditions, set up the aircraft for safe approach flight.	
	2. BLADE TIP LIGHTS/КОНТУР ОГНИ SWITCH	ON
	3. FORM LIGHT/СТРОЕВ ОГНИ SWITCH	100%
OhP	1. NAV LIGHTS/АНО КОД SWITCH	100%
	2. ANTI ICE/DUST PROT / ПОС ДВИГ SWITCH	DUST/ПЗУ
Centre Panel	1. INNER-OUTER/БИЛЖН.-ДАЛЬН. SWITCH	OUTER/ДАЛЬН
	2. MASTER ARM/ГЛАВНЫЙ SWITCH	OFF
	3. WEAP ARM-OFF/ВЕР-НЕ ВЕР SWITCH	OFF/НЕ ВЕР
Front Panel	1. HSI DH/DTA MANUAL-AUTO/ЗПУ-ЗК РУЧН-АУТ SWITCH	AUTO/АУТ
	2. HSI	CHECK
Right Panel	NOTE To automate the navigation process, the ROUTE/MAPШ mode can be used to automatically align the aircraft with the required heading or track for the airport selected on the PVI-800.	
	1. HDG HOLD/Н AUTOPILOT MODE BUTTON	OFF
Coll.	1. DESCENT-ROUTE/СНИЖЕН-МАРШ SWITCH	ROUTE/MAPШ
END		

NIGHT LANDING

Centre Panel	NOTE If flying at night, set up the aircraft lighting for safe landing and taxiing.	
	1. LAND LIGHTS/ПОСАД ФАРЫ SWITCHES - LDG LIGHT-RETRACT/УПР СВЕТ-УБОРКА - MAIN-BACKUP/ОСН-РЕЗЕРВ	LDG LIGHT/ УПР СВЕТ AS NEEDED
Coll.	1. LDG LIGHT/ФАРА НАТ	ADJUST
WP	1. ANTI-COL BEACON/ПРОБЕЛЕСК МАЯК СВ	ON
END		

LANDING**NOTE**

The type of landing is generally chosen according to the landing area (dimensions, condition, and elevation), meteorological conditions, and weight of the helicopter. The landing should take place, if possible, against the wind.

Final approach	1. LANDING	REQUESTED
	2. LANDING GEAR	DOWN
	3. INNER NDB - AIRSPEED - ALTITUDE - SINK RATE	PASS OVER 140km/h 70m 2–3m/s
Vertical landing using the Rotor-in-Ground effect	1. PULL BACK CYCLIC TO DECELERATE - AIRSPEED - ALTITUDE	40–50km/h 20–30m
	2. MAINTAIN STEADY DECELERATION - AIRSPEED - ALTITUDE	0km/h 2–3m
	3. COLLECTIVE - SLOWLY DOWN - FULLY DOWN	UNTIL LANDED WHEN LANDED
Vertical landing without using the Rotor-in-Ground effect	1. DETERMINE SAFE ALTITUDE ABOVE OBSTACLES	ENSURE 10m CLEARANCE
	2. PULL BACK CYCLIC TO DECELERATE - AIRSPEED - VERTICAL SPEED	40–50km/h <2m/s
	3. MAINTAIN STEADY DECELERATION - AIRSPEED - ALTITUDE	0km/h 20–30m
	4. DESCEND FROM HOVER WHILE AVOIDING LATERAL MOVEMENT	ENSURE 5m CLEARANCE
	5. COLLECTIVE - SLOWLY DOWN - FULLY DOWN	UNTIL LANDED WHEN LANDED
Roll-out style landing	1. PULL BACK CYCLIC TO DECELERATE - AIRSPEED - ALTITUDE	60–70km/h 20–30m
	2. MAINTAIN DECELERATION/DESCENT - AIRSPEED - ALTITUDE	30–40km/h 0m
	3. COLLECTIVE - SLOWLY DOWN	UNTIL NOSE WHEEL DOWN
	4. WHEEL BRAKES	SPEED <40km/h

END

ENGINE AND EQUIPMENT SHUT DOWN

Flight controls	1. CYCLIC AND PEDALS	NEUTRAL
	2. COLLECTIVE	FULLY DOWN
Left, Overhead, Front, Right, Back and Wall Panels	1. ALL ELECTRICALLY POWERED EQUIPMENT - K-041 switch - Helmet-mounted Sight - Laser - Nav lights - Winscreen Wipers - Pitot heating - Engine anti-Ice - Landing lights - ABRIS - PVI-800 - Autopilot channels - Signal Flares - L-140 Laser Warning - UV-26 Countermeasures - INU	OFF
	2. SAI	CAGED
	<p>⚠ CAUTION</p> <p>All electrical systems will lose power and turn off automatically if the generators are turned off and/or the engine is throttled down to where it no longer generates sufficient electrical power. To avoid power fluctuations and potential damage, turn the systems off manually before shutting down the generator, and before reducing engine power.</p> <p>If time is of the essence, forceful system shut-down through loss of electrical power from generators and engines is allowed</p> <p>Wait until engine is shut down before turning off any other circuit breakers.</p>	
	3. LH and RH AC SYS GEN/~ТОК ГЕН. ЛЕВ. and ПРАВ. CBS	OFF
Left Panel	1. ENGINE THROTTLE LEVERS	IDLE
	2. ENGINE CUT-OFF VALVES	OFF
	3. ROTOR BRAKE Once rotor RPM is <30%	ON
Wall Panel	1. LEFT and RIGHT FUEL SHUTOFF/ЛЕВ. and ПРАВ. ДВИГ. CBS Once engines are fully spooled down.	OFF
	2. FUEL PUMP/НАСОСЫ БАКОВ CBS	OFF
	3. ALL REMAINING CIRCUIT BRAKERS	OFF
	4. BATTERIES	OFF
END		

INGRESS TO TARGET AREA

ABRIS	1. CHARTS SETUP/НАСТРОЙКА КАРТЫ MENU	SELECT																	
	2. TACTICAL SITUATION / ТАКТИКА OPTION	+																	
	3. NAV/HAB MODE	SELECT																	
	4. MAP SCALE	SET																	
Left, Overhead, Centre, Wall panels	1. LDG LIGHTS/ФАРА	RETRACTED																	
	2. LAS-OFF/ИЗЛ-ОТКЛ	LAS/ИЗЛ																	
	3. NAV LIGHTS/АНО КОД	OFF																	
	4. UV-26 PROGRAM	SET																	
	5. MASTER ARM/ГЛАВНЫЙ SWITCH	ON																	
	6. WEAPON MODES	SET																	
	<table border="1"> <thead> <tr> <th>Mode</th> <th>Burst length</th> <th>Ammunition Store</th> <th>Rate of Fire</th> </tr> </thead> <tbody> <tr> <td>MANUAL/ПУЧН</td> <td>LNG/ДЛ</td> <td>HE/ОФ</td> <td>LOW/MT</td> </tr> <tr> <td>AUTO/АВТ</td> <td>MED/СР</td> <td>API/БР</td> <td>HIGH/БТ</td> </tr> <tr> <td></td> <td>SHORT/КОР</td> <td></td> <td></td> </tr> </tbody> </table>		Mode	Burst length	Ammunition Store	Rate of Fire	MANUAL/ПУЧН	LNG/ДЛ	HE/ОФ	LOW/MT	AUTO/АВТ	MED/СР	API/БР	HIGH/БТ		SHORT/КОР			
	Mode	Burst length	Ammunition Store	Rate of Fire															
MANUAL/ПУЧН	LNG/ДЛ	HE/ОФ	LOW/MT																
AUTO/АВТ	MED/СР	API/БР	HIGH/БТ																
	SHORT/КОР																		
7. ANTI-COL BEACON/ПРОБЛЕСК МАЯК СВ	OFF																		
8. BLADE TIP LIGHTS/КОНТУР ОГНИ СВ	OFF																		
END																			

TARGET/INGRESS POINT DESIGNATION

PVI-800	1. MODE SELECTOR	EDIT/ВВОД
	2. INU-UPDATE/И251В-ПРОЛ SWITCH	INU/И251В
	3. NAV TGT/ОТ BUTTON	PRESS
	4. TARGET POINT NUMBER	PRESS
LP	1. LAS-OFF/ИЗЛ-ОТКЛ	LAS/ИЗЛ
Cyclic and Collective	1. UNCAGE SHKVAL BUTTON	PRESS
	2. SHKVAL CURSOR	MOVE TO TARGET
	3. SHKVAL TRACKING GATE SIZE	ADJUST
	4. TGT LOCK/АВТ ЗАХВ BUTTON	PRESS
	5. UNCAGE SHKVAL BUTTON HUD displays "OT" symbol.	PRESS
PVI-800	1. ENTER/ВВОД BUTTON Target coordinates are stored in the numbered location.	PRESS
	2. MODE SELECTOR	OPER/ПАВ
LP	1. TARGET MODE RESET/СБРОС BUTTON	PRESS
END		

DATA LINK SETUP

LP	1. FLIGHT MEMBER VHF FREQUENCY	CHECK
Wall Panel	1. DL/ТЛК CB	ON
	2. VHF-TLK/УКВ-ТЛК CB	ON
Right Panel	1. ID NO./КТО Я SELECTOR Flight lead is 1, wingmen/second element are 2–3	PER FLIGHT POSITION
	2. DATA/РЕЖИМ SELECTOR	AS REQUIRED
	OFF/ОТКЛ – link disabled; REC/ПРИЕМ – receive only; WINGM/ВЕДОМ – to/from all wing members; COM/КОМ – to/from flight leader only. In WINGM/ВЕДОМ and COM/КОМ mode, wingman icons will be displayed on the ABRIS.	
	3. NAV DATALINK POWER CB	ON/ВЦУ
END		

TARGET/INGRESS POINT DESIGNATION FOR DATA LINK

Overhead Panel	1. TARGET	LOCKED
	2. TARGET TYPE	SELECT
	◇/1: Combat vehicle – △/2: AAA/SAM – □/3: Other – ◻: Ingress point	
	3. SEND/MEM / ПРД/ПАМ BUTTON	PRESS
	4. REPEAT	FOR ALL TARGETS
LP	1. TARGET MODE RESET/СБРОС BUTTON	PRESS
END		

DATA EXCHANGE BETWEEN HELICOPTERS

Overhead Panel	1. TARGET TYPE	SELECT
	2. RECIPIENT(S) The selected button lights up and the recipient's icon will flash on the ABRIS.	SELECT
	3. REPEAT TARGET SELECTION	AS NEEDED
NOTE		
If there is more than one target of the same type in system memory, you will need to go back and press the target type button on the Data Link Control Panel as many times as required to cycle through all targets of the same type in memory. It is important to note that if no recipient is chosen before this step, pressing the target type button will not scroll through your targets on the ABRIS, and nothing will be sent. You must choose a target type, then the recipient, and then go back to the target type button in order to scroll through targets on the ABRIS. The exception to this: if you have selected the DL TO ALL/BCEM button, none of the flight member icons will flash on the ABRIS.		
	4. SEND/MEM / ПРД/ПАМ BUTTON On the ABRIS, the selected target marker symbol and flight member icon will stop blinking and stay solid.	PRESS
NOTE		
If the receiving flight member(s) successfully received and acknowledged data receipt, all the lighted Data Link Panel buttons will turn off. If data receipt is not acknowledged, the SEND/MEM / ПРД/ПАМ button will start blinking. In such a case, press the SEND/MEM / ПРД/ПАМ button again. If DL TO ALL/BCEM was selected, the lighted buttons will turn off regardless of successful data receipt acknowledgement.		
END		

DELETING A DATA LINK TARGET

LP	1. TARGET MODE RESET/СБРОС BUTTON	PRESS
Overhead Panel	1. TARGET TYPE BUTTON If multiple targets of a type have been stored, keep pressing the button until the correct target is selected.	PRESS
	2. CLEAR/СТИП BUTTON The selected target disappear from the ABRIS.	PRESS
END		

SENDING A PVI-800 TARGET POINT

PVI-800	1. NAV TGT/OT BUTTON	PRESS
	2. TARGET POINT NUMBER	PRESS
Overhead Panel	1. TARGET TYPE BUTTON	PRESS
	2. RECIPIENT(S) The selected button lights up.	SELECT
	3. SEND/MEM / ПРД/ПАМ BUTTON Once acknowledgement has been received, all lights on the selected buttons will turn off.	PRESS
END		

AUTOMATIC INGRESS TO TARGET

Overhead Panel	1. TARGET Press the corresponding target type button until the correct target is highlighted on the ABRIS.	SELECT
	2. DL INGRESS/ВЫХОД BUTTON	PRESS
RP	1. DH-DT/3K-ЛЗП SWITCH	DH/3K
Coll.	1. DESCENT-ROUTE/СНИЖЕН-МАРШ SWITCH	ROUTE/МАРШ
Left Panel	1. AUTO TURN/АДВ BUTTON The ABRIS target marker will stop flashing and will marked by a cross.	PRESS
	1. APPROACH TARGET	TO <8km
Cyclic	2. UNCAGE SHKVAL BUTTON	PRESS
	Press the Uncage/Designate target button on the cyclic and begin searching for the target with the Shkval sensor. If necessary, turn on the Shkval's scanning mode by pressing the button again. Once a target is detected, slew the cursor to the target to turn scanning off, adjust the tracking gate size, and turn on automatic tracking.	
OhP	1. DL INGRESS/ВЫХОД BUTTON To turn off ingress mode.	PRESS
END		

9K121 VIKHR ATGM EMPLOYMENT

Preparation	Minimum safe launch altitude – Hover: 10m – Forward flight: 50m	Maximum launch altitude – Barometric: 4,000m – Practical/All speeds: 3,000m	Range to target – Minimum: 800m – Maximum: 8,000m
	1. WEAPON MODES - MAN-AUTO/РУЧН-АВТ MODE SWITCH - BURST (SHORT/КОР=1, OTHERS=2) - HARDPOINTS - MASTER ARM/ГЛАВНЫЙ SWITCH		AS DESIRED AS DESIRED OUTER/ВНЕШН ON
	2. TARGETING MODE - CANNON/OCH РЕЖ SELECTOR - LAS-OFF/ИЗЛ-ОТКЛ SWITCH - AT/AC SWITCH - A/A, A/A HO and MOV GND TGT/ВЦ, ППС and НПС BUTTONS		MOV/ППУ LAS/ИЗЛ ON ON PER TARGET TYPE
	3. TGT LOCK/АВТ ЗАХВ BUTTON To ground stabilise Shkval. “ТГ” symbol will show on display.		PRESS
	4. TARGET TRACKING GATE		SLEW and ADJUST
	5. TGT LOCK/АВТ ЗАХВ BUTTON To lock target. “ТА” symbol will show on display; “ТА-ИД” (auto-tracking) symbol will show on HUD.		PRESS
	6. AUTO TURN/АДВ BUTTON		PRESS
	7. TRACKING GATE ON APPROACH		ADJUST AS NEEDED
Launch	1. MANOEUVRE HELICOPTER TO POSITION TARGET		WITHIN LAUNCH ZONE RETICLE
	2. PARAMETERS FOR LAUNCH Within acceptable range; angular speed <math><3^\circ/s</math>. “C” (launch permitted) symbol displayed on HUD.		CHECK
	3. WEAPONS RELEASE TRIGGER		LOWER To cover cannon trigger
	4. WEAPONS RELEASE TRIGGER		PRESS and HOLD
	5. MAINTAIN POSITIVE AIM		WHILE IN FLIGHT
	6. TARGET MODE RESET/СБРОС BUTTON On target hit to cage the Shkval sensor; turn off target tracking and laser channel; reset weapon type selection; and switch back to NAV mode.		PRESS
NOTE The automatic aiming can be overridden by setting the mode to MANUAL/РУЧН. In this mode, launch permission is granted even if launch parameters are not met.			
END			

KH-25ML AGM EMPLOYMENT

Preparation	Minimum safe launch altitude – Hover: 50m – Forward flight: 100m	Maximum launch altitude – Barometric: 4,000m – Practical/All speeds: 3,000m	Range to target – Minimum: 1km – Maximum: 20km
	1. WEAPON MODES - MAN-AUTO/РУЧН-АВТ MODE SWITCH - HARDPOINTS - MASTER ARM/ГЛАВНЫЙ SWITCH		AUTO/АВЫ OUTER/ВНЕШН ON
	2. TARGETING MODE - CANNON/OCH РЕЖ SELECTOR - LAS-OFF/ИЗЛ-ОТКЛ SWITCH - AT/AC SWITCH - A/A, A/A HO and MOV GND TGT/ВЦ, ППС and НПЦ BUTTONS		MOV/ППУ LAS/ИЗЛ ON ON PER TARGET TYPE
	3. STDBY-NORM/ЛДП-ЛД MODE SWITCH On front panel Laser Designator Control Panel.		UNCOVERED and STDBY/ЛДП
	4. TGT LOCK/АВТ ЗАХВ BUTTON To ground stabilise Shkval. “ТГ” symbol will show on display.		PRESS
	5. TARGET TRACKING GATE		SLEW and ADJUST
	6. TGT LOCK/АВТ ЗАХВ BUTTON To lock target. “ТА” symbol will show on display; “ТА-ИД” (auto-tracking) symbol will show on HUD.		PRESS
	7. AUTO TURN/АДВ BUTTON		PRESS
	8. TRACKING GATE ON APPROACH		ADJUST AS NEEDED
Launch	1. MANOEUVRE HELICOPTER TO POSITION TARGET		WITHIN LAUNCH ZONE RETICLE
	2. PARAMETERS FOR LAUNCH Within acceptable range; angular speed <math><3^\circ/s</math>. “C” (launch permitted) symbol displayed on HUD.		CHECK
	3. WEAPONS RELEASE TRIGGER		LOWER To cover cannon trigger
	4. WEAPONS RELEASE TRIGGER		PRESS and HOLD
	5. MAINTAIN POSITIVE AIM		WHILE IN FLIGHT
	6. TARGET MODE RESET/СБРОС BUTTON On target hit to cage the Shkval sensor; turn off target tracking and laser channel; reset weapon type selection; and switch back to NAV mode.		PRESS
	7. RESET LA/СБРОС ЛДП BUTTON		PRESS
	8. STDBY-NORM/ЛДП-ЛД MODE SWITCH		NORM/ЛД and COVERED
END			

2A42 AND UPK-23 CANNON AUTO-TRACKING EMPLOYMENT

Preparation	Minimum safe altitude – Hover: 10m – Level flight with Shkval: 30m – Level flight without Shkval: 20m	Maximum altitude – Barometric: 4,000m Maximum speed – IAS: 300km/h	Range to target – Minimum: 800m – Maximum: 2,000m – Pitch angle: $\pm 60^\circ$
	1. WEAPON MODES - MAN-AUTO/РУЧН-АВТ MODE SWITCH - LNG-MED-SHORT/ДЛ-СР-КОР SWITCH - HE-АРІ/ОФ-БР SWITCH - LOW-HIGH/МТ-БТ SWITCH - HARDPOINTS - MASTER ARM/ГЛАВНЫЙ SWITCH		AUTO/АВТ AS DESIRED AS DESIRED AS DESIRED PER POD PLACEMENT ON
2. TARGETING MODE - CANNON/OCH РЕЖ SELECTOR - LAS-OFF/ИЗЛ-ОТКЛ SWITCH - AT/AC SWITCH - A/A, A/A HO and MOV GND TGT/ВЦ, ППС and НПС BUTTONS		MOV/ППУ LAS/ИЗЛ ON ON PER TARGET TYPE	
3. UGM В / НП/АКС DIAL On back panel to select UPK-23 ballistics regime.		5	
4. TGT LOCK/АВТ ЗАХВ BUTTON To ground stabilise Shkval. “ТГ” symbol will show on display.		PRESS	
5. TARGET TRACKING GATE		SLEW and ADJUST	
6. TGT LOCK/АВТ ЗАХВ BUTTON To lock target. “ТА” symbol will show on display; “ТА-ИД” (auto-tracking) symbol will show on HUD.		PRESS	
7. AUTO TURN/АДВ BUTTON		PRESS	
8. TRACKING GATE ON APPROACH		ADJUST AS NEEDED	
Launch	1. MANOEUVRE HELICOPTER TO POSITION TARGET		WITHIN RANGE-OF-MOTION GATE
	2. PARAMETERS FOR LAUNCH Within acceptable range, speed, and angle. “С” (launch permitted) symbol displayed on HUD.		CHECK
	3. WEAPONS RELEASE TRIGGER If using the 2A42 30mm cannon.		RAISE To uncover cannon trigger
	4. CANNON/WEAPONS RELEASE TRIGGER		PRESS and HOLD
	5. TARGET MODE RESET/СБРОС BUTTON Once target is hit – cages Shkval sensor; resets tracking and weapon selection settings.		PRESS
NOTE The cannon aiming can be overridden by setting the mode to MANUAL/РУЧН. In this mode, launch permission is granted even if launch parameters are not met.			
END			

2A42 AND UPK-23 CANNON MANUAL EMPLOYMENT

Preparation	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 33%; padding: 5px;"> Minimum safe altitude – Hover: 10m – Level flight with Shkval: 30m – Level flight without Shkval: 20m </td> <td style="width: 33%; padding: 5px;"> Maximum altitude – Barometric: 4,000m Maximum speed – IAS: 300km/h </td> <td style="width: 33%; padding: 5px;"> Range to target – Minimum: 800m – Maximum: 2,000m – Pitch angle: ±60° </td> </tr> </table>	Minimum safe altitude – Hover: 10m – Level flight with Shkval: 30m – Level flight without Shkval: 20m	Maximum altitude – Barometric: 4,000m Maximum speed – IAS: 300km/h	Range to target – Minimum: 800m – Maximum: 2,000m – Pitch angle: ±60°							
	Minimum safe altitude – Hover: 10m – Level flight with Shkval: 30m – Level flight without Shkval: 20m	Maximum altitude – Barometric: 4,000m Maximum speed – IAS: 300km/h	Range to target – Minimum: 800m – Maximum: 2,000m – Pitch angle: ±60°								
<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 70%; padding: 5px;"> 1. WEAPON MODES - MAN-AUTO/РУЧН-АВТ MODE SWITCH - LNG-MED-SHORT/ДЛ-СР-КОР SWITCH - HE-API/ОФ-БР SWITCH - LOW-HIGH/МТ-БТ SWITCH - HARDPOINTS - MASTER ARM/ГЛАВНЫЙ SWITCH </td> <td style="width: 30%; padding: 5px; text-align: center;"> MAN/РУЧН AS DESIRED AS DESIRED AS DESIRED PER POD PLACEMENT ON </td> </tr> <tr> <td style="padding: 5px;"> 2. TARGETING MODE - CANNON/OCH РЕЖ SELECTOR - LAS-OFF/ИЗЛ-ОТКЛ SWITCH - AT/AC SWITCH </td> <td style="padding: 5px; text-align: center;"> FIX/НПУ LAS/ИЗЛ OFF </td> </tr> <tr> <td style="padding: 5px;"> 3. UGM В / НП/АКС DIAL On back panel to set up UPK-23 ballistics regime. </td> <td style="padding: 5px; text-align: center;"> 5 </td> </tr> <tr> <td style="padding: 5px;"> 4. MANOEUVRE TO POSITION TARGET </td> <td style="padding: 5px; text-align: center;"> INSIDE AIM RETICLE </td> </tr> <tr> <td style="padding: 5px;"> 5. TGT LOCK/АВТ ЗАХВ BUTTON To lase target and measure range. The aim reticle will move to the calculated impact point for the range based on the selected ballistics regime. </td> <td style="padding: 5px; text-align: center;"> PRESS </td> </tr> </table>	1. WEAPON MODES - MAN-AUTO/РУЧН-АВТ MODE SWITCH - LNG-MED-SHORT/ДЛ-СР-КОР SWITCH - HE-API/ОФ-БР SWITCH - LOW-HIGH/МТ-БТ SWITCH - HARDPOINTS - MASTER ARM/ГЛАВНЫЙ SWITCH	MAN/РУЧН AS DESIRED AS DESIRED AS DESIRED PER POD PLACEMENT ON	2. TARGETING MODE - CANNON/OCH РЕЖ SELECTOR - LAS-OFF/ИЗЛ-ОТКЛ SWITCH - AT/AC SWITCH	FIX/НПУ LAS/ИЗЛ OFF	3. UGM В / НП/АКС DIAL On back panel to set up UPK-23 ballistics regime.	5	4. MANOEUVRE TO POSITION TARGET	INSIDE AIM RETICLE	5. TGT LOCK/АВТ ЗАХВ BUTTON To lase target and measure range. The aim reticle will move to the calculated impact point for the range based on the selected ballistics regime.	PRESS	
1. WEAPON MODES - MAN-AUTO/РУЧН-АВТ MODE SWITCH - LNG-MED-SHORT/ДЛ-СР-КОР SWITCH - HE-API/ОФ-БР SWITCH - LOW-HIGH/МТ-БТ SWITCH - HARDPOINTS - MASTER ARM/ГЛАВНЫЙ SWITCH	MAN/РУЧН AS DESIRED AS DESIRED AS DESIRED PER POD PLACEMENT ON										
2. TARGETING MODE - CANNON/OCH РЕЖ SELECTOR - LAS-OFF/ИЗЛ-ОТКЛ SWITCH - AT/AC SWITCH	FIX/НПУ LAS/ИЗЛ OFF										
3. UGM В / НП/АКС DIAL On back panel to set up UPK-23 ballistics regime.	5										
4. MANOEUVRE TO POSITION TARGET	INSIDE AIM RETICLE										
5. TGT LOCK/АВТ ЗАХВ BUTTON To lase target and measure range. The aim reticle will move to the calculated impact point for the range based on the selected ballistics regime.	PRESS										
Launch	<table border="1" style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 70%; padding: 5px;"> 1. MANOEUVRE TO POSITION TARGET </td> <td style="width: 30%; padding: 5px; text-align: center;"> INSIDE AIM RETICLE </td> </tr> <tr> <td style="padding: 5px;"> 2. PARAMETERS FOR LAUNCH </td> <td style="padding: 5px; text-align: center;"> CHECK </td> </tr> <tr> <td style="padding: 5px;"> 3. WEAPONS RELEASE TRIGGER If using the 2A42 30mm cannon. </td> <td style="padding: 5px; text-align: center;"> RAISE To uncover cannon trigger </td> </tr> <tr> <td style="padding: 5px;"> 4. CANNON/WEAPONS RELEASE TRIGGER </td> <td style="padding: 5px; text-align: center;"> PRESS and HOLD </td> </tr> </table>	1. MANOEUVRE TO POSITION TARGET	INSIDE AIM RETICLE	2. PARAMETERS FOR LAUNCH	CHECK	3. WEAPONS RELEASE TRIGGER If using the 2A42 30mm cannon.	RAISE To uncover cannon trigger	4. CANNON/WEAPONS RELEASE TRIGGER	PRESS and HOLD		
	1. MANOEUVRE TO POSITION TARGET	INSIDE AIM RETICLE									
	2. PARAMETERS FOR LAUNCH	CHECK									
	3. WEAPONS RELEASE TRIGGER If using the 2A42 30mm cannon.	RAISE To uncover cannon trigger									
4. CANNON/WEAPONS RELEASE TRIGGER	PRESS and HOLD										
NOTE The cannon aiming can also be done wholly manually using the stand-by reticle rather than laser range-finding. To do so, move the HUD mode switch to GRID/CETKA.											
END											
<div style="border: 1px dashed green; height: 20px; width: 100%;"></div>											

S-13 AND S-8 ROCKET AUTO-TRACKING EMPLOYMENT

Preparation	1. WEAPON MODES - MAN-AUTO/РУЧН-АВТ MODE SWITCH - LNG-MED-SHORT/ДЛ-СР-КОР SWITCH - HARDPOINTS - MASTER ARM/ГЛАВНЫЙ SWITCH	AUTO/АВТ AS DESIRED PER POD PLACEMENT ON												
	Short burst = 1 rocket/launcher; Medium = one quarter of stores; Long = half of rockets from each launcher.													
	2. TARGETING MODE - CANNON/OCH РЕЖ SELECTOR - LAS-OFF/ИЗЛ-ОТКЛ SWITCH - AT/AC SWITCH - A/A, A/A HO and MOV GND TGT/ВЦ, ППС and НПЦ BUTTONS	MOV/ППУ LAS/ИЗЛ ON ON PER TARGET TYPE												
3. UGM В / НП/АКС DIAL On back panel to select ballistics regime.	AS REQUIRED													
<table border="1"> <tr> <td>0</td> <td>S-8КОМ AT/AP rockets</td> <td>3</td> <td>S-24 heavy rockets</td> </tr> <tr> <td>1</td> <td>S-8TsM smoke rockets</td> <td>4</td> <td>S-8М HE rockets</td> </tr> <tr> <td>2</td> <td>S-13 rockets</td> <td>5</td> <td>УКР-23 gun pods</td> </tr> </table>			0	S-8КОМ AT/AP rockets	3	S-24 heavy rockets	1	S-8TsM smoke rockets	4	S-8М HE rockets	2	S-13 rockets	5	УКР-23 gun pods
0	S-8КОМ AT/AP rockets	3	S-24 heavy rockets											
1	S-8TsM smoke rockets	4	S-8М HE rockets											
2	S-13 rockets	5	УКР-23 gun pods											
	4. TGT LOCK/АВТ ЗАХВ BUTTON To ground stabilise Shkval. "ТГ" symbol will show on display.	PRESS												
	5. TARGET TRACKING GATE	SLEW AND ADJUST												
	6. TGT LOCK/АВТ ЗАХВ BUTTON To lock target. "ТА" symbol will show on display; "ТА-ИД" (auto-tracking) symbol will show on HUD.	PRESS												
	7. AUTO TURN/АДВ BUTTON	PRESS												
	8. TRACKING GATE ON APPROACH	ADJUST AS NEEDED												
Launch	1. MANOEUVRE TO POSITION TARGET	INSIDE AIM RETICLE												
	2. PARAMETERS FOR LAUNCH Within acceptable range, speed, and angle. "C" (launch permitted) symbol displayed on HUD.	CHECK												
	3. WEAPONS RELEASE TRIGGER	LOWER												
	4. WEAPONS RELEASE TRIGGER	PRESS and HOLD												
	5. TARGET MODE RESET/СБРОС BUTTON Once target is hit – cages Shkval sensor; resets tracking and weapon selection settings.	PRESS												
NOTE The rocket aiming can be overridden by setting the mode to MANUAL/РУЧН. In this mode, launch permission is granted even if launch parameters are not met.														
END														

S-13 AND S-8 ROCKET MANUAL EMPLOYMENT

Preparation	1. WEAPON MODES - MAN-AUTO/РУЧН-АВТ MODE SWITCH - LNG-MED-SHORT/ДЛ-СР-КОР SWITCH - HARDPOINTS - MASTER ARM/ГЛАВНЫЙ SWITCH	MAN/РУЧН AS DESIRED PER POD PLACEMENT ON												
	Short burst = 1 rocket/launcher; Medium = one quarter of stores; Long = half of rockets from each launcher.													
	2. TARGETING MODE - CANNON/OCH РЕЖ SELECTOR - LAS-OFF/ИЗЛ-ОТКЛ SWITCH - AT/AC SWITCH	FIX/НПУ OFF/ОТКЛ OFF												
	3. UGM В / НП/АКС DIAL On back panel to select ballistics regime.	AS REQUIRED												
<table border="1"> <tr> <td>0</td> <td>S-8КОМ AT/AP rockets</td> <td>3</td> <td>S-24 heavy rockets</td> </tr> <tr> <td>1</td> <td>S-8TsM smoke rockets</td> <td>4</td> <td>S-8M HE rockets</td> </tr> <tr> <td>2</td> <td>S-13 rockets</td> <td>5</td> <td>UKP-23 gun pods</td> </tr> </table>			0	S-8КОМ AT/AP rockets	3	S-24 heavy rockets	1	S-8TsM smoke rockets	4	S-8M HE rockets	2	S-13 rockets	5	UKP-23 gun pods
0	S-8КОМ AT/AP rockets	3	S-24 heavy rockets											
1	S-8TsM smoke rockets	4	S-8M HE rockets											
2	S-13 rockets	5	UKP-23 gun pods											
Launch	4. MANOEUVRE TO POSITION TARGET	INSIDE AIM RETICLE												
	5. TGT LOCK/АВТ ЗАХВ БУТТОН To lase target and measure range. The aim reticle will move to the calculated impact point for the range based on the selected ballistics regime.	PRESS												
	1. MANOEUVRE TO POSITION TARGET	INSIDE AIM RETICLE												
	2. PARAMETERS FOR LAUNCH	CHECK												
3. WEAPONS RELEASE TRIGGER	LOWER													
4. WEAPONS RELEASE TRIGGER	PRESS and HOLD													
NOTE The rocket aiming can also be done wholly manually using the stand-by reticle rather than laser range-finding. To do so, move the HUD mode switch to GRID/GETKA.														
END														

BOMB EMPLOYMENT

Preparation	1. WEAPON MODES - HARDPOINTS - MASTER ARM/ГЛАВНЫЙ SWITCH	PER BOMB PLACEMENT ON								
	2. CALCULATE RELEASE POINT	CHECK								
	3. UGM B / НП/АКС DIAL On back panel to select ballistics regime.	AS REQUIRED								
<table border="1"> <tr> <td>7</td> <td>FAB-250 bombs</td> <td>9</td> <td>KMGU-2 RT cluster bombs</td> </tr> <tr> <td>8</td> <td>FAB-500 bombs</td> <td>10</td> <td>KMGU-2 KO cluster bombs</td> </tr> </table>			7	FAB-250 bombs	9	KMGU-2 RT cluster bombs	8	FAB-500 bombs	10	KMGU-2 KO cluster bombs
7	FAB-250 bombs	9	KMGU-2 RT cluster bombs							
8	FAB-500 bombs	10	KMGU-2 KO cluster bombs							
Launch	1. MANOEUVRE TO POSITION TARGET	INSIDE AIM RETICLE								
	2. ALTITUDE >200m	CHECK								
	3. PARAMETERS FOR LAUNCH	CHECK								
	4. WEAPONS RELEASE TRIGGER	LOWER								
	5. WEAPONS RELEASE TRIGGER	PRESS and HOLD								
END										

EGRESS FROM TARGET AREA

Left, Front, Centre Panel	1. TARGET MODE RESET/СБРОС BUTTON	PRESS
	2. RESET LA/СБРОС ЛДП BUTTON	PRESS
	3. STDBY-NORM/ЛДП-ЛД MODE SWITCH	NORM/ЛД and COVERED
	4. MASTER ARM/ГЛАВНЫЙ SWITCH	ON
Overhead, Wall Panel	1. CANNON/ППУ LIGHT OFF	CHECK
	2. NAV LIGHTS/АНО КОД	AS REQUIRED
	3. BLADE TIP LIGHTS/КОНТУР ОГНИ СВ	AS REQUIRED
END		

ABRIS PAGE TRANSLATIONS

MENU / МЕНЮ	DATA / ДАННЫЕ	DATE SETUP / ЧИСЛО: [DATE]			
MENU / МЕНЮ	NAVIGATION DATA / НАВИГАЦИЯ	[DATE]-NO / HET			
	TOPO DATA / ТОПОГРАФИЯ	[DATE]-NO / HET			
	COMPANY ROUTES / КОМП. МАРШРУТЫ	[#] [DATE]-NO / HET			
	ADDITIONAL INFO / ДОП. ИНФОРМАЦИЯ	[#] [DATE]-NO / HET			
	TERRAIN DATA / РЕЛЬЕФ	[DATE]-NO / HET			
	PERF / ТТХ	[DATE]-NO / HET			
	ROUTES / МАРШРУТЫ	[#]-NO / HET			
	METEO / МЕТЕО	[DATE]-NO / HET			
	SEA CHARTS / МОРСКИЕ КАРТЫ	[#]-NO			
	NAV. SENSORS / НАВ. ДАТЧИКИ				
	GNSS / ГНСС	READY-NO / ГОТОВ-HET			
	ALTIMETER / ВЫСОТОМЕР	READY-NO / ГОТОВ-HET			
	RESOURCE / РЕСУРС	[#]			
	S/N / С/Н	[#]			
	VERSION S.W. / ВЕРСИЯ ПО	[#]			
	OPTION/ОПЦИИ	CTRL/УПРАВ	PLAN/ПЛАН	GNSS/CHC	NAV/HAB
	OPTIONS > SETUP > MAIN / ОПЦИИ > УСТАН > ОСНОВН				
	OPTION / ОПЦИИ				
	MAIN / ОСНОВНЫЕ НАСТРОЙКИ				
OPTION MENU / МЕНЮ ОПЦИЯ	MAP MOTION / ДВИЖЕМОЕ КАРТЫ	RELATIVE-TRUE / ОТНОСИТ-ИСТИННОЕ			
	MAP ORIENTATION / ОРИЕНТАЦИЯ КАРТЫ	HEADING-TRACK-NORTH / КУРС-ПУ-СЕВЕР			
	MAP SCALE / МАСШТАБ	USER-AUTO / ВРУЧНУЮ-АВТО			
	TRACK/HEADING / НУ/КУРС	TRUE-MAG / ИСТ-МАГ			
	ALTITUDE / ВЫСОТА	GNSS-BARO-RADIO / ГНСС-БАРО-РАДИО			
	LOCAL TIME / ЧАСОВОЙ ПОЯС	[TIME ZONE]			
	TIME SETUP / ВРЕМЯ	[TIME]			
	DATE SETUP / ЧИСЛО	[DATE]			
	AFT START / ВРЕМЯ ПОЛЕТА	AUTO-USER / АВТО-ВРУЧНУЮ			
	FLIGHT RECORDER / САМОПИСЕЦ	1-(5)-60			
	WPT SEQUENCE / ВЫБОР ППМ	AUTO-USER / АВТО-ВРУЧНУЮ			
	STP PASSED / ПРОЛЕТ ППМ	0-(5)-10 KM			
	XTE SCALE / ШКАЛА ЛБУ				
	MIN	1-2-5-10-20 KM			
	MAX	1-2-5-10-20 KM			
	RMI1 / РМИ1	TO STP-FROM STP-VOR-RADIO-OFF / НА ППМ-ОТ ППМ-VOR-АРК-ВЫКЛ			
	RMI2 / РМИ2	TO STP-FROM STP-VOR-RADIO-OFF / НА ППМ-ОТ ППМ-VOR-АРК-ВЫКЛ			
	RAIM THRESHLD / ПОРОГ RAIM	-99-(100)-999 M			
	SELECT THRESHLD / ВИБОР ПОРОГА	AUTO-USER / АВТО-ВРУЧНУЮ			
	CHECK PSEUDORANGE / УЧЕТ ПСЕВДОДАЛЬНОСТИ	ON-OFF / ВКЛ-ВЫКЛ			
	SETUP/УСТАН	V	Λ	CHANGE/СМЕНА	MENU/МЕНЮ
	OPTIONS > SETUP > UNITS / ОПЦИИ > УСТАН > ЕДИНИЦЫ				
	OPTION / ОПЦИИ				
	UNITS / ЕДИНИЦЫ				
OPTION MENU / МЕНЮ ОПЦИЯ	LATITUDE / ШИРОТА	° ' "N/S- ° 'N/S / ° ' "C/Y- ° 'C/Y			
	LONGITUDE / ДОЛГОТА	° ' "E/W- ° 'E/W / ° ' "B/3- ° 'B/3			
	SPEED / СКОРОСТЬ	KMH-KNOTS-M/S / KM/Ч-УЗЛ-М/С			
	RANGE / РАССТОЯНИЕ	KM-AM-MM / KM-AM-MM			
	ALTITUDE / ВЫСОТА	M-FT / M-ФТ			
	WEIGHT / ВЕС	KG-LB / КГ-ФНТ			
	ELLIPSOID / ЭЛЛИПСОИД	KRASOVSKY-WGS84 / КРАСОВСКОГО-WGS84			
	SETUP/УСТАН	V	Λ	CHANGE/СМЕНА	MENU/МЕНЮ

ABRIS PAGE TRANSLATIONS

OPTION MENU МЕНЮ ОПЦИЯ	OPTIONS > SETUP > PERF / ОПЦИИ > УСТАН > ТТХ			
	OPTION / ОПЦИИ			
	PERFORMANCE SETUP			
	SPEEDS AND BANKS / СКОРОСТИ И КРЕНЫ			
	V1			0-(120)-350 KMH
	V2			0-(160)-350 KMH
	V4			0-(120)-350 KMH
	V SPEED IN CLIMB / НАБОРА НОРМАЛЬНАЯ			0-(130)-350 KMH
	V ECONOMIC SPEED IN CLIMB / НАБОРА МД			0-(130)-350 KMH
	V CRUISING SPEED / КРЕЙС НОРМАЛЬНАЯ			0-(200)-350 KMH
	V ECONOMIC SPEED / КРЕЙС МД			0-(180)-350 KMH
	V SPEED IN DESCENT / СНИЖЕНИЯ НОРМАЛЬНАЯ			0-(120)-350 KMH
	V ECONOMIC SPEED IN DESC. / СНИЖЕНИЯ МД			0-(120)-350 KMH
	VY RATE OF CLIMB / НАБОР			0-(5)-50 M/S
	VY RATE OF DESCENT / СНИЖЕНИЕ			0-(4)-50 M/S
	ENROUTE BANK / КРЕН НА МАРШРУТЕ			0-(15)-60°
	BANK ON APPROACH / КРЕН Б РА			0-(15)-60°
	FUEL / ТОПЛИВО			
	TAXI FUEL / РУЛЕНИЕ			0-(20)-100 KG
	TAKEOFF FUEL / ВЗЛЕТ			0-(20)-100 KG
CRUISE CONSUMPTION / ЭШЕЛОН РАСХОД НОРМ			0-(786)-1500 KG	
ECONOMIC CONSUMPTION / ЭШЕЛОН РАСХОД МД			0-(1000)-1500 KG	
SETUP/УСТАН	V	Λ	CHANGE/СМЕНА	MENU/МЕНЮ
OPTION MENU МЕНЮ ОПЦИЯ	OPTIONS > SETUP > SIGNAL / ОПЦИИ > УСТАН > СИГНАЛ			
	OPTION / ОПЦИИ			
	ALARMS / СИГНАЛИЗАЦИЯ			
	APPROACH TO / ПОДХОД К			
	WPT / ППМ			0-(1)-20 MIN
	TOP-OF-CLIMB / ТОЧКА НАБОРА			0-(1)-20 MIN
	TOP-OF-DESCENT / ТОЧКА СНИЖЕНИЯ			0-(1)-20 MIN
	POINT OF TURN / ТОЧКА НАЧАЛА РАЗВ			0-(1)-20 MIN
	FIR/UIR BOUNDARY / ГРАНИЦА РПИ			0-(1)-20 MIN
	RESTRICTED / ГРАНИЦА ЗОРП			0-(1)-20 MIN
	CONTROLLED / ГРАНИЦА ЦОНЫ УВД			0-(1)-20 MIN
	LIMITS / ЛИМИТ			
	XTE / ПО ЛБУ			0-(1)-20
	CDI / ПО ПУ			0-(20)-90°
	SETUP/УСТАН	V	Λ	CHANGE/СМЕНА
CTRL MENU МЕНЮ УПРАВ	CTRL > SETUP > MSG / УПРАВ > УСТАН > СООБЩЕН			
	CTRL / УПРАВЛЕНИЕ			
	MESSAGES / СООБЩЕНИЯ			
[MESSAGE]			[TIME]	
SETUP/УСТАН	V	Λ	LAST/ПОСЛ	MENU/МЕНЮ
CTRL MENU МЕНЮ УПРАВ	CTRL > SETUP > K-041 / УПРАВ > УСТАН > K-041			
	CTRL / УПРАВЛЕНИЕ			
	K-041			
	MODE / РЕЖИМ			WORK-CHECK
	TIME OUT			[TIME]
	LATITUDE / ШИРОТА			[LATITUDE]
	LONGITUDE / ДОЛГОТА			[LONGITUDE]
	HDNG / КУРС			[ANGLE]
	TRK / ФПУ			[ANGLE]
	SPEED / СКОРОСТЬ			[SPEED]
SETUP/УСТАН			CHANGE/СМЕНА	MENU/МЕНЮ

ABRIS PAGE TRANSLATIONS

OPTION MENU МЕНЮ ОПЦИИ	OPTIONS > SETUP > CHARTS / ОПЦИИ > УСТАН > КАРТЫ						
	OPTION / ОПЦИИ						
	CHARTS SETUP / НАСТРОЙКА КАРТЫ						
	MAP / КАРТА			SEL-ALL-OFF / ВИБ-ВСЕ-ВЫКЛ			
	AIRPORTS / АЭРОДРОМЫ				+/-		
	RUNWAYS / ВПП				+/-		
	AIRPORT COMM / СВЯЗЬ АЭРОДРОМА				+/-		
	ILS				+/-		
	ILS MARKERS / ILS МАРКЕРЫ				+/-		
	TERMINAL NDB / NDB АЭРОДРОМА				+/-		
	VHF NAVAID / СРЕДСТВА ОБЧ				+/-		
	NDB				+/-		
	ENROUTE AIRWAYS / ВОЗДУШНЫЕ ТРАССЫ				+/-		
	FAN MARKERS / ВЕЕРНЫЕ МАРКЕРЫ				+/-		
	ENROUTE WAYPOINTS / ТРАССОВЫЕ ППМ				+/-		
	HOLDING PATTERNS / ЗОНЫ ОЖИДАНИЯ				+/-		
	ENROUTE COMM / ЧАСТОТЫ СВЯЗИ				+/-		
	RESTRICTED AIRSPACE / ОГР. ВОЗДУШНЫЕ ЗОНЫ				+/-		
	TACTICAL SITUATION / ТАКТИКА				+/-		
	POPULATION PLACES / НАС. ПУНКТЫ				+/-		
	LAKES / ОЗЕРА				+/-		
RIVERS / РЕКИ				+/-			
RAILWAYS / ЖЕЛ. ДОРОГИ				+/-			
ROADS / ДОРОГИ				+/-			
CABLE/PIPELINES / ЛИНИИ ЛЭП				+/-			
TEXT / ТЕКСТ				+/-			
LINE OBJECTS / ЛИНЕЙНЫЕ ОБЪЕКТЫ				+/-			
GEO. СЕТКА				+/-			
UTM СЕТКА				+/-			
SETUP/УСТАН		∨	∧	CHANGE/СМЕНА	MENU/МЕНЮ		
CTRL MENU МЕНЮ УПРАВ	CTRL > SETUP > DTB / УПРАВ > УСТАН > БЗД						
	CTRL / УПРАВЛЕНИЕ						
	ONBOARD LOADER / БОРТОВОЙ ЗАГРУЗЧИК						
	NAVIGATION DATA / НАВИГАЦИЯ				[#]-NO / HET		
	TOPO DATA / ТОПОГРАФИЯ				[#]-NO / HET		
	COMPANY ROUTES / КАМП. МАРШРУТЫ				[#] [DATE]-NO / HET		
	ADDITIONAL INFO / ДОП. ИНФОРМАЦИЯ				[#] [DATE]-NO / HET		
	TERRAIN DATA / РЕЛЬЕФ				[#]-NO / HET		
	PERF / ТТХ				[DATE]-NO / HET		
	ROUTES / МАРШРУТЫ				[#]-NO / HET		
	METEO / МЕТЕО				[DATE]-NO / HET		
	SEA CHARTS / МОРСКИЕ КАРТЫ				[DATE]-NO / HET		
	ONBOARD STORAGE / БОРТОВОЙ НАКОПИТЕЛЬ						
	NAVIGATION DATA / НАВИГАЦИЯ				[DATE]		
	TOPO DATA / ТОПОГРАФИЯ				[DATE]		
	COMPANY ROUTES / КАМП. МАРШРУТЫ				[#] [DATE]		
	ADDITIONAL INFO / ДОП. ИНФОРМАЦИЯ				[#] [DATE]		
	TERRAIN DATA / РЕЛЬЕФ				[DATE]		
	PERF / ТТХ				[DATE]		
	ROUTES / МАРШРУТЫ				[#]-NO / HET		
	METEO / МЕТЕО				[DATE]		
SEA CHARTS / МОРСКИЕ КАРТЫ				[#]-NO / HET			
SETUP/УСТАН			LOAD/ЗАГРУЗ	SAVE/СОХРАН	MENU/МЕНЮ		
SETUP/УСТАН				COPY/КОПИР	MENU/МЕНЮ		
SETUP/УСТАН		∨	∧	SAVE/СОХРАН	MENU/МЕНЮ		
PLAN ПЛАН	PLAN > SELECT > REVISE / ПЛАН > ВЫБРАТЬ > ВОЗВРАТ						
	PLAN / ПЛАН						
	TC / ЗИПУ	WIND / A°	TAS / V	DST / СППМ	ETA / ТППМ	FUEL / ОЧАС	ALT / H
	TH / ИК	KMH / M/C	GS KMH / WM/C	REM KM / СОСТKM	ETA / ТПРОЛ	REM / GOCT	T°C
	TO / HA >[#]	[LATITUDE]	[LONGITUDE]				
	[ANGLE]	[ANGLE]	[#]	[#]	[TIME]		[#]
				[TIME]	[#]		
[ANGLE]	[ANGLE]	[#]	[#]			[#]	
SELECT/ВЫБРАТЬ		EDIT/РЕДАКТ		ACTIV/АКТ		MENU/МЕНЮ	

ABRIS PAGE TRANSLATIONS

PLAN MENU МЕНЮ ПЛАН	ADD INF > ADD LIN / ДОП. ИНФ > ДОБ.ЛИН					
	LINE / ЛИНИЯ					
	LAT / ШИР		[LATITUDE]			
	LON / ДОЛ		[LONGITUDE]			
	ALTITUDE / ВЫСОТА		[ALTITUDE]			
	MVR / СКЛ		[ANGLE]			
	RANGE / РАССТОЯНИЕ		[RANGE]			
	BEARING / АЗИМУТ		[ANGLE]			
	OPPOSITE / ОБРАТНЫЙ		[ANGLE]			
	ENTER / ВВОД		COLOR / ЦВЕТ	SCALE+/МCШТБ+	SCALE-/МCШТБ-	CANCEL/ОТМЕНА
PLAN MENU МЕНЮ ПЛАН	PLAN > EDIT > DRAW / ПЛАН > РЕДАКТ > РИСОВ					
	PLAN / ПЛАН					
	[#] [NAME]		FBY-OVR-FIN / ТНП-ТОП-ТЗП	MVR / СКЛ	[#]	[LATITUDE]
			TCA / ИПУ	[ANGLE]	TH / ИК	[ANGLE]
						DIST / PCT [DISTANCE]
	EDIT/РЕДАКТ	DELETE/УДАЛИТЬ		SCALE+/МCШТБ+	SCALE-/МCШТБ-	PLAN/ПЛАН
	ADD/ДОБАВ			SCALE+/МCШТБ+	SCALE-/МCШТБ-	PLAN/ПЛАН
ENTER/ВВОД	MOVE/СДВИГ		>>	SEARCH/ПОИСК	CANCEL/ОТМЕНА	
PLAN MEN. МЕН.ПЛАН	PLAN > EDIT > SPEED / ПЛАН > РЕДАКТ > СКОР					
	PLAN / ПЛАН					
	[#] [NAME]		TAS / ИВС	DIST / PCT	TENR / ТУЧ	ETA / ТППМ
			[#]	[#]	[TIME]	[TIME]
EDIT/РЕДАКТ			SCALE+/МCШТБ+	SCALE-/МCШТБ-	PLAN/ПЛАН	
PLAN MEN. МЕН.ПЛАН	PLAN > EDIT > VNAV / ПЛАН > РЕДАКТ > ВНАВ					
	PLAN / ПЛАН					
	[#] [NAME]		S	ALT / H	VY	
			[#]	@	[#]	[#]
EDIT/РЕДАКТ	CLEAR/ОЧИСТКА		SCALE+/МCШТБ+	SCALE-/МCШТБ-	PLAN/ПЛАН	
PLAN MEN. МЕН.ПЛАН	PLAN > EDIT > METEO / ПЛАН > РЕДАКТ > МЕТЕО					
	PLAN / ПЛАН					
	[#] [NAME]		WIND DIR/VEL / ВЕТЕР	T°C		
		[ANGLE]° / [#] KMH	[#]	[TIME]		
EDIT/РЕДАКТ			SCALE+/МCШТБ+	SCALE-/МCШТБ-	PLAN/ПЛАН	
PLAN MEN. МЕН.ПЛАН	PLAN > EDIT > FUEL / ПЛАН > РЕДАКТ > ТОПЛИВО					
	PLAN / ПЛАН					
	[#] [NAME]		REM / ГОСТ	FUEL / QЧАС	TENR / ТУЧ	
		[#]	[#]	[TIME]		
EDIT/РЕДАКТ			SCALE+/МCШТБ+	SCALE-/МCШТБ-	PLAN/ПЛАН	
GNSS СНС	GNSS / СНС					
	GNSS INFORMATION / ИНФОРМАЦИЯ ГНСС					
	SENSOR / ДАТЧИК		[ID]			
	LAST FIX / ПОСЛ ВРМ		[TIME]			
	POS / ПОЗ		[LAT/LONG]			
	ALT / ВЫС		[ALTITUDE]			
	GS / ПС		[SPEED]			
	TRK / ФПУ		[ANGLE]			
	PREC HOR / ТОЧН ГОР		[DISTANCE]			
	PREC VER / ТОЧН ВЕР		[DISTANCE]			
	PDOP		[#]			
	HDOP		[#]			
	VDOP		[#]			
	TDOP		[#]			
	SYSTEM / СИСТЕМА		[ID]			
	SV TRACK / КА СЛЕЖ		[#]			
	USE / ИСП		[#]			
	RAIM		[#]			
	OK / ХОРОШО		USER-AUTO / МАРШП-ВРУЧНУЮ			
	MENU/МЕНЮ	USER/РУЧН		CALC/РАСЧ	SYST/СИСТ	NAV/НАВ

ABRIS PAGE TRANSLATIONS

GNSS MENU МЕНЮ CHC	GNSS > CALC / CHC > PACЧ			
	CALC / PACЧ			
GNSS MENU МЕНЮ CHC	GNSS INFORMATION / ИНФОРМАЦИЯ ГНСС			
	SENSOR / ДАТЧИК			[ID]
	LAST FIX / ПОСЛ ВРМ			[TIME]
	POS / ПОЗ			[LAT/LONG]
	ALT / ВЫС			[ALTITUDE]
	GS / ПС			[SPEED]
	TRK / ФПУ			[ANGLE]
	PREC HOR / ТОЧН ГОР			[DISTANCE]
	PREC VER / ТОЧН ВЕР			[DISTANCE]
	PDOP			[#]
	HDOP			[#]
	VDOP			[#]
	TDOP			[#]
	SYSTEM / СИСТЕМА			[ID]
	SV TRACK / КА СЛЕЖ			[#]
	USE / ИСП			[#]
	DESTINATION AIRDROME / АЭРОДРОМ НАЗНАЧЕНИЯ			[NAME]
	ETA / ВРЕМЯ ПРИБЫТИЯ			[TIME]
	POS / ПОЗ			[LAT/LONG]
	PRAIM ETA			[TIME DIFF.]
MENU/МЕНЮ	GNSS/CHC	>>	ENTER/ВВОД	NAV/HAB
GNSS MENU МЕНЮ CHC	GNSS > SYST / CHC > СИСТ			
	SYST / СИСТ			
GNSS MENU МЕНЮ CHC	MAIN CPU-YES / ОСН. ПРОЦЕССОР-ДА			
	FLASH 988 MB / РПЗУ 988МБ			NAV SENSOR / НАВ.ДАТЧИК
	[#]			POWER / БЛОК ЭП
	RAM 2048MB / ОЗУ 2048МБ			RS
	[#]			ANALOG / ЦАП
				1234
				DIGITAL / АЦП
				12345
				ARINC
				TX RX
				0 0
				1 1
				2 2
				3 3
	1 2 3 4 5			ARINC-429
				X-PCB
	RESOURCE / РЕСУРС			[#]
	S/N / С/Н			[#]
	VERSION SW / ВЕРСИЯ ПО			[#]
	SETUP/УСТ	GNSS/ГНСС		TEST/ТЕСТ
GNSS CHC	GNSS > SYST > SETUP > ARINC / CHC > СИСТ > УСТ > ARINC			
	SYST / СИСТ			
GNSS CHC	MAIN CPU-YES / ОСН. ПРОЦЕССОР-ДА			
	SETUP/УСТ	GNSS/ГНСС		TEST/ТЕСТ
GNSS CHC	GNSS > SYST > SETUP > RS-232 / CHC > СИСТ > УСТ > RS-232			
	SYST / СИСТ			
GNSS CHC	MAIN CPU-YES / ОСН. ПРОЦЕССОР-ДА			
	SETUP/УСТ	GNSS/ГНСС		TEST/ТЕСТ
GNSS CHC	GNSS > SYST > SETUP > ANALOG / CHC > СИСТ > УСТ > ЦАП			
	SYST / СИСТ			
GNSS CHC	MAIN CPU-YES / ОСН. ПРОЦЕССОР-ДА			
	SETUP/УСТ	GNSS/ГНСС		TEST/ТЕСТ
GNSS CHC	GNSS > SYST > SETUP > DIGITAL / CHC > СИСТ > УСТ > АЦП			
	SYST / СИСТ			
GNSS CHC	MAIN CPU-YES / ОСН. ПРОЦЕССОР-ДА			
	SETUP/УСТ	GNSS/ГНСС		TEST/ТЕСТ

ABRIS PAGE TRANSLATIONS

GNSS MENU МЕНЮ СНС	GNSS > SYST > SETUP > BUILT / СНС > СИСТ > УСТ > ВСТРОЕН						
	SYST/СИСТ						
	BUILT-IN SENSOR SETUP						
	SENSOR / ДАТЧИК		ASHTech GG12				
	COM PORT / ПОРТ		BUILT				
	BAUD RATE / СКОРОСТЬ БОД		1200-2400-4800-9600- 19200 -3844-57600-115200				
	DATA BITS / БИТЫ ДАННЫХ		4-5-6-7- 8				
	PARITY / ЧЕТНОСТЬ		NO -ЧЕТ-НЕЧЕТ-MARKER-ПРОБЕЛ / НЕТ -ЧЕТ-НЕЧЕТ-MARKER-ПРОБЕЛ				
	STOP BITS / СТОП БИТ		1.0 -1.5-2.0				
	FLOW CONTROL / КОНТРОЛЬ		HARDWARE -XON/XOFF- NO / АППАРАТНОЕ -XON/XOFF- НЕТ				
	SYSTEM / ИСП ГПС		GPS/GLONASS -GPS / ГПС/ГЛОНАСС -GPS				
	PDOP MASK / МАСКА PDOP		[4.0]				
	ELEV MASK / МАСКА ВОЗВ		[5]°				
	EXCLUDE SV / ИСКЛЮЧИТЬ КА		[0]				
SAVE & TEST / СОХР И ТЕСТ		-					
SETUP/УСТ		V		Λ	CHANGE/СМЕНА	NAV/HAB	
GNSS СНС	GNSS > SYST > SETUP > AUDIO / СНС > СИСТ > УСТ > АУДИО						
	SYST / СИСТ						
MAIN CPU-YES / ОСН. ПРОЦЕССОР-ДА							
SETUP/УСТ		GNSS/ГНСС		TEST/ТЕСТ	NAV/HAB		
GNSS СНС	GNSS > SYST > SETUP > D/C / СНС > СИСТ > УСТ > РК						
	SYST / СИСТ						
MAIN CPU-YES / ОСН. ПРОЦЕССОР-ДА							
SETUP/УСТ		GNSS/ГНСС		TEST/ТЕСТ	NAV/HAB		
GNSS СНС	GNSS > SYST > SETUP > TEST / СНС > СИСТ > УСТ > ТЕСТ						
	SYST / СИСТ						
MAIN CPU-YES / ОСН. ПРОЦЕССОР-ДА							
SETUP/УСТ		GNSS/ГНСС		TEST/ТЕСТ	NAV/HAB		
GNSS СНС	GNSS > SYST > SETUP > LOG / СНС > СИСТ > УСТ > ТРАССА						
	SYST / СИСТ						
MAIN CPU-YES / ОСН. ПРОЦЕССОР-ДА							
SETUP/УСТ		GNSS/ГНСС		TEST/ТЕСТ	NAV/HAB		
GNSS СНС	GNSS > SYST > SETUP > SOFT / СНС > СИСТ > УСТ > ПО						
	SYST / СИСТ						
MAIN CPU-YES / ОСН. ПРОЦЕССОР-ДА							
SETUP/УСТ		GNSS/ГНСС		TEST/ТЕСТ	NAV/HAB		
NAV НАВ	NAV / НАВ						
	TRK/ФЮУ [#]° T						
	GS / ПС	[#] KMH	TO / НА	[ID]	[ID]		
	BRG / ПНГ	[#] °	DTA / ЗПУ	[#] °	[#] °		
	AFT / T	[TIME]	DST / PCT	[#] KM	[#] KM		
	ALT / ВЫС	[#]	ETA / ТППМ	[TIME]	[TIME]		
		[LATITUDE]		[TIME]			
		[LONGITUDE]					
	SEARCH/ПОИСК		MAP/КАРТА		FPL/ШБЖ	SUSP/ПУЧН	ARC/ОБЗОР
	NAV MENU МЕНЮ НАВ	NAV > SEARCH > AIRPORT / НАВ > ПОИСК > АЭРОДРОМ					
SEARCH / ПОИСК							
Λ V NEAREST AIRPORTS / БЛИЖАЙШИЕ АЭРОДРОМЫ							
[#]		[NAME]	[ANGLE] ° T				
	[ALTITUDE]	CIVIL-MIL / ГРАЖД-ВОЕН	[DISTANCE]				
	RUNWAYS / ВПП [LENGTH]						
SEARCH/ПОИСК		TO/НА		INFO/ИНФО	NAME/ИМЯ	NAV/HAB	
NAV MENU МЕНЮ НАВ	NAV > SEARCH > VOR / НАВ > ПОИСК > VOR						
	SEARCH / ПОИСК						
	Λ V NEAREST VOR / БЛИЖАЙШИЕ VOR						
	[#]	[NAME]	[ANGLE] ° T				
	D [FREQUENCY]	[CODE] VOR	[DISTANCE]				
	(L) [MORSE SIGNAL]						
SEARCH/ПОИСК		TO/НА		INFO/ИНФО	NAME/ИМЯ	NAV/HAB	
NAV MENU МЕНЮ НАВ	NAV > SEARCH > NDB / НАВ > ПОИСК > ОПРС						
	SEARCH / ПОИСК						
	Λ V NEAREST NDB / БЛИЖАЙШИЕ ОПРС						
	[#]	[NAME]	[ANGLE] ° T				
	D [FREQUENCY]	[CODE]	[DISTANCE]				
	(L) [MORSE SIGNAL]						
SEARCH/ПОИСК		TO/НА		INFO/ИНФО	NAME/ИМЯ	NAV/HAB	

ABRIS PAGE TRANSLATIONS

NAV MENU МЕНЮ НАВ	NAV > SEARCH > WPT / НАВ > ПОИСК > ППМ				
	SEARCH / ПОИСК				
	^ V NEAREST WPT / БЛИЖАЙШИЕ ППМ				
	[#]	[NAME]		[ANGLE] ° T	
		INT-REFPOINT		[DISTANCE]	
	SEARCH/ПОИСК	ТО/НА	INFO/ИНФО	NAME/ИМЯ	NAV/НАВ
NAV MENU МЕНЮ НАВ	NAV > SEARCH > TOWN / НАВ > ПОИСК > ГОРОД				
	SEARCH / ПОИСК				
	^ V NEAREST TOWN / БЛИЖАЙШИЕ ГОРОДА				
	[#]	[NAME]			
	SEARCH/ПОИСК	ТО/НА	INFO/ИНФО	NAME/ИМЯ	NAV/НАВ
NAV MENU МЕНЮ НАВ	MAP / КАРТА				
			TRK/ФЮУ [#] ° T		
	GS / ПС	[#] KMH	TO / HA	[ID]	[ID]
	BRG / ПНГ	[#] °	DTA / ЗПУ	[#] °	[#] °
	AFT / T	[TIME]	DST / PCT	[#] KM	[#] KM
	ALT / ВЫС	[#]	ETA / ТППМ	[TIME]	[TIME]
		[LATITUDE]		[TIME]	
		[LONGITUDE]			
	INFO/ИНФО	ERBL/МЕРИТЬ	SCALE+/МСШТБ+	SCALE-/МСШТБ-	NAV/НАВ
NAV MENU МЕНЮ НАВ	NAV > MAP > ERBL / НАВ > КАРТА > МЕРИТЬ				
	MAP / КАРТА				
	TRK / ФПУ	[ANGLE] °	ERB	[LATITUDE]	[LONGITUDE]
	GS / ПС	[#] KMH	BRG	[ANGLE] ° / [ANGLE] °	
	BRG / ПНГ	[ANGLE] °	DST	[#]	
	AFT / T	[TIME]	ALT / ВЫС	[#]	
	ALT / ВЫС	[#] M	MVR / ЦКЛ	[ANGLE] °	
	INFO/ИНФО	MARKER/МАРКЕР	SCALE+/МСШТБ+	SCALE-/МСШТБ-	NAV/НАВ
NAV MENU МЕНЮ НАВ	NAV > FPL > НАВ > ШБЖ				
	FPL / ШБЖ				
	[NAME]				
	TC / ЗИПУ	WIND / A°	TAS / V	DST / СППМ	ETA / ТППМ
	TH / ИК	KMH / KM/Ч	GS KMH / WKM/Ч	REM KM / СОСТКМ	ETA / ТПРОЛ
	> OT	[#] [NAME]	[LATITUDE]	[LONGITUDE]	
	[ANGLE]	[ANGLE]	[#]	[#]	[#]
	[ANGLE]	[ANGLE]	[#]	[#]	[#]
	[ANGLE]	[ANGLE]	[#]	[#]	[#]
	TO / HA>	[#] [NAME]	[LATITUDE]	[LONGITUDE]	
	REM / СОСТ	[#] KM	ETE	[TIME]	FUEL
					[#] KG
	VNAV/BHAB	ТО/НА		WPT/ППМ	NAV/НАВ
PLAN MEN. МЕН.ПЛАН	NAV > FPL > VNAV / НАВ > ШБЖ > BHAB				
	VNAV / BHAB				
	[#] [NAME]	S	@	ALT / H	VY
	[#]	[#]	[#]	[#]	[#]
	EDIT/РЕДАКТ	VNAV TO/BHAB HA	TGT VS/ЗАД ВУ	ACTIV/AKT	NAV/НАВ
ARC / HSI ОБРОЗ / ПНП	ARC / ОБРОЗ and HSI / ПНП				
			TRK/ФЮУ [#] ° T		
	[ANGLE] ° TO STP / HA	ППМ			VNAV / BHAB
	[ANGLE] ° RADIO / APK				[SCALE]
	GS / ПС	[#] KMH	TO / HA	[ID]	[ID]
	BRG / ПНГ	[#] °	DTA / ЗПУ	[#] °	[#] °
	AFT / T	[TIME]	DST / PCT	[#] KM	[#] KM
	ALT / ВЫС	[#]	ETA / ТППМ	[TIME]	[TIME]
		[LATITUDE]		[TIME]	
		[LONGITUDE]			
	SEARCH/ПОИСК	MAP/КАРТА	FPL/ШБЖ	SUSP/РУЧН	HSI/ПНП
	SEARCH/ПОИСК	MAP/КАРТА	FPL/ШБЖ	SUSP/РУЧН	MENU/МЕНЮ